

OMAP35x EVM Linux PSP

User Guide



02.01.03.11

Publication date 10 September 2009

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

TI products are not authorized for use in safety-critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of TI products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by TI. Further, Buyers must fully indemnify TI and its representatives against any damages arising out of the use of TI products in such safety-critical applications.

TI products are neither designed nor intended for use in military/aerospace applications or environments unless the TI products are specifically designated by TI as military-grade or "enhanced plastic." Only products designated by TI as military-grade meet military specifications. Buyers acknowledge and agree that any such use of TI products which TI has not designated as military-grade is solely at the Buyer's risk, and that they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI products are neither designed nor intended for use in automotive applications or environments unless the specific TI products are designated by TI as compliant with ISO/TS 16949 requirements. Buyers acknowledge and agree that, if they use any non-designated products in automotive applications, TI will not be responsible for any failure to meet such requirements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

Products		Applications	
Amplifiers	amplifier.ti.com	Audio	www.ti.com/audio
Data Converters	dataconverter.ti.com	Automotive	www.ti.com/automotive
DSP	dsp.ti.com	Broadband	www.ti.com/broadband
Interface	interface.ti.com	Digital Control	www.ti.com/digitalcontrol
Logic	logic.ti.com	Military	www.ti.com/military
Power Mgmt	power.ti.com	Optical Networking	www.ti.com/opticalnetwork
Microcontrollers	microcontroller.ti.com	Security	www.ti.com/security
		Security	www.ti.com/security
		Telephony	www.ti.com/telephony
		Video & Imaging	www.ti.com/video
		Wireless	www.ti.com/wireless

Mailing Address:

Texas Instruments,
Post Office Box 655303,
Dallas, Texas 75265

Table of Contents

Read This First	xvii
1. Installation	1
1.1. System Requirements	2
1.2. Installation	3
1.3. Installation Steps	5
1.4. Environment Setup	6
1.5. Setup NFS filesystem	7
2. x-loader	9
2.1. Introduction	10
2.2. Compiling X-Loader	11
2.3. Signing x-load.bin	12
2.4. Flashing x-loader	13
2.4.1. OneNAND	13
2.4.2. NAND	13
2.5. Preparing MMC/SD for boot	14
2.5.1. Creating bootable partition	14
2.5.2. Copying x-loader	14
3. U-Boot	15
3.1. Compiling U-Boot	17
3.2. Flashing U-Boot	18
3.2.1. OneNAND	18
3.2.2. Micron NAND	18
3.3. Configuring U-Boot	19
3.3.1. Using ramdisk image	19
3.3.2. Using NFS (Default U-Boot configuration)	19
3.3.3. Using NFS with no DHCP in Linux	20
3.4. Managing OneNAND	22

3.4.1. Marking a bad block	22
3.4.2. Erasing OneNAND	22
3.4.3. Writing to OneNAND	23
3.4.4. Reading from OneNAND	23
3.4.5. Scrubbing OneNAND	24
3.5. Managing NAND	25
3.5.1. Marking a bad block	25
3.5.2. Viewing bad blocks	25
3.5.3. Erasing NAND	25
3.5.4. Writing to NAND	26
3.5.5. Reading from NAND	27
3.5.6. Unlocking NAND address space	27
3.5.7. NAND ECC algorithm selection	28
4. Kernel	29
4.1. Compiling Linux Kernel	30
4.2. Configuring Linux Kernel	31
4.2.1. Build configuration for OMAP35x	31
4.3. Booting Linux Kernel	34
4.3.1. Selecting boot mode	34
5. Audio Driver	37
5.1. Introduction	39
5.1.1. References	39
5.1.2. Acronyms & Definitions	39
5.2. Features	41
5.2.1. Features Supported	41
5.2.2. Constraints	41
5.3. Architecture	43
5.3.1. ALSA SoC Layer	43
5.3.2. Design	43
5.4. Driver Configuration	45

5.4.1. Configuration Steps	45
5.4.2. Installation	55
5.5. Software Interfaces	56
5.5.1. Application Interface	56
5.5.2. Driver Interface	59
5.6. Sample Applications	63
5.6.1. Introduction	63
5.6.2. A minimal playback application	63
5.6.3. A minimal record application	67
5.7. Revision History	70
6. Display Driver	71
6.1. Introduction	73
6.1.1. References	73
6.1.2. Acronyms & Definitions	73
6.1.3. Hardware Overview	73
6.2. Features	74
6.2.1. Overview	74
6.2.2. Usage	74
6.3. Architecture	101
6.3.1. Driver Architecture	101
6.3.2. Software Design Interfaces	101
6.4. Software Interfaces	103
6.4.1. 'fbdev' Driver Interface	103
6.4.2. V4L2 Driver Interface	104
6.4.3. SYSFS Software Design Interfaces	106
6.5. Driver Configuration	107
6.5.1. Configuration Steps	107
6.5.2. Installation	113
6.6. Sample Application Flow	115
6.7. Revision History	117

7. Resizer Driver	119
7.1. Introduction	121
7.1.1. References	121
7.1.2. Acronyms	121
7.1.3. Hardware Overview	121
7.2. Features	122
7.2.1. Overview of features supported	122
7.2.2. Usage of Features	122
7.2.3. Constraints	128
7.3. Architecture	130
7.4. Software Interface	131
7.4.1. Application Programming Interface	131
7.4.2. IOCTLs	132
7.4.3. Data Structures	136
7.5. Driver Configuration	141
7.5.1. Configuration Steps	141
7.6. Sample Application Flow	144
7.7. Revision History	145
8. Daughter Card Module	147
8.1. Mass Market Daughter Card	148
8.1.1. Acronyms & Definitions	148
8.1.2. Introduction	148
8.2. Block Diagram	149
8.3. Board Illustration	150
8.4. Features supported under software	151
9. Capture Driver	153
9.1. Introduction	155
9.1.1. References	156
9.1.2. Acronyms & Definitions	157

9.2. Features	158
9.2.1. Supported features	158
9.2.2. Constraints/Limitations	158
9.2.3. Known Issues	158
9.3. Architecture	160
9.3.1. System Diagram	160
9.3.2. Software Design Interfaces	162
9.4. Driver Configuration	178
9.4.1. Configuration Steps	178
9.4.2. Installation	182
9.5. Sample Applications	184
9.5.1. Introduction	184
9.5.2. Hardware Setup	184
9.5.3. Provided Sample Applications	184
10. USB Driver	185
10.1. Introduction	187
10.1.1. References	187
10.1.2. Hardware Overview	187
10.2. Features	189
10.2.1. Supported	189
10.2.2. Not supported	189
10.3. Driver configuration	191
10.3.1. USB phy selection for MUSB OTG port	191
10.3.2. USB controller in host mode	191
10.3.3. MUSB OTG controller in gadget mode	192
10.3.4. MUSB OTG controller in OTG mode	193
10.3.5. Host mode applications	194
10.3.6. USB Controller and USB MSC HOST	194
10.3.7. USB HID Class	195
10.3.8. USB Controller and USB HID	196
10.3.9. USB Audio	196

10.3.10. USB Video	197
10.3.11. Gadget Mode Applications	198
10.3.12. CDC/RNDIS gadget	199
10.3.13. USB OTG (HNP/SRP) testing	200
10.4. Software Interface	202
10.4.1. sysfs	202
10.4.2. procfs	202
10.5. Revision history	203
11. MMC Driver	205
11.1. Introduction	206
11.1.1. References	206
11.1.2. Acronyms & Definitions	206
11.2. Features	207
11.2.1. Features Supported	207
11.2.2. Features Not Supported	207
11.2.3. Limitations	207
11.3. Revision History	208
12. Power Management	209
12.1. Introduction	211
12.1.1. References	211
12.2. Features	212
12.2.1. Supported	212
12.2.2. Not Supported	212
12.2.3. Limitations	212
12.3. Architecture	213
12.3.1. cpuidle	213
12.3.2. Dynamic Tick Suppression	215
12.3.3. Suspend & Resume	215
12.4. Configuration	216
12.4.1. cpuidle	216

12.4.2. cpufreq	217
12.4.3. SmartReflex	217
12.5. Software Interface	219
12.5.1. cpuidle	219
12.5.2. Suspend & Resume	220
12.5.3. SmartReflex	220
12.6. Revision History	222

List of Figures

4.1. Boot switch position	34
5.1. ALSA SoC Architecture	44
5.2. Configure ALSA Driver: Step 2	45
5.3. Configure ALSA Driver: Step 3	46
5.4. Configure ALSA Driver: Step 4	47
5.5. Configure ALSA Driver: Step 5	48
5.6. Configure ALSA Driver: Step 6	49
5.7. Configure ALSA Driver: Step 7	50
5.8. Configure ALSA Driver: Step 8	51
5.9. Configure ALSA Driver: Step 9	52
5.10. Configure ALSA Driver: Step 10	53
5.11. Configure ALSA Driver: Step 11	54
5.12. Configure ALSA Driver: Step 12	55
5.13. OMAP3 ALSA Driver : Half duplex playback	58
5.14. OMAP3 ALSA Driver : Half duplex record	58
5.15. State Diagram	61
5.16. Data flow path	62
6.1. Video source color Keying	84
6.2. Video destination color Keying	85
6.3. Alpha blending with almost 50% transparency	88
6.4. Alpha blending with almost 100% transparency	89
6.5. Alpha blending with almost 0% transparency	89
6.6. 1-BPP Data Memory Organization	94
6.7. 2-BPP Data Memory Organization	94
6.8. 4-BPP Data Memory Organization	94
6.9. 8-BPP Data Memory Organization	94
6.10. 12-BPP Data Memory Organization	95
6.11. 16-BPP Data Memory Organization	95
6.12. 24-BPP Data Memory Organization	95
6.13. ARGB 32-BPP Data Memory Organization	95

6.14. RGBA 32-BPP Data Memory Organization	95
6.15. 24-BPP Packed Data Memory Organization	96
6.16. UYVY 4:2:2 Data Memory Organization	96
6.17. YUV2 4:2:2 Data Memory Organization	96
6.18. OMAP35x Display Subsystem Architecture	101
6.19. Configure V4L2 video Driver: Step 2	107
6.20. configure V4L2 video Driver: Step 3	107
6.21. Configure V4L2 video Driver: Step 4	108
6.22. Configure V4L2 video Driver: Step 5	108
6.23. Configure V4L2 video Driver: Step 6	109
6.24. Configure Graphics display Driver: Step 2	109
6.25. configure Graphics display Driver: Step 3	110
6.26. configure Graphics display Driver: Step 4	110
6.27. configure Graphics display Driver: Step 5	111
6.28. Select TV as default output device: Step 6	111
6.29. Select NTSC_M as TV mode: Step 6	112
6.30. Select Composite out as TV out interface: Step 6	113
6.31. Application for v4l2 driver using MMAP buffers	115
6.32. Application for FBDEV driver	116
7.1. OMAP Resizer HW Block Diagram	121
7.2. Basic Architecture of Resizer Driver	130
7.3. Configure omap-resizer Driver: Step 2	141
7.4. configure omap-resizer Driver: Step 3	141
7.5. Configure omap-resizer Driver: Step 4	142
7.6. Configure omap-resizer Driver: Step 5	142
7.7. Configure omap-resizer Driver: Step 6	143
7.8. Resizer Sample Application Flow	144
8.1. Block Diagram	149
8.2. Board Illustration	150
9.1. Capture Driver Component Overview	155
9.2. Capture Physical Input Interface	156

9.3. Capture Driver Basic Architecture	160
9.4. Configure Capture Driver: Step 4	178
9.5. Configure Capture Driver: Step 5	179
9.6. Configure Capture Driver: Step 6	179
9.7. Configure Capture Driver: Step 7	180
9.8. Configure Capture Driver: Step 8	181
9.9. Configure Capture Driver: Step 9	182
10.1. MUSB OTG: Location of Mini-AB receptacle on the EVM	188
10.2. MUSB OTG: Location of USB PHY from NXP on the EVM	188
10.3. USB Driver: Illustration of Mass Storage Class	194
10.4. USB Driver: Illustration of HID Class	195
12.1. cpuidle overview	213

List of Tables

5.1. Acronyms	39
5.2. Audio Driver : Constraints	41
5.3. Device Interface	56
5.4. Proc Interface	56
5.5. Commonly Used APIs	57
6.1. Acronyms	73
6.2. Memory requirement for V4L2 and FBDEV driver Buffers	77
7.1. Resizer: Input Size Calculation	126
7.2. Resizer: open System Call arguments	131
7.3. Resizer: close system call arguments	131
7.4. Resizer: mmap system call arguments	132
7.5. Resizer: munmap system call arguments	132
7.6. Resizer: ioctl RSZ_S_PARAMS arguments	133
7.7. Resizer: ioctl RSZ_G_PARAMS arguments	133
7.8. Resizer: ioctl RSZ_G_STATUS argument	134
7.9. Resizer: ioctl RSZ_S_EXP argument	134
7.10. Resizer: ioctl RSZ_RESIZE arguments	135
7.11. Resizer: ioctl RSZ_REQBUF arguments	135
7.12. Resizer: ioctl RSZ_QUERYBUF arguments	136
7.13. Resizer: ioctl RSZ_QUEUEBUF arguments	136
7.14. Resizer: Parameters Configuration Structure fields	137
7.15. Resizer: Request Buffer Structure fields	137
7.16. Resizer: Buffer structure fields	138
7.17. Resizer: Luma enhancement structure fields	138
7.18. Resizer: Status structure fields	139
7.19. Resizer: Crop Size structure fields	139
8.1. MMDC Acronyms	148
9.1. Capture Driver Acronyms	157
10.1. OMAP3 USB Driver: sysfs attributes	202
11.1. Acronyms	206

12.1. C-states in OMAP3	214
-------------------------------	-----

Read This First

About This Manual

This document describes how to install and work with Texas Instruments' (TI) Platform Support Package for OMAP35x platform for Linux 2.6.29-rc3. The PSP Package serves to provide a fundamental software platform for development, deployment and execution. This abstracts the functionality provided by the hardware. The product forms the basis for all application development on this platform.

In this context, the document contains instructions to:

- Install the release
- Build the sources contained in the release

The document also provides detailed overview of specific drivers and modules contained in the PSP package.

- Audio Driver
- Video Display Driver
- Resizer Driver
- Video Capture Driver
- USB Driver
- MMC Driver
- Power Management

How to Use This Manual

This document includes the following chapters:

- Chapter 1, *Installation* - describes the installation procedure for OMAP35x EVM Linux PSP package.
- Chapter 2, *x-loader* - describes the procedure to build and execute the x-loader. and
- Chapter 3, *U-Boot* - describes the procedure to build and execute U-Boot.
- Chapter 4, *Kernel* - describes the procedure to build and execute the Linux kernel.
- Chapter 5, *Audio Driver* - describes the implementation of audio driver.
- Chapter 6, *Display Driver* - describes the implementation of video display driver.
- Chapter 7, *Resizer Driver* - describes the implementation of resizer driver.
- Chapter 8, *Daughter Card Module* - describes the features available on Daughter card.
- Chapter 9, *Capture Driver* - describes the implementation of video capture driver.
- Chapter 10, *USB Driver* - describes the implementation of USB driver.
- Chapter 11, *MMC Driver* - describes the implementation of MMC driver.
- Chapter 12, *Power Management* - describes the power management frameworks.

Please go through the Release Notes document available in the release package before starting the installation.

Notation of information elements

The document may contain these additional elements:



Warning

This is an example of warning message. It usually indicates a non-recoverable change, e.g. formatting a filesystem.

**Caution**

This is an example of caution message.

**Important**

This is an example of important message.

**Note**

This is an example of additional note. This usually indicates additional information in the current context.

**Tip**

This is an example of a useful tip.

If You Need Assistance

For any assistance, please send an mail to software support [<mailto:softwaresupport@ti.com>].

Trademarks

OMAP™ is a trademark of Texas Instruments Incorporated.

All other trademarks are the property of the respective owner.

Installation

Abstract

Table of Contents

1.1. System Requirements	2
1.2. Installation	3
1.3. Installation Steps	5
1.4. Environment Setup	6
1.5. Setup NFS filesystem	7

1.1. System Requirements

Hardware Requirements:

- OMAP EVM Main Board (REV C or later) and OMAP35XX Processor Board with OMAP35x ES 2.1/3.1 Processor (REV B or later) This release also supports the OMAP EVM2 Main board with ES3.1 processor.

Software Requirements:

- Code Sourcery ARM tool chain version 2008-q1

1.2. Installation

Extract the contents of release package with the following command:

```
$ tar -xvfz OMAP35x-PSP-SDK-MM.mm.pp.bb.tgz
```

This creates a directory OMAP35x-PSP-SDK-MM.mm.pp.bb with the following contents:

```
\---OMAP35x-PSP-SDK-MM.mm.pp.bb
|-- License.html
|-- Software-manifest.html
|-- docs
|   |-- Building-RootFs-Arago.html
|   |-- DataSheet-MM.mm.pp.bb.pdf
|   |-- GettingStarted.pdf
|   |-- MigrationGuide-MM.mm.pp.bb.pdf
|   |-- ReleaseNotes-MM.mm.pp.bb.pdf
|   `-- UserGuide-MM.mm.pp.bb.pdf
|-- host-tools
|   |-- linux
|   |   `-- signGP
|   |-- src
|   |   `-- signGP.c
|   |-- windows
|   |   |-- PumpKIN.exe
|   |   |-- PumpKIN.hlp
|   |   |-- peripheral-boot-images
|   |   |   |-- Readme.txt
|   |   |   |-- dnld_startup_omap3_evm.bin
|   |   |   `-- peripheral-u-boot.bin
|   |   |-- utilities
|   |   |   |-- CommunicationInterface.dll
|   |   |   |-- CoreEngine.dll
|   |   |   |-- DownloadUtility.exe
|   |   |   `-- DownloadUtility.ini
|   `-- images
|       |-- boot-strap
|       |   `-- x-load.bin.ift
|       |-- examples
|       |-- fs
|       |   |-- nfs-base.tar.gz
|       |   |-- nfs.tar.gz
|       |   |-- ramdisk-base.gz
|       |   |-- ramdisk.gz
|       |   |-- rootfs-base.jffs2
|       |   `-- rootfs.jffs2
|       |-- kernel
|       |   `-- uImage
|       |-- u-boot
|       |   `-- u-boot.bin
|       `-- utils
```

```

|-- itbok.bin
-- scripts
|-- Readme.txt
|-- initenv-micron.txt
|-- initenv-samsung.txt
|-- reflash-micron.txt
|-- reflash-samsung.txt
-- src
|-- boot-strap
|-- ChangeLog-MM.mm.pp.bb
|-- ShortLog
|-- Unified-patch-MM.mm.pp.bb.gz
|-- diffstat-MM.mm.pp.bb
|-- x-loader-patches-
MM.mm.pp.bb.tar.gz
|-- x-loader-MM.mm.pp.bb.tar.gz
-- examples
|-- examples.tar.gz
-- kernel
|-- Readme.txt
|-- ChangeLog-MM.mm.pp.bb
|-- ShortLog
|-- Unified-patch-MM.mm.pp.bb.gz
|-- diffstat-MM.mm.pp.bb
|-- kernel-patches-
MM.mm.pp.bb.tar.gz
|-- linux-MM.mm.pp.bb.tar.gz
-- u-boot
|-- Readme.txt
|-- ChangeLog-MM.mm.pp.bb
|-- ShortLog
|-- Unified-patch-MM.mm.pp.bb.gz
|-- diffstat-MM.mm.pp.bb
|-- u-boot-MM.mm.pp.bb.tar.gz
|-- uboot-patches-
MM.mm.pp.bb.tar.gz
|-- utils
|-- Readme.txt
|-- ITBOK-AND-UBOOT.tar.bz2
|-- dnld-util-target.tar.bz2
-- test-suite
|-- lftb-MM.mm.pp.bb.tar.gz
|-- lptb-MM.mm.pp.bb.tar.gz

```



Important

The values of *MM*, *mm*, *pp* and *bb* in this illustration will vary across the releases and actually depends on individual component versions.

1.3. Installation Steps

Instructions for initial setup of the EVM are contained in the OMAP3 EVM Users Guide included with the EVM kit.

Refer section 2.1 for the detailed instructions to bring-up the EVM.

To use the pre-built binaries included in the release, skip to section 2.4. You can always return to section 2.1 for instructions on how to build the x-loader, u-boot and Linux kernel.

1.4. Environment Setup

1. Set the environment variable PATH to contain the binaries of the CodeSourcery cross-compiler tool-chain.
2. For example, in bash:

```
$ export PATH=/opt/toolchain/2008-q1/bin:$PATH
```

Add location of u-boot tools to the PATH environment variable.

3. For example, in bash:

```
$ export PATH=/opt/u-boot/tools:$PATH
```



Note

Actual instructions and the path setting will depend upon your shell and location of the tools

1.5. Setup NFS filesystem

This step is required when root filesystem is mounted from an NFS location.

Extract the contents of the NFS image (nfs.tar.bz2) to a directory exported via NFS.

```
$ cd /opt/nfs/target  
$ tar xjfv nfs.tar.bz2
```



Important

Execute this command as 'root' user. Some of the files included in this archive require root permissions for creation.

x-loader

Abstract

Table of Contents

2.1. Introduction	10
2.2. Compiling X-Loader	11
2.3. Signing x-load.bin	12
2.4. Flashing x-loader	13
2.4.1. OneNAND	13
2.4.2. NAND	13
2.5. Preparing MMC/SD for boot	14
2.5.1. Creating bootable partition	14
2.5.2. Copying x-loader	14

2.1. Introduction

X-loader is loaded by ROM boot loader into internal RAM. X-loader support boot from OneNAND, NAND, MMC/SD.

2.2. Compiling X-Loader

Change to the base of the X-Loader directory.

```
$ cd ./x-load
```

Remove the intermediate files generated during build. This step is not necessary when building for the first time.

```
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm distclean
```

Choose the configuration for OMAP3 EVM.

```
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm  
omap3evm_config
```

Initiate the build.

```
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm
```

On successful completion, file `x-load.bin` will be created in the current directory.

2.3. Signing x-load.bin

The file `x-load.bin` needs to be signed before it can be used by the ROM bootloader.

To sign the X-Loader binary: (look for `signGP` tool under `host-tools/linux` folder)

```
$ signGP x-load.bin
```

The signing utility creates `x-load.bin.ift` in the current directory.

2.4. Flashing x-loader

2.4.1. OneNAND

To flash the x-loader into OneNAND, execute following commands at the U-Boot prompt:

```
OMAP3EVM# mw.b 0x80000000 0xFF 0x100000  
OMAP3EVM# tftp 0x80000000 x-load.bin.ift
```



Note

On Older U-boot versions(from PSP 1.0.x releases), the OneNand will have to be unlocked before write/erase operation. For subsequent releases of u-boot, this step is not required.

```
OMAP3EVM# onenand unlock 0x000000 0x20000
```

```
OMAP3EVM# onenand erase 0x00000000 0x00080000  
OMAP3EVM# onenand write 0x80000000 0x0 0x10000
```

2.4.2. NAND

To flash the x-loader into Micron NAND, execute following commands at the U-Boot prompt:

```
OMAP3EVM# mw.b 0x80000000 0xFF 0x100000  
OMAP3EVM# tftp 0x80000000 x-load.bin.ift  
OMAP3EVM# nand unlock  
OMAP3EVM# nand erase 0 40000  
OMAP3EVM# nandecc hw  
OMAP3EVM# nand write.i 0x80000000 0 40000  
OMAP3EVM# nand lock
```



Note

nandecc command has changed from the previous release.

2.5. Preparing MMC/SD for boot

2.5.1. Creating bootable partition

To be able to boot from MMC/SD, there should be valid bootable partition on the card.

Use HP USB Disk Storage Format Tool (available from <http://www.systanalyzer.com/sp27213.exe>) and follow the steps below:

Specifically Use version 2.0.6 of the HP Disk Format Tool. Later versions do work well with the boot code.

- Connect the card reader to the Windows machine where the formatting tool has been installed.
- Insert MMC/SD card into the card reader.
- Launch the HP USB Disk Storage Format Tool.
- Select **FAT32** as File System.
- Click on **Start**.
- After formatting is done Click **OK**.

2.5.2. Copying x-loader

Copy the `x-load.bin.ift` to the MMC/SD card and rename it as `MLO`.

Once the U-Boot and Linux kernel are built, `u-boot.bin`, `uImage` and `ramdisk.gz` should be copied to the card.

U-Boot

Abstract

This chapter describes the steps required to build and configure u-boot to use different filesystems during the kernel boot.

It also describes new commands for managing bad blocks.

Table of Contents

3.1. Compiling U-Boot	17
3.2. Flashing U-Boot	18
3.2.1. OneNAND	18
3.2.2. Micron NAND	18
3.3. Configuring U-Boot	19
3.3.1. Using ramdisk image	19
3.3.2. Using NFS (Default U-Boot configuration)	19

3.3.3. Using NFS with no DHCP in Linux	20
3.4. Managing OneNAND	22
3.4.1. Marking a bad block	22
3.4.2. Erasing OneNAND	22
3.4.3. Writing to OneNAND	23
3.4.4. Reading from OneNAND	23
3.4.5. Scrubbing OneNAND	24
3.5. Managing NAND	25
3.5.1. Marking a bad block	25
3.5.2. Viewing bad blocks	25
3.5.3. Erasing NAND	25
3.5.4. Writing to NAND	26
3.5.5. Reading from NAND	27
3.5.6. Unlocking NAND address space	27
3.5.7. NAND ECC algorithm selection	28

3.1. Compiling U-Boot

Change to the base of the u-boot directory.

```
$ cd ./u-boot
```

Remove the intermediate files generated during build. This step is not necessary when building for the first time.

```
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm distclean
```

Choose the configuration for OMAP3 EVM.

```
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm  
omap3_evm_config
```

Initiate the build.

```
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm
```

On successful completion, file `u-boot.bin` will be created in the current directory.



Note

The u-boot build commands have changed from the previous release.

3.2. Flashing U-Boot

3.2.1. OneNAND

To flash `u-boot.bin` to the OneNAND execute the commands listed below:

```
OMAP3EVM# mw.b 0x80000000 0xFF 0x100000
OMAP3EVM# tftp 0x80000000 u-boot.bin
```



Note

With Older U-boot versions(from PSP 1.0.x releases), the OneNand will have to be unlocked before erase/write operation. For subsequent releases of u-boot, this step is not required.

```
OMAP3EVM# onenand unlock 0x000000 0x300000
```

```
OMAP3EVM# onenand erase 0x00080000 0x001C0000
OMAP3EVM# onenand write 0x80000000 0x80000 0x1C0000
```

3.2.2. Micron NAND

To flash `u-boot.bin` to the Micron NAND execute the commands listed below:

```
OMAP3EVM# mw.b 0x80000000 0xFF 0x100000
OMAP3EVM# tftp 0x80000000 u-boot.bin
OMAP3EVM# nand unlock
OMAP3EVM# nand erase 0x80000 0x1C0000
OMAP3EVM# nandeccl sw
OMAP3EVM# nand write.i 0x80000000 0x80000 0x1C0000
OMAP3EVM# nand lock
```



Note

`nandeccl` command has changed from the previous release.

3.3. Configuring U-Boot

This section assumes that EVM has been setup properly.

1. Enable UART1 on the EVM : On Jumper J8 select 1-2
2. Connect EVM (UART1) to the HOST PC through serial cable.
3. Start a terminal emulator (e.g. Hyperterm) on the HOST PC.
4. Power on EVM and wait for u-boot to come up.

Some commands entered on the console are long. The command text may appear wrapped in the document. Wherever indicated, these commands must be entered in a single line.

3.3.1. Using ramdisk image

Set the bootargs:

```
OMAP3EVM# setenv bootargs mem=128M console=ttyS0,115200n8
          root=/dev/ram0 rw initrd=0x81600000,16M ip=dhcp
          mpu=600
```



Note

The entire command should be entered in a single line.

Set the bootcmd:

```
OMAP3EVM# setenv bootcmd 'dhcp;
tftp 0x80000000 uImage;tftp 0x81600000 ramdisk.gz;
bootm 80000000'
```



Note

The entire command should be entered in a single line.

3.3.2. Using NFS (Default U-Boot configuration)

Set the bootargs:

```
OMAP3EVM# setenv bootargs console=ttyS0,115200n8 noinitrd
```

```
ip=dhcp rw root=/dev/nfs nfsroot=192.168.1.101:
/opt/nfs/target,nolock,rsiz=4096,wsiz=4096 mem=128M
mpurate=600
```


Note

- The entire command should be entered in a single line.
- Replace NFS server IP address(192.168.1.101) and mount path(/opt/nfs/target) with actuals based on your NFS server setting.

Set the bootcmd:

```
OMAP3EVM# setenv 'bootcmd dhcp;tftp 0x80000000 uImage;bootm'
```

3.3.3. Using NFS with no DHCP in Linux

Disable the DHCP support in the build configuration:

```
Device Drivers
Networking Support
Networking options
IP: DHCP Support
```

Set the bootargs:

```
OMAP3EVM# setenv bootargs 'console=ttyS0,115200n8 noinitrd rw
root=/dev/nfs nfsroot=192.168.1.101:
/opt/nfs/target,nolock,rsiz=4096,wsiz=4096 mem=128M
mpurate=600'
```

Set the bootcmd:

```
OMAP3EVM# setenv bootcmd 'dhcp;setenv addip setenv bootargs
$(bootargs)
ip=$(ipaddr):$(serverip):$(gatewayip):$(netmask):
$(hostname)::off eth=$(ethaddr);run addip;
tftp 0x80000000 uImage; bootm 0x80000000'
```


Note

The entire command should be entered in a single line.



Important

To save the variables on the flash, use the u-boot command **saveenv**.

3.4. Managing OneNAND

The u-boot has been updated to include bad block management for OneNAND. These updates also impacted behavior of existing OneNAND commands. This section describes the new and modified commands added for the purpose.

3.4.1. Marking a bad block

To forcefully mark a block as bad:

```
OMAP3EVM# onenand markbad <offset>
```

For example, to mark block 32 (assuming erase block size of 128Kbytes) as bad block - offset = blocknum * 128 * 1024:

```
OMAP3EVM# onenand markbad 0x400000
```

3.4.2. Erasing OneNAND

To erase OneNAND blocks in the address range:

```
OMAP3EVM# onenand erase <stoffsaddr> <endoffsaddr>  
or  
OMAP3EVM# onenand erase block <stblknum-endblknum>
```



Note

The behavior of this command was modified.

This commands skips bad blocks (both factory or user marked) encountered within the specified range.



Important

If the erase operation fails, the block is marked bad and the command aborts. To continue erase operation, the command needs to be re-executed for the remaining blocks in the range.

For example, to erase blocks 32 through 34:

```
OMAP3EVM# onenand erase 0x00400000 0x00440000
or
OMAP3EVM# onenand erase block 32-34
```

3.4.3. Writing to OneNAND

To write *len* bytes of data from a memory buffer located at *addr* to the OneNAND block *offset*:

```
OMAP3EVM# onenand write <addr> <offset> <len>
```



Note

The behavior of this command was modified.

If a bad block is encountered during the write operation, it is skipped and the write operation continues from next 'good' block.



Important

If the write fails on ECC check, the block where the failure occurred is marked bad and write operation is aborted. The command needs to be re-executed to complete the write operation. The offset and length for reading have to be page aligned else the command will abort.

For example, to write 0x40000 bytes from memory buffer at address 0x80000000 to OneNAND - starting at block 32 (offset 0x400000):

```
OMAP3EVM# onenand write 0x80000000 0x400000 0x40000
```

3.4.4. Reading from OneNAND

To read *len* bytes of data from OneNAND block at *offset* to memory buffer located at *addr*:

```
OMAP3EVM# onenand read <addr> <offset> <len>
```



Note

The behavior of this command was modified.

If a bad block is encountered during the read operation, it is skipped and the read operation continues from next 'good' block.



Important

If the read fails on ECC check, the block where the failure occurred is marked bad and read operation is aborted. The command needs to be re-executed to complete the read operation. But, the data in just marked bad block is irrecoverably lost. The offset and length for reading have to be page aligned else the command will abort.

For example, to read 0x40000 bytes from OneNAND - starting at block 32 (offset 0x400000) to memory buffer at address 0x80000000:

```
OMAP3EVM# onenand read 0x80000000 0x400000 0x40000
```

3.4.5. Scrubbing OneNAND

This command operation is similar to the `erase` command, with a difference that it doesn't care for bad blocks. It attempts to erase all blocks in the specified address range.

To scrub OneNAND blocks in the address range:

```
OMAP3EVM# onenand scrub <stoffsaddr> <eoffsaddr>
or
OMAP3EVM# onenand scrub block <stblknum-endblknum>
```



Note

This is a new command.



Important

The command does not check whether the block is a user marked or factory marked bad block. This command fails on a factory marked bad block.



Important

If the erase operation fails, the block is marked as bad and the command aborts. The command needs to be re-executed for the remaining blocks in the range.

3.5. Managing NAND

The u-boot has been updated to include NAND flash support

3.5.1. Marking a bad block

To forcefully mark a block as bad:

```
OMAP3EVM# nand markbad <offset>
```



Note

This is a new command.

For example, to mark block 32 (assuming erase block size of 128Kbytes) as bad block - $\text{offset} = \text{blocknum} * 128 * 1024$:

```
OMAP3EVM# nand markbad 0x400000
```

3.5.2. Viewing bad blocks

Gives a list of bad blocks in NAND

```
OMAP3EVM# nand bad
```



Note

The user marked bad blocks can be viewed by using this command only after a reset.

3.5.3. Erasing NAND

To erase NAND blocks in the address range or using block numbers

```
OMAP3EVM# nand erase <stoffsaddr> <len>
```

**Note**

The behavior of this command was modified.

This command skips bad blocks (both factory or user marked) encountered within the specified range.

**Important**

If the erase operation fails, the block is marked bad and the command aborts. To continue erase operation, the command needs to be re-executed for the remaining blocks in the range.

For example, to erase blocks 32 through 34

```
OMAP3EVM# nand erase 0x00400000 0x40000
```

3.5.4. Writing to NAND

To write *len* bytes of data from a memory buffer located at *addr* to the NAND block *offset*:

```
OMAP3EVM# nand write <addr> <offset> <len>
```

**Note**

The behavior of this command was modified.

If a bad block is encountered during the write operation, it is skipped and the write operation continues from next 'good' block.

**Important**

If the write fails on ECC check, the block where the failure occurred is marked bad and write operation is aborted. The command needs to be re-executed to complete the write operation. The offset and length for reading have to be page aligned else the command will abort.

For example, to write 0x40000 bytes from memory buffer at address 0x80000000 to NAND - starting at block 32 (offset 0x400000):

```
OMAP3EVM# nand write 0x80000000 0x400000 0x40000
```


3.5.5. Reading from NAND

To read *len* bytes of data from NAND block at *offset* to memory buffer located at *addr*:

```
OMAP3EVM# nand read <addr> <offset> <len>
```



Note

The behavior of this command was modified.

If a bad block is encountered during the read operation, it is skipped and the read operation continues from next 'good' block.



Important

If the read fails on ECC check, the block where the failure occurred is marked bad and read operation is aborted. The command needs to be re- executed to complete the read operation. But, the data in just marked bad block is irrecoverably lost. The offset and length for reading have to be page aligned else the command will abort.

For example, to read 0x40000 bytes from NAND - starting at block 32 (offset 0x400000) to memory buffer at address 0x80000000:

```
OMAP3EVM# nand read 0x80000000 0x400000 0x40000
```

3.5.6. Unlocking NAND address space

To unlock NAND flash for writing

```
OMAP3EVM# nand unlock <offset> <len>
```



Note

This is a new command.

For example, to unlock block 32 (assuming erase block size of 128Kbytes)

```
OMAP3EVM# nand unlock 0x20000
```

3.5.7. NAND ECC algorithm selection

To select ECC algorithm for NAND

```
OMAP3EVM# nandecc <sw/hw>
```

**Note**

To write X-loader from U-Boot, ECC algorithm to be selected is HW since bootrom uses this algorithm for reading. To write U-Boot from U-Boot, ECC algorithm to be selected is SW.

```
OMAP3EVM# nandecc hw  
or  
OMAP3EVM# nandecc sw
```

Kernel

Abstract

Table of Contents

4.1. Compiling Linux Kernel	30
4.2. Configuring Linux Kernel	31
4.2.1. Build configuration for OMAP35x	31
4.3. Booting Linux Kernel	34
4.3.1. Selecting boot mode	34

4.1. Compiling Linux Kernel

Change to the base of the Linux source directory.

Create default configuration for the OMAP3EVM.

```
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm  
omap3_evm_defconfig
```

Initiate the build.



Note

For the kernel image(uImage) to be built, mkimage utility must be included in the path. mkimage utility is generated(under tools folder) while building u-boot.bin

```
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm uImage
```

On successful completion, file uImage will be created in the directory ./arch/arm/boot.

Copy this file to the root directory of your TFTP server.

4.2. Configuring Linux Kernel

Enter following command to make changes to default configuration. The configuration options for various drivers will be described in the PSP datasheet

```
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm menuconfig
```

Following drivers are enabled in the default configuration:

- Serial port
- Mentor USB in Host mode
- USB EHCI
- Ethernet
- MMC/SD
- Video Display
- Audio
- NAND and OneNAND
- Touchscreen

4.2.1. Build configuration for OMAP35x

The default configuration included in the release contains all default values to build Linux kernel for **OMAP35x EVM**. The specific processor type - OMAP3503, OMAP3515, OMAP3525 and OMAP3530 - is detected at runtime.

This section illustrates these configuration items for reference.

To create default configuration:

```
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm  
omap3_evm_defconfig
```

To view configuration:

```
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm menuconfig
```

From the onscreen menu, select **System Type**:

```

General setup  --->
[*] Enable loadable module support  --->
[*] Enable the block layer  --->
System Type  --->
Bus support  --->
Kernel Features  --->
...

```

These items would be selected by default:

- OMAP35x Family
- OMAP 3530 EVM board

```

ARM system type (TI OMAP)  --->
TI OMAP Implementations  --->
-- OMAP34xx Based System
--   OMAP3430 support
[*] OMAP35x Family
    *** OMAP Board Type ***
[ ] OMAP3 LDP board
[ ] OMAP 3430 SDP board
[*] OMAP 3530 EVM board
...

```

Choose **Exit** to return to the previous menu.

4.2.1.1. Power module PR785

The OMAP3EVM ships with power module using TPS65950 PMIC. If the board uses PR785 power module, following changes are necessary:

From the onscreen menu, select **System Type**.

```

Code maturity level options  --->
General setup  --->
Loadable module support  --->
Block layer  --->
System Type  --->

```

Now select **PR785 Power board selection for OMAP3 EVM --->**.

```

ARM system type (TI OMAP)  --->

```

```
TI OMAP Implementations --->
-- OMAP34xx Based System
--   OMAP3430 support
[*] OMAP35x Family
    *** OMAP Board Type ***
[ ] OMAP3 LDP board
[ ] OMAP 3430 SDP board
[*] OMAP 3530 EVM board
    PR785 Power board selection for OMAP3 EVM --->
        [ ] Power board for OMAP3 EVM
[ ] OMAP3 BEAGLE board
...
...
```

Now select **Power board for OMAP3 EVM**.

Return back to main menu, and select **Device Drivers**

Now select **Multifunction device drivers**

From this sub-menu, deselect **Texas Instruments TWL4030/TPS659x0 Support**.

Return back to main menu, and select **Device Drivers**

Now select **Voltage and Current Regulator Support**

From this sub-menu, select **TPS6235X Power regulator for OMAP3EVM (NEW)**

Save the configuration.

4.3. Booting Linux Kernel

4.3.1. Selecting boot mode

Boot mode can be selected using dip switch SW4 on the EVM. It is shown below in figure boot switch and "SW-1" in the figure indicates pin 1 position in the SW4 dip switch on the EVM and similarly it is mapped for other pins.

Boot Mode	SW-1	SW-2	SW-3	SW-4	SW-5	SW-6
MMC with OneNAND	OFF	OFF	ON	ON	ON	x
MMC with OneNAND	ON	OFF	OFF	ON	ON	x
MMC with NAND	OFF	ON	ON	ON	OFF	x
MMC with NAND	ON	ON	ON	OFF	OFF	x
OneNAND	ON	ON	ON	ON	ON	x
OneNAND	ON	OFF	OFF	ON	OFF	x
NAND	OFF	ON	ON	ON	ON	x
NAND	OFF	ON	OFF	ON	OFF	x

Figure 4.1. Boot switch position



Note

This selection identifies the location from where the x-loader and u-boot binaries are executed.

Power on EVM and wait for u-boot to come up.



Important

Ensure that u-boot environment variables `bootargs` and `bootcmd` are properly set. See section 3.3 for more details.

In addition, set these environment variables with correct values:

- serverip
- bootfile

For example:

```
OMAP3EVM# setenv serverip xx.xx.xx.xx
OMAP3EVM# setenv bootfile uImage
```


To boot the Linux kernel from OneNAND/NAND:

```
OMAP3EVM# boot
```

To boot the Linux kernel from MMC/SD card, set the mmcboot environment variable as follows (only an illustration - substitute with actual image path and load address for your system)

```
OMAP3EVM# setenv mmcboot 'mmcinit; fatload mmc 0 0x82000000  
uImage; bootm 0x82000000'  
OMAP3EVM# saveenv
```

In case of boot from MMC/SD card and using ramdisk image as the filesystem, set the mmcboot environment variable as follows (only an illustration - substitute with actual image path and load address for your system)

```
OMAP3EVM# setenv mmcboot 'mmcinit; fatload mmc 0 0x82000000  
uImage; fatload mmc 0 0x83600000 ramdisk.gz; bootm 0x82000000'  
OMAP3EVM# saveenv
```

Once setup, the mmcboot variable can be exercised as follows:

```
OMAP3EVM# run mmcboot
```

Once the Linux kernel boots, login as "root". No password is required.

Audio Driver

Abstract

Table of Contents

5.1. Introduction	39
5.1.1. References	39
5.1.2. Acronyms & Definitions	39
5.2. Features	41
5.2.1. Features Supported	41
5.2.2. Constraints	41
5.3. Architecture	43
5.3.1. ALSA SoC Layer	43
5.3.2. Design	43
5.4. Driver Configuration	45

5.4.1. Configuration Steps	45
5.4.2. Installation	55
5.5. Software Interfaces	56
5.5.1. Application Interface	56
5.5.2. Driver Interface	59
5.6. Sample Applications	63
5.6.1. Introduction	63
5.6.2. A minimal playback application	63
5.6.3. A minimal record application	67
5.7. Revision History	70

5.1. Introduction

The TWL4030 audio module contains audio analog inputs and outputs. It is connected to the main OMAP35x processor through the TDM/I2S interface (audio interface) and used to transmit and receive audio data. The TWL4030 codec is connected via Multi-Channel Buffered Serial Port (McBSP) interface, a communication peripheral, to the main processor.

McBSP provides a full-duplex direct serial interface between the device (OMAP35x processor) and other devices in the system such as the TWL4030 codec. It provides a direct interface to industry standard codecs, analog interface chips (AICs) and other serially connected A/D and D/A devices:

- Inter-IC Sound (I2S) compliant devices
- Pulse Code Modulation (PCM) devices
- Time Division Multiplexed (TDM) bus devices.

The TWL4030 audio module is controlled by internal registers that can be accessed by the high speed I2C control interface.

This user manual defines and describes the usage of user level and platform level interfaces of the ALSA SoC Audio driver.

5.1.1. References

1. ALSA SoC Project Homepage [<http://www.alsa-project.org/main/index.php/ASoC>]
2. ALSA Project Homepage [http://www.alsa-project.org/main/index.php/Main_Page]
3. ALSA User Space Library [<http://www.alsa-project.org/alsa-doc/alsa-lib/>]
4. Using ALSA Audio API [<http://www.equalarea.com/paul/alsa-audio.html/>]
Author: Paul Davis
5. TWL4030 OMAP Power Management and System Companion Device Silicon Revision 2.1. (Author: Texas Instruments)

Literature Number: SWCU026D

5.1.2. Acronyms & Definitions

Acronym	Definition
ALSA	Advanced Linux Sound Architecture

Acronym	Definition
ALSA SoC	ALSA System on Chip
DMA	Direct Memory Access
I2C	Inter-Integrated Circuit
McBSP	Multi-channel Buffered Serial Port
PCM	Pulse Code Modulation
TDM	Time Division Multiplexing
OSS	Open Sound System
I2S	Inter-IC Sound

Table 5.1. Acronyms

5.2. Features

This section describes the supported features and constraints of the ALSA SoC Audio driver.

5.2.1. Features Supported

- Supports TWL4030 audio codec in ALSA SoC framework.
- Supports audio in both mono and stereo modes.
- Multiple sample rate support (8 KHz, 11.025 KHz, 12 KHz, 16 KHz, 22.05 KHz, 24 KHz, 32 KHz, 44.1 KHz and 48 KHz) for both capture and playback.
- Supports simultaneous playback and record (full-duplex mode).
- 16 Bit Little Endian Signed PCM data.
- I2S mode of operation.
- Interleaved access mode.
- Start, stop, pause and resume feature.
- Supports mixer interface for TWL4030 audio codec.
- McBSP is configured as slave and TWL4030 Codec is configured as master.

5.2.2. Constraints

Constraint	Remark
Support for synthesizer and similar interfaces other than ones described in supported features.	Synthesizer and midi interfaces are not supported as many codecs do not support the same. If any codec driver does support it, it would be a specific functionality of that driver alone.
Formats other than I2S.	Formats such as TDM, Left and Right Justified are currently not supported.
Opening of the same stream (Play/Record) multiple times	The audio driver will support a single input (RECORD) and a single output stream (PLAY). The audio driver will not allow opening the same stream (Play/Record) multiple times concurrently.
Configuration of McBSP as Master.	TWL4030 codec needs to be configured in Master mode only,

Constraint	Remark
Configuration of capture and playback streams in different sampling rates.	and therefore McBSP can only be used as slave along with this codec. TWL4030 codec uses McBSP instance 2 on OMAP3 EVM. This McBSP instance has a limitation that when used in full-duplex mode, both reception and transmission could only use the same clock signal and the same frame synchronization signal. Hence capture and playback streams cannot be configured for two different sampling frequencies.
OSS emulation layer support.	OSS emulation layer is not supported because of which OSS based applications (for e.g. madplay) may not work properly.

Table 5.2. Audio Driver : Constraints

5.3. Architecture

5.3.1. ALSA SoC Layer

The overall project goal of the ALSA System on Chip (ASoC) layer is to provide better ALSA support for embedded system on chip processors and portable audio codecs. Currently there is some support in the kernel for SoC audio, however it has some limitations:

- Currently, codec drivers are often tightly coupled to the underlying SoC cpu. This is not really ideal and leads to code duplication.
- There is no standard method to signal user initiated audio events. e.g. Headphone/Mic insertion, Headphone/Mic detection after an insertion event.
- Current drivers tend to power up the entire codec when playing (or recording) audio. This is fine for a PC, but tends to waste a lot of power on portable devices. There is also no support for saving power via changing codec oversampling rates, bias currents, etc.

5.3.2. Design

The ASoC layer is designed to address these issues and provide the following features:

- Codec independence: Allows reuse of codec drivers on other platforms and machines.
- Easy I2S/PCM audio interface setup between codec and SoC. Each SoC interface and codec registers it's audio interface capabilities with the core and are subsequently matched and configured when the application hw params are known.
- Dynamic Audio Power Management (DAPM): DAPM automatically sets the codec to it's minimum power state at all times. This includes powering up/down internal power blocks depending on the internal codec audio routing and any active streams.
- Pop and click reduction: Pops and clicks can be reduced by powering the codec up/down in the correct sequence (including using digital mute). ASoC signals the codec when to change power states.

To achieve all this, ASoC basically splits an embedded audio system into three components:

- Codec driver: The codec driver is platform independent and contains audio controls, audio interface capabilities, codec dapm definition and codec IO functions.
- Platform driver: The platform driver contains the audio dma engine and audio interface drivers (e.g. I2S, AC97, PCM) for that platform.

- Machine driver: The machine driver handles any machine specific controls and audio events. i.e. turning on an amp at start of playback.

Following architecture diagram shows all the components and the interactions among them:




Figure 5.1. ALSA SoC Architecture

5.4. Driver Configuration

5.4.1. Configuration Steps

To enable audio driver support in the kernel:

1. Open menuconfig options from kernel command prompt.
2. Select Device Drivers as shown here:




Figure 5.2. Configure ALSA Driver: Step 2

3. Select Device Drivers > Sound card support as shown here:

```

----- Device Drivers -----
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < >

^(-)-----
[*] Watchdog Timer Support --->
    Sonics Silicon Backplane --->
        Multifunction device drivers --->
            Multimedia devices --->
                Graphics support --->
<*> Sound card support --->
    [*] HID Devices --->
    [*] USB support --->
    <*> MMC/SD/SDIO card support --->
    < > Sony MemoryStick card support (EXPERIMENTAL) --->
l(+)------

<Select>    < Exit >    < Help >

```

Figure 5.3. Configure ALSA Driver: Step 3

4. Select Device Drivers > Sound card support > Advanced Linux Sound Architecture as shown here:

```

--- Sound card support ---
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < >

--- Sound card support
[*] Advanced Linux Sound Architecture --->
< > Open Sound System (DEPRECATED) --->

<Select>    < Exit >    < Help >

```

Figure 5.4. Configure ALSA Driver: Step 4

5. Select Device Drivers > Advanced Linux Sound Architecture > OSS PCM (digital audio) API and OSS PCM (digital audio) API - Include plugin system (NEW), as shown here:




Figure 5.5. Configure ALSA Driver: Step 5

6. Select Device Drivers > Advanced Linux Sound Architecture > Dynamic device file minor numbers as shown here:




Figure 5.6. Configure ALSA Driver: Step 6

7. Select Device Drivers > Sound > Advanced Linux Sound Architecture > Support old ALSA API as shown here:




Figure 5.7. Configure ALSA Driver: Step 7

8. Select Device Drivers > Sound > Advanced Linux Sound Architecture > ALSA for SoC audio support as shown here:




Figure 5.8. Configure ALSA Driver: Step 8

9. Select Device Drivers > Sound > Advanced Linux Sound Architecture > ALSA for SoC audio support > SoC Audio for the Texas Instruments OMAP chips and SoC Audio support for OMAP3EVM board, as shown here:

```

--- ALSA for SoC audio support ---
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < >

--- ALSA for SoC audio support
[*]> SoC Audio for the Texas Instruments OMAP chips
<*> SoC Audio support for OMAP3EVM board
< > Build all ASoC CODEC drivers (NEW)

<Select>    < Exit >    < Help >

```

Figure 5.9. Configure ALSA Driver: Step 9

10. To enable McBSP hardware, select System Type as shown here:

```

----- Linux Kernel Configuration -----
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < >

  General setup --->
  [*] Enable loadable module support --->
  [*] Enable the block layer --->
  System Type --->
    Bus support --->
    Kernel Features --->
    Boot options --->
    CPU Power Management --->
    Floating point emulation --->
    Userspace binary formats --->
  l(+)-

  <Select>    < Exit >    < Help >

```

Figure 5.10. Configure ALSA Driver: Step 10

11. Select System Type > TI OMAP Implementations as shown here:

```

-- System Type --
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < >

ARM system type (TI OMAP) --->
TI OMAP Implementations --->
  *- OMAP34xx Based System
  *-  OMAP3430 support
  [*] OMAP35x Family
      *** OMAP Board Type ***
      [ ] OMAP3 LDP board
      [ ] OMAP 3430 SDP board
      [*] OMAP 3530 EVM board
      [ ]  OMAP 3530 EVM daughter card board
1(+)-

<Select>    < Exit >    < Help >

```

Figure 5.11. Configure ALSA Driver: Step 11

12. Select System Type > TI OMAP Implementations > McBSP Support, as shown here:

```

----- TI OMAP Implementations -----
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < >
^(-)-----
[ ] GPIO switch support
[*] OMAP multiplexing support
[ ] Multiplexing debug output
[*] Warn about pins the bootloader didn't set up
-[*- McBSP support
[ ] MMU framework support
< > Mailbox framework support
    System timer (Use 32KHz timer) --->
    (128) Kernel internal timer frequency for 32KHz timer
    (1) GPTIMER used for system tick timer
l(+)-----
<Select>    < Exit >    < Help >

```

Figure 5.12. Configure ALSA Driver: Step 12

5.4.2. Installation

5.4.2.1. Driver built statically

If the audio driver is built statically into the kernel, it is activated during boot-up. There is no special procedure to install the driver.

5.5. Software Interfaces

This section provides the details of the Application Interface and the Driver Interface for the ALSA Audio driver.

5.5.1. Application Interface

Application developer uses ALSA-lib, a user space library, rather than the kernel API. The library offers 100% of the functionality of the kernel API, but adds major improvements in usability, making the application code simpler and better looking.

The online-documentation for the same is available at:

<http://www.alsa-project.org/alsa-doc/alsa-lib/>

5.5.1.1. Device Interface

The operational interface in `/dev/` contains three main types of devices: (a) PCM devices for recording or playing digitized sound samples, (b) CTL devices that allow manipulating the internal mixer and routing of the card, and (c) MIDI devices to control the MIDI port of the card, if any.

Name	Description
<code>/dev/snd/controlC0</code>	Control devices (i.e. mixer, etc).
<code>/dev/snd/pcmC0D0c</code>	PCM Card 0 Device 0 Capture device.
<code>/dev/snd/pcmC0D0p</code>	PCM Card 0 Device 0 Playback device..

Table 5.3. Device Interface

5.5.1.2. Proc Interface

The `/proc/asound` kernel interface is a status and configuration interface. A lot of useful information about the sound system can be found in the `/proc/asound` subdirectory.

See the table below for different proc entries in `/proc/asound`:

Name	Description
<code>cards</code>	List of registered cards.
<code>version</code>	Version and date the driver was built on.
<code>devices</code>	List of registered ALSA devices.

Name	Description
pcm	The list of allocated PCM streams.
cardX/ (X = 0-7)	The card specific directory.
cardX/pcm0p	The directory of the given PCM playback stream.
cardX/pcm0c	The directory of the given PCM capture stream.

Table 5.4. Proc Interface

5.5.1.3. Commonly Used APIs

Some of the commonly used APIs to write an ALSA based application are:

Name	Description
snd_pcm_open	Opens a PCM stream.
snd_pcm_close	Closes a previously opened PCM stream.
snd_pcm_hw_params_any	Fill params with a full configuration space for a PCM.
snd_pcm_hw_params_test_<<parameter>>	Test the availability of important parameters like number of channels, sample rate etc.
snd_pcm_hw_params_test_format, snd_pcm_hw_params_test_rate, etc.	
snd_pcm_hw_params_set_<<parameter>>	Set the different configuration parameters.
snd_pcm_hw_params_set_format, snd_pcm_hw_params_set_rate, etc.	
snd_pcm_hw_params	Install one PCM hardware configuration chosen from a configuration space.
snd_pcm_writei	Write interleaved frames to a PCM.
snd_pcm_readi	Read interleaved frames from a PCM.
snd_pcm_prepare	Prepare PCM for use.
snd_pcm_drop	Stop a PCM dropping pending frames.
snd_pcm_drain	Stop a PCM preserving pending frames.

Table 5.5. Commonly Used APIs

5.5.1.4. User Space Interactions

This section depicts the sequence of operations for a simple playback and capture application.




Figure 5.13. OMAP3 ALSA Driver : Half duplex playback




Figure 5.14. OMAP3 ALSA Driver : Half duplex record

5.5.2. Driver Interface

This section describes the various function entry points into the various platform specific drivers of the audio driver.

The platform specific codec drivers are required to implement the mentioned entry points and register with the device driver framework by calling `platform_driver_register` and `platform_device_register` with the appropriate data structures. The framework calls the corresponding `probe` function in which the sound card is registered and new PCM streams are created. The platform specific audio driver is required to register itself with the kernel to let the kernel know about its availability.

5.5.2.1. Description

The platform specific ALSA audio driver is instantiated as a 'platform_driver' and is expected to implement the following function hooks, for the core ALSA layer to probe it and handle correctly:

`codec_clock_on ()`

Initializes the McBSP peripheral and the TWL4030 audio codec.

`codec_clock_off ()`

Used for cleanup.

`codec_configure_dev ()`

Used to configure the TWL4030 codec.

`codec_set_samplerate ()`

Used to set the desired sample rate.

`codec_set_stereomode ()`

Used to set the desired mode: mono or stereo.

Moreover, as mentioned above, while probing, the various PCM related functions which can be performed on the actual underlying codec are also registered via function hooks. They are codec specific functions which will be called from the OMAP audio layer on receiving the specific request from the user space.

Both capture and playback side PCM functions need to be registered. Following is a list of all the functions which could be implemented for a specific codec:

open

Codec initialization. The first function to be called during the initialization of the communication paths and do the initial stuff required for the codec to become operational. Codec is assumed to be operational at the end of this stage.

close

Codec clean up operations are done here. This function is the last to be called and is to be designed to request all the communication paths to shutdown. Codec is no longer operational at the end of this stage.

ioctl

This is used for any special action to pcm ioctls. But usually you can pass a generic ioctl callback, `snd_pcm_lib_ioctl`.

hw_params

This is called when the hardware parameter (`hw_params`) is set up by the application, that is, once when the buffer size, the period size, the format, etc. are defined for the pcm substream. Many hardware setups should be done in this callback, including the allocation of buffers.

hw_free

This is called to release the resources allocated via `hw_params`.

prepare

This callback is called when the PCM is "prepared". You can set the format type, sample rate, etc. here. The difference from `hw_params ()` is that the prepare callback will be called at each time `snd_pcm_prepare ()` is called, i.e. when recovered after under-runs, etc.

trigger

This data transfer hook is called for transmits and receives to send/receive data.

pointer

This data transfer hook is used to query the codec driver as to the location of the transfer of the current buffer.

5.5.2.2. States




Figure 5.15. State Diagram

The diagram above defines the various generic high level states through which the audio driver transitions during its life time. On the driver initialization, the various data structures are initialized, all the devices are registered and basic operations to make the driver ready for operation are done. It is the combination of both codec's driver initialization along with the audio driver's initialization that the audio driver completes entry into the initialized state.

When an application initiates an open, the codec is configured to default settings. Further configurations are done based on specific requests sent to the driver. These would include the volume control settings, the sampling rate information, whether the data is to be read/played to the device etc. On completion of the default configuration of the driver, the driver enters in to ready state where the driver is ready for data transfer.

The application may now initiate data read/write operations based on which DMA is used to transfer the data to or from the codec. The operational stage is thus stated to be reached where transfers are operational. This DMA data transfer operation is done asynchronously. Once the data transfer is completed, the driver goes back into its ready state awaiting more data transfer.

Once the application is completed, it initiates a close, at which, if the driver is in operational mode, current pending transfers are emptied and

it moves to ready stage. The driver then transitions to the initialized state after the codec is shutdown from the ready state.

During operational or ready stage, if a suspend request is received, the driver locks out any further data transfers and enters into suspended state after shutting down the codec. On resumption, the driver moves into ready state after re-initializing the codec, awaiting further data transfers to happen. When the driver is being shutdown, the data structures, if any, are cleaned up and the driver exits.

5.5.2.3. Data Flow

The data transfer flow from the user space to the actual hardware is illustrated below:




Figure 5.16. Data flow path

5.6. Sample Applications

This chapter describes the sample application provided along with the package. The binary and the source for these sample application can be available in the Examples directory of the Release Package folder.

5.6.1. Introduction

Writing an audio application involves the following steps:

- Opening the audio device.
- Set the parameters of the device.
- Receive audio data from the device or deliver audio data to the device.
- Close the device.

These steps are explained in detail in this section.



Note

User space ALSA libraries can be downloaded from this link [<http://www.alsa-project.org/main/index.php/Download>].

User needs to build and install them before he starts using the ALSA based applications.

5.6.2. A minimal playback application

This program opens an audio interface for playback, configures it for stereo, 16 bit, 44.1kHz, interleaved conventional read/write access. Then it delivers a chunk of random data to it, and exits. It represents about the simplest possible use of the ALSA Audio API, and isn't meant to be a real program.

5.6.2.1. Opening the audio device

To write a simple PCM application for ALSA, we first need a handle for the PCM device. Then we have to specify the direction of the PCM stream, which can be either playback or capture. We also have to provide some information about the configuration we would like to use, like buffer size, sample rate, pcm data format. So, first we declare:

```
#include <stdio.h>
#include <stdlib.h>
#include <alsa/asoundlib.h>

#define BUFF_SIZE 4096
```

```
int main (int argc, char *argv[])
{
    int err;
    short buf[BUFF_SIZE];
    int rate = 44100; /* Sample rate */
    unsigned int exact_rate; /* Sample rate returned by */

    /* Handle for the PCM device */
    snd_pcm_t *playback_handle;

    /* Playback stream */
    snd_pcm_stream_t stream = SND_PCM_STREAM_PLAYBACK;

    /* This structure contains information about
    /* the hardware and can be used to specify the
    /* configuration to be used for the PCM stream. */
    snd_pcm_hw_params_t *hw_params;
```

The most important ALSA interfaces to the PCM devices are the "plughw" and the "hw" interface. If you use the "plughw" interface, you need not care much about the sound hardware. If your soundcard does not support the sample rate or sample format you specify, your data will be automatically converted. This also applies to the access type and the number of channels. With the "hw" interface, you have to check whether your hardware supports the configuration you would like to use. Otherwise, user can use the default interface for playback by:

```
/* Name of the PCM device, like plughw:0,0 */
/* The first number is the number of the soundcard, */
/* the second number is the number of the device. */

static char *device = "default"; /* playback device */
```

Now we can open the PCM device:

```
/* Open PCM. The last parameter of this function is the mode. */
if ((err = snd_pcm_open (&playback_handle,
                        device, stream, 0)) < 0) {
    fprintf (stderr, "cannot open audio device (%s)\n",
            snd_strerror (err));
    exit (1);
}
```

5.6.2.2. Setting the parameters of the device

Now we initialize the variables and allocate the hwparams structure:

```
/* Allocate the snd_pcm_hw_params_t structure on the stack. */
if ((err = snd_pcm_hw_params_malloc (&hw_params)) < 0) {
    fprintf (stderr, "cannot allocate hardware parameters (%s)\n",
```

```
    snd_strerror (err));  
    exit (1);  
}
```

Before we can write PCM data to the soundcard, we have to specify access type, sample format, sample rate, number of channels, number of periods and period size. First, we initialize the `hwparams` structure with the full configuration space of the soundcard:

```
/* Init hwparams with full configuration space */  
if ((err = snd_pcm_hw_params_any (playback_handle,  
                                  hw_params)) < 0) {  
    fprintf (stderr, "cannot initialize hardware  
                  parameter structure (%s)\n",  
            snd_strerror (err));  
    exit (1);  
}
```

Now configure the desired parameters. For this example, we assume that the soundcard can be configured for stereo playback of 16 Bit Little Endian data, sampled at 44100 Hz. Therefore, we restrict the configuration space to match this configuration only.

The access type specifies the way in which multi-channel data is stored in the buffer. For INTERLEAVED access, each frame in the buffer contains the consecutive sample data for the channels. For 16 Bit stereo data, this means that the buffer contains alternating words of sample data for the left and right channel.

```
/* Set access type. */  
if ((err = snd_pcm_hw_params_set_access (playback_handle,  
                                          hw_params, SND_PCM_ACCESS_RW_INTERLEAVED)) < 0) {  
    fprintf (stderr, "cannot set access type (%s)\n",  
            snd_strerror (err));  
    exit (1);  
}  
  
/* Set sample format */  
if ((err = snd_pcm_hw_params_set_format (playback_handle,  
                                          hw_params, SND_PCM_FORMAT_S16_LE)) < 0) {  
    fprintf (stderr, "cannot set sample format (%s)\n",  
            snd_strerror (err));  
    exit (1);  
}  
  
/* Set sample rate. If the exact rate is not supported */  
/* by the hardware, use nearest possible rate.          */  
exact_rate = rate;  
  
if ((err = snd_pcm_hw_params_set_rate_near (playback_handle,  
                                             hw_params, &exact_rate, 0)) < 0) {  
    fprintf (stderr, "cannot set sample rate (%s)\n",  
            snd_strerror (err));  
}
```

```

    exit (1);
}

if (rate != exact_rate) {
    fprintf(stderr, "The rate %d Hz is not supported by
                    your hardware.\n ==> Using %d
                    Hz instead.\n", rate, exact_rate);
}

/* Set number of channels */
if ((err = snd_pcm_hw_params_set_channels (playback_handle,
                                           hw_params, 2)) < 0) {
    fprintf (stderr, "cannot set channel count (%s)\n",
            snd_strerror (err));
    exit (1);
}

```

Now we apply the configuration to the PCM device pointed to by `pcm_handle` and prepare the PCM device.

```

/* Apply HW parameter settings to PCM device and prepare
 * device.
 */
if ((err = snd_pcm_hw_params (playback_handle,
                              hw_params)) < 0) {
    fprintf (stderr, "cannot set parameters (%s)\n",
            snd_strerror (err));
    exit (1);
}

snd_pcm_hw_params_free (hw_params);

if ((err = snd_pcm_prepare (playback_handle)) < 0) {
    fprintf (stderr, "cannot prepare audio
                    interface for use (%s)\n", snd_strerror (err));
    exit (1);
}

```

5.6.2.3. Writing data to the device

After the PCM device is configured, we can start writing PCM data to it. The first write access will start the PCM playback. For interleaved write access, we use the function:

```

/* Write some junk data to produce sound. */
if ((err =
    snd_pcm_wrotei (playback_handle, buf, BUFF_SIZE/2))
    != BUFF_SIZE/2) {
    fprintf (stderr, "write to audio interface failed (%s)\n",
            snd_strerror (err));
    exit (1);
} else {
    fprintf (stdout, "snd_pcm_wrotei successful\n");
}

```



```
}
```

After the PCM playback is started, we have to make sure that our application sends enough data to the soundcard buffer. Otherwise, a buffer under-run will occur. After such an under-run has occurred, `snd_pcm_prepare` should be called.

5.6.2.4. Closing the device

After the data has been transferred, the device needs to be closed by calling:

```
snd_pcm_close (playback_handle);  
exit (0);  
}
```

5.6.3. A minimal record application

This program opens an audio interface for capture, configures it for stereo, 16 bit, 44.1kHz, interleaved conventional read/write access. Then it reads a chunk of random data from it, and exits. It isn't meant to be a real program.

Note that it is not possible to use one pcm handle for both playback and capture. So you have to configure two handles if you want to access the PCM device in both directions.

```
#include <stdio.h>  
#include <stdlib.h>  
#include <alsa/asoundlib.h>  
  
#define BUFF_SIZE 4096  
  
int main (int argc, char *argv[])  
{  
    int err;  
    short buf[BUFF_SIZE];  
    int rate = 44100; /* Sample rate */  
    int exact_rate;   /* Sample rate returned by */  
  
    snd_pcm_t *capture_handle;  
  
    /* This structure contains information about      */  
    /* the hardware and can be used to specify the   */  
    /* configuration to be used for the PCM stream. */  
    snd_pcm_hw_params_t *hw_params;  
  
    /* Name of the PCM device, like hw:0,0 */  
    /* The first number is the number of the soundcard, */  
    /* the second number is the number of the device. */  
    static char *device = "default"; /* capture device */
```

```
/* Open PCM. The last parameter of this function is
 * the mode.
 */
if ((err = snd_pcm_open (&capture_handle, device,
                        SND_PCM_STREAM_CAPTURE, 0)) < 0) {
    fprintf (stderr, "cannot open audio device (%s)\n",
            snd_strerror (err));
    exit (1);
}

memset(buf,0,BUFF_SIZE);

/* Allocate the snd_pcm_hw_params_t structure on the stack. */
if ((err = snd_pcm_hw_params_malloc (&hw_params)) < 0) {
    fprintf (stderr, "cannot allocate hardware
                    parameter structure (%s)\n",
            snd_strerror (err));
    exit (1);
}

/* Init hwparams with full configuration space */
if ((err = snd_pcm_hw_params_any (capture_handle,
                                hw_params)) < 0) {
    fprintf (stderr, "cannot initialize hardware
                    parameter structure (%s)\n",
            snd_strerror (err));
    exit (1);
}

/* Set access type. */
if ((err = snd_pcm_hw_params_set_access (capture_handle,
                                        hw_params,
                                        SND_PCM_ACCESS_RW_INTERLEAVED)) < 0) {
    fprintf (stderr, "cannot set access type (%s)\n",
            snd_strerror (err));
    exit (1);
}

/* Set sample format */
if ((err = snd_pcm_hw_params_set_format (capture_handle,
                                        hw_params,
                                        SND_PCM_FORMAT_S16_LE)) < 0) {
    fprintf (stderr, "cannot set sample format (%s)\n",
            snd_strerror (err));
    exit (1);
}

/* Set sample rate. If the exact rate is not supported */
/* by the hardware, use nearest possible rate. */
exact_rate = rate;

if ((err = snd_pcm_hw_params_set_rate_near (capture_handle,
                                            hw_params, &exact_rate, 0)) < 0) {
    fprintf (stderr, "cannot set sample rate (%s)\n",
            snd_strerror (err));
    exit (1);
}
```

```
if (rate != exact_rate) {
    fprintf(stderr, "The rate %d Hz is not supported "
                  "by your hardware.\n ==> Using %d "
                  "Hz instead.\n", rate, exact_rate);
}

/* Set number of channels */
if ((err = snd_pcm_hw_params_set_channels(capture_handle,
                                          hw_params, 2)) < 0) {
    fprintf (stderr, "cannot set channel count (%s)\n",
            snd_strerror (err));
    exit (1);
}

/* Apply HW parameter settings to PCM device and
 * prepare device.
 */
if ((err = snd_pcm_hw_params (capture_handle,
                              hw_params)) < 0) {
    fprintf (stderr, "cannot set parameters (%s)\n",
            snd_strerror (err));
    exit (1);
}

snd_pcm_hw_params_free (hw_params);

if ((err = snd_pcm_prepare (capture_handle)) < 0) {
    fprintf (stderr, "cannot prepare audio interface for use
(%s)\n",
            snd_strerror (err));
    exit (1);
}

/* Read data into the buffer. */
if ((err = snd_pcm_readi (capture_handle, buf, 128)) != 128) {
    fprintf (stderr, "read from audio interface failed (%s)\n",
            snd_strerror (err));
    exit (1);
} else {
    fprintf (stdout, "snd_pcm_readi successful\n");
}

snd_pcm_close (capture_handle);
exit (0);
}
```

5.7. Revision History

0.95	Original version
0.97	Added proc and device related information and reorganized the content.
0.97p1	Added constraint that configuration of capture and playback streams in different sampling rates is not possible because of McBSP instance 2 limitation.
02.00.00	Moved to kernel version 2.6.26 and alsa core version 1.0.16.
02.01.00	Moved to ALSA SoC layer v1.0.18a and kernel version 2.6.29.
02.01.01	Moved to ALSA SoC layer v1.0.19.

Display Driver

Abstract

Table of Contents

6.1. Introduction	73
6.1.1. References	73
6.1.2. Acronyms & Definitions	73
6.1.3. Hardware Overview	73
6.2. Features	74
6.2.1. Overview	74
6.2.2. Usage	74
6.3. Architecture	101
6.3.1. Driver Architecture	101
6.3.2. Software Design Interfaces	101

6.4. Software Interfaces	103
6.4.1. 'fbdev' Driver Interface	103
6.4.2. V4L2 Driver Interface	104
6.4.3. SYSFS Software Design Interfaces	106
6.5. Driver Configuration	107
6.5.1. Configuration Steps	107
6.5.2. Installation	113
6.6. Sample Application Flow	115
6.7. Revision History	117

6.1. Introduction

This chapter describes the driver overview along with the supported features and constraints

6.1.1. References

1. Video for Linux Two Home Page [<http://linux.bytesex.org/v4l2/>]
2. Video for Linux Two API Specification [<http://v4l2spec.bytesex.org/v4l2spec/v4l2.pdf>]

6.1.2. Acronyms & Definitions

Acronym	Definition
V4L2	Video for Linux Two
DSS	Display SubSystem
NTSC	National Television System Committee
PAL	Phase Alternating Line
LCD	Liquid Crystal Display

Table 6.1. Acronyms

6.1.3. Hardware Overview

The display subsystem provides the logic to display a video frame from the memory frame buffer (either SDRAM or SRAM) on a liquid-crystal display (LCD) panel or a TV set. The display subsystem integrates the following elements

- Display controller (DISPC) module
- Remote frame buffer interface (RFBI) module
- Serial display interface (SDI) complex input/output (I/O) module with the associated phased-locked loop (PLL)
- Display serial interface (DSI) complex I/O module and a DSI protocol engine
- DSI PLL controller that drives a DSI PLL and high-speed (HS) divider
- NTSC/PAL video encoder

6.2. Features

6.2.1. Overview

The OMAP35x Display driver supports the following features:

- Supports LCD display interface at VGA resolution (480*640)
- Supports TV display interface at NTSC/PAL resolutions on Video Pipelines (both S-Video out and composite out is supported)
- Supports DVI digital interface at 720P and 480P resolution.
- Supports Graphics pipeline and two video pipelines. Graphics pipeline is supported through fbdev and video pipelines through V4L2
- Supported color formats: On OSD (Graphics pipeline): RGB565, RGB888, ARGB and RGBA. On Video pipelines: YUV422 interleaved, RGB565, RGB888.
- Configuration of parameters such as height and width of display screen, bits-per-pixel etc.
- Supports setting up of OSD and Video pipeline destinations (TV or LCD). Through syfs for OSD and compile time option for video pipelines
- Supports buffer management through memory mapped and user pointer buffer exchange for application usage (mmaped)
- Supports rotation - 0, 90, 180 and 270 degrees on LCD and TV output
- Supports destination and source colorkeying on Video pipelines through V4L2
- Supports alpha blending through ARGB pixel format on Video2 pipeline and RGBA and ARGB format on graphics pipeline and global alpha blending

6.2.2. Usage

Usage of each feature supported by driver is explained below.

6.2.2.1. Opening and Closing of Driver

The device can be opened using open call from the application, with the device name and mode of operation as parameters. Application can open the driver only in blocking mode. Non-blocking mode of open is not supported.

V4L2 Driver

The driver will expose two software channels (/dev/v4l/video1 and /dev/v4l/video2), one for each video pipeline. Both of these channels supports only blocking mode of operations. These channels can only be opened once.

```
/* call to open a video Display logical channel
in blocking mode */
video2fd_blocking = open ("/dev/v4l/video1", O_RDWR);
/* closing of channels */
close (video2fd_blocking);
```

FBDEV Driver

The driver will expose one software channels (/dev/fb0) for the graphics pipeline. The driver cannot be opened multiple times. Driver can be opened once only.

```
/* call to open a graphics Display logical channel
in blocking mode */
fb0fd_blocking = open ("/dev/fb0", O_RDWR);
/* closing of channels */
close (fb0fd_blocking);
```

6.2.2.2. Command Line arguments

V4L2 Driver

V4L2 driver supports command line argument for specifying default number of buffers and buffer size for both the video pipelines. These arguments are video1_numbuffers, video2_numbuffers, video1_bufsize and video2_bufsize. Once number of buffers specified at the time of insertion, these many buffers are always available until driver is removed from the kernel.

V4L2 driver uses the VRFB buffers for rotation. Because of the limitation of the VRFB engine these buffers are quite big in size. Size of the VRFB buffers is listed in buffer managment section. VRFB buffers are allocated by driver during vidioc_reqbufs ioctl if the rotation is enabled and freed during vidioc_streamoff. But under heavy system load memory fragmentation may occur and VFRB buffer allocation may fail. To address this issue V4L2 driver provides command line argument to allocate the VRFB buffers at driver init time and buffers will be freed when driver is unloaded. Command line argument is vid1_static_vrfb_alloc and vid2_static_vrfb_alloc for video1 and video2 nodes respectively.

For dynamic build of the driver, these argument are specified at the time of inserting the driver. For static build of the driver, these argument can

be specified along with boot time arguments. Following example shows how to specify command line argument for static and dynamic build.

Insert the dynamically built module with following parameters

```
# insmod omap_vout.ko video1_numbuffers=3 video2_numbuffers=3
video1_bufsize=644000 video2_bufsize=644000
vid1_static_vrfb_alloc=y vid2_static_vrfb_alloc=y
```

Set the bootargs for statically compiled driver on bootloader:

```
OMAP3EVM# setenv bootargs console=ttyS0,115200n8 mem=128M
root=/dev/nfs nointrd nfsroot=172.24.190.19:nfs-
server/home,nolock,rsize=4096,wsiz=4096 ip=dhcp
omap_vout.video1_numbuffers=3 omap_vout.video2_numbuffers=3
omap_vout.video1_bufsize=64400 omap_vout.video2_bufsize=64400
omap_vout.vid1_static_vrfb_alloc=y
omap_vout.vid2_static_vrfb_alloc=y mpurate=600
```



Note

The entire command should be entered in a single line.

FBDEV Driver

FBDEV driver supports command line argument for enabling/setting rotation angle, rotation type and size of vram. These command line arguments can only be used with boot time arguments as FBDEV driver only supports static build. Following example shows how to specify 90 degree rotation in boot time argument.

Set the bootargs for enabling rotation:

```
setenv bootargs console=ttyS0,115200n8 mem=128M nointrd
root=/dev/nfs nfsroot=172.24.133.229:/home/user/remote/
_install,nolock,rsize=4096,wsiz=4096 ip=dhcp omapfb.rotate=1
omapfb.rotate_type=1 mpurate=600
```

Following example shows how to specify size of framebuffer in boot time argument.

Set the bootargs for specifying size of framebuffer:

```
setenv bootargs console=ttyS0,115200n8 mem=128M nointrd
root=/dev/nfs nfsroot=172.24.133.229:/home/user/remote/
_install,nolock,rsize=4096,wsiz=4096 ip=dhcp vram=20M
omapfb.vram=20M mpurate=600
```



Note

The entire command should be entered in a single line.

6.2.2.3. Buffer Management

Driver	Without Rotation	With Rotation
FBDEV Driver	A single buffer of size 1280*720*4*2 bytes	A single buffer of size 2048*720*4 bytes
V4L2 Driver	Single buffer takes 1280*720*4 bytes. Number of buffers can be configured using VIDIOC_REQBUFS ioctl and command line argument.	Same requirement as without rotation. Additionally allocates one buffer of size 1695744 bytes for each context. Number of context are same as the number of buffers allocated using REQBUFS not more than four.

Table 6.2. Memory requirement for V4L2 and FBDEV driver Buffers

V4L2 Driver

Memory Mapped buffer mode and User pointer buffer mode are the two memory allocation modes supported by driver.

In Memory map buffer mode, application can request memory from the driver by calling VIDIOC_REQBUFS ioctl. In this mode, maximum number of buffers is limited to VIDEO_MAX_FRAME (defined in driver header files) and is limited by the available memory in the kernel. If driver is not able to allocate the requested number of buffer, it will return the number of buffer it is able to allocate. The main steps that the application must perform for buffer allocation are:

1) Allocating Memory

This ioctl is used to allocate memory for frame buffers. This is a necessary ioctl for streaming IO. It has to be called for both drivers buffer mode and user buffer mode. Using this ioctl, driver will identify whether driver buffer mode or user buffer mode will be used.

Ioctl: VIDIOC_REQBUFS

It takes a pointer to instance of the `v4l2_requestbuffers` structure as an argument.

User can specify the buffer type (`V4L2_BUF_TYPE_VIDEO_OUTPUT`), number of buffers, and memory type (`V4L2_MEMORY_MMAP`, `V4L2_MEMORY_USERPTR`) at the time of buffer allocation. In case of driver buffer mode, this ioctl also returns the actual number of buffers allocated in count member of `v4l2_requestbuffer` structure

It can be called with zero number of buffers to free up all the buffers already allocated. It also frees allocated buffers when application changes buffer exchange mechanism. Driver always allocates buffers of maximum image size supported. If application wants to change

buffer size, it can be done through video1_buffsize and video2_buffsize command line arguments

When rotation is enabled, driver also allocates buffer for the VRFB virtual memory space along with the mmap or user buffer. It allocates same number of buffers as the mmap or user buffers. Maximum number of buffers, which can be allocated, is 4 when rotation is enabled.

```
/* structure to store buffer request parameters */
struct v4l2_requestbuffers reqbuf;
reqbuf.count = numbuffers;
reqbuf.type = V4L2_BUF_TYPE_VIDEO_OUTPUT;
reqbuf.memory = V4L2_MEMORY_MMAP;
ret = ioctl(fd , VIDIOC_REQBUFS, &reqbuf);
if(ret < 0) {
    printf("cannot allocate memory\n");
    close(fd);
    return -1;
}
```

2) Getting physical address

This ioctl is used to query buffer information like buffer size and buffer physical address. This physical address is used in m-mapping the buffers. This ioctl is necessary for driver buffer mode as it provides the physical address of buffers, which are used to mmap system call the buffers.

Ioctl: VIDIOC_QUERYBUF

It takes a pointer to instance of v4l2_buffer structure as an argument. User has to specify the buffer type (V4L2_BUF_TYPE_VIDEO_OUTPUT), buffer index, and memory type (V4L2_MEMORY_MMAP) at the time of querying.

```
/* allocate buffer by VIDIOC_REQBUFS */

/* structure to query the physical address
of allocated buffer */
struct v4l2_buffer buffer;
/* buffer index for quering -0 */
buffer.index = 0;
buffer.type = V4L2_BUF_TYPE_VIDEO_OUTPUT;
buffer.memory = V4L2_MEMORY_MMAP;

if (ioctl(fd, VIDIOC_QUERYBUF, &buffer) < 0) {
    printf("buffer query error.\n");
    close(fd);
    exit(-1);
}
/*The buffer.m.offset will contain the physical
address returned from driver*/
```

3) Mapping Kernel space address to user space

Mapping the kernel buffer to the user space can be done via mmap. User can pass buffer size and physical address of buffer for getting the user space address

```
/* allocate buffer by VIDIOC_REQBUFS */
/* query the buffer using VIDIOC_QUERYBUF */
/* addr hold the user space address */
unsigned int addr;
Addr = mmap(NULL, buffer.size, PROT_READ | PROT_WRITE, MAP_SHARED,
            fd, buffer.m.offset);
/* buffer.m.offset is same as returned from VIDIOC_QUERYBUF */
```

FBDEV Driver

FBDEV driver supports only memory mapped buffers. If rotation is not enabled at the time of insertion of the driver, it allocates one physically contiguous buffers, which can support 640X480 resolution for all buffer formats supported. If rotation is enabled, driver allocates single buffer of maximum resolution for the VRFB memory space. Following steps are required to map buffers in application memory space

1) Getting fix screen information

FBIOGET_FSCREENINFO ioctl is used to get the not-changing screen information like physical address of the buffer, size of the buffer, line length.

```
/* Getting fix screen information */
struct fb_fix_screeninfo fix;
ret = ioctl(display_fd, FBIOGET_FSCREENINFO, &fix);
if(ret < 0) {
    printf("Cannot get fix screen information\n");
    exit(0);
}
printf("Line length = %d\n", fix.line_length);
printf("Physical Address = %x\n", fix.smem_start);
printf("Buffer Length = %d\n", fix.smem_len);
```

2) Getting Variable screen information

FBIOGET_VSCREENINFO ioctl is used to get the variable screen information like resolution, bits per pixel etc.

```
/* Getting fix screen information */
struct fb_var_screeninfo var;
ret = ioctl(display_fd, FBIOGET_VSCREENINFO, &var);
if(ret < 0) {
    printf("Cannot get variable screen information\n");
    exit(0);
}
printf("Resolution = %dx%d\n", var.xres, var.yres);
printf("bites per pixel = %d\n", var.bpp);
```

3) Mapping Kernel space address to user space

Mapping the kernel buffer to the user space can be done via mmap system call.

```
/* addr hold the user space address */
unsigned int addr, buffersize;
/* Get the fix screen info */
/* Get the variable screen information */
buffersize = fix.line_length * var.yres;
addr = mmap(NULL, buffersize, PROT_READ | PROT_WRITE, MAP_SHARED,
            fd, 0);
/* buffer.m.offset is same as returned from VIDIOC_QUERYBUF */
```

6.2.2.4. Rotation

Rotation is implemented with use of Rotation Engine module in Virtual Rotation Frame Buffer module in OMAP35X. Rotation engine supports rotation of an image with degree 0, 90, 180 and 270. There are 12 contexts available for rotating an image and there are four virtual memory space associated with each context. To rotate an image, image is written to 0 degree virtual memory for a context and rotated image can read back from the virtual memory for that angle of the same context.

For using Rotation Engine, User has to allocate physical memory and provide address of the memory to the rotation engine. The buffer size for this physical buffer should be large enough to store the image to be rotated. When program writes to the virtual address of the context, rotation engine write to this memory space and when program reads image from virtual address, rotation engine reads image from this buffer with rotation angle.

V4L2 Driver

V4L2 driver supports rotation by using rotation engine in the VRFB module. Driver allocates physical buffers, required for the rotation engine, when application calls VIDIOC_REQBUFS ioctl. Therefore, when this ioctl is called driver allocates buffers for storing image and allocates buffers for the rotation engine. It also programs VRFB rotation engine when this ioctl is called. At the time of enqueueing memory mapped buffer, driver copies entire image from mmaped buffer to buffer for the rotation engine using DMA. DSS is programmed to take image from VRFB memory space when rotation is enabled. So DSS always gets rotated image. Maximum four buffers can be allocated using REQBUFS ioctl when rotation is enabled.

Driver provides ioctl interface for enabling/disabling and changing the rotation angle. These ioctls are VIDIOC_S_CTRL/VIDIOC_G_CTRL as drive allocates buffer for VRFB during REQBUFS ioctl, application has to enable/set the rotation angle before calling REQBUFS ioctl. After enabling rotation, application can change the rotation angle. Rotation

angle cannot be changed while streaming is on. Following code shows how to set rotation angle to 90 degree.



Important

Rotation value must be set using `VIDIOC_S_CTRL` before setting any format using `VIDIOC_S_FMT` as `VIDIOC_S_FMT` uses rotation value for calculating buffer formats. Also `VIDIOC_S_FMT` `ioctl` must be called after changing the rotation angle to change parameters as per the new rotation angle

```
struct v4l2_control control;
int degree = 90;

control.id = V4L2_CID_ROTATION;
control.value = degree;
ret = ioctl(fd, VIDIOC_S_CTRL, &control);
if (ret < 0) {
    perror("VIDIOC_S_CTRL\n");
    close(fd);
    exit(0);
}
/* Rotation angle is now set to 90 degree. Application can now do
streaming to see rotated image*/
```

FBDEV Driver

FBDEV driver supports rotation by using rotation engine in the VRFB module. For using this feature of the driver, rotation has to be enabled. Application can enable rotation by enabling/setting rotation angle in boot time argument of the kernel for FBDEV driver. One of the fields in the `fb_var_screeninfo` structure has been used for 'rotate' field. Applications can thus use the `FBIOPUT_VSCREENINFO` `ioctl` to set the rotation angle. Applications have to set this 'rotate' field in the `fb_var_screeninfo` structure equal to the angle of rotation (0, 90, 180 or 270) and call this `ioctl`. Frame buffer driver also supports the rotation through `sysfs` entry. Any one of the two method can be used to configure rotation.

Constraint: While doing rotation x-resolution virtual should be equal to x-resolution. y-resolution virtual should be greater than or equal to y-resolution. Please note that VRFB rotation engine requires alignment of 32 bytes in horizontal size and 32 lines in vertical size. So while doing rotation x-resolution should be 32 byte aligned and y resolution and y resolution virtual should be 32 lines aligned. For example for 360X360 required resolution with 16bpp no of bytes per line comes to $360 \times 2 = 720$. Which is not 32 byte aligned. While no of lines comes to 360 which is also not 32 lines aligned. So actual resolution should be set to 368X368. But if same resolution is required for 32bpp then no of bytes per line comes to 360×4 that is 1440. Which is 32 byte aligned so actual resolution should be set to 360X368. Also the maximum y-res virtual possible is 2048 because of VRFB limitation when rotation enabled.



Important

FBDEV driver internally reverses/manages the xres and yres for the 90 and 270 degree rotation, so user must give original values for rotation.

var.rotate variable should not be modified when rotation is not selected through command line arguments else behaviour is unexpected.



Important

By default frame buffer driver allocates the buffer for single 720P frame considering 0 degree rotation.

This allocation can be overridden using the command line arguments "vram=" and omapfb.vram="

Memory requirement can be calculated by following equation

$(2048 * yres_virtual * max_Bpp) * NO_OF_BUFFERS$, 2048 is the default pitch required by VRFB, yres_virtual = maximum virtual y-resolution required, max_Bpp = maximum bytes per pixel required, NO_OF_BUFFERS = Number of buffers required for panning.

So for 720*1280 resolution with 32bpp with two buffers with 90 or 270 degree rotation it comes to $(2048 * 1280 * 4) * 2 = 20971520$ bytes which rounds upto 20M bytes. so above command line arguments will look like

"vram=20M omapfb.vram=20M"

So it is not desirable to have panning for 720P resolution. For 480P it comes to $(2048 * 720 * 4) * 2$ which is equal to 11796480 bytes with rounding up it is 12M bytes.

Rotation is supported for 16bpp, 24 unpacked bpp and 32 bpp.

Rotation can be enabled by using "omapfb.rotate=1" and "omapfb.rotate_type=1" boot time argument given to the boot loader. Following gives an example of enabling rotation by setting rotation angle of 90 degree. Value of omapfb.rotate can be 0, 1, 2 or 3 where 0 = 0 degree, 1 = 90 degree, 2 = 180 degree and 3 = 270 degree.

```
OMAP3EVM# setenv bootargs 'console=ttyS0,115200n8 mem=128M
noinitrd root=/dev/nfs nfsroot=172.24.133.229:/home/
filesystem,nolock,rsize=4096,wsz=4096 ip=dhcp omapfb.rotate=1
omapfb.rotate_type=1 vram=20M omapfb.vram=20M mpurate=600'
```



Note

This whole command should be written in single line

Following code listings demos how to set the rotation in frame buffer driver using ioctl and sysfs entry.

```
struct fb_var_screeninfo var;
/* Set the rotation through ioctl. */
/* Get the Variable screen info through "FBIOGET_VSCREENINFO" */
var.rotate = 1; /* To set rotation angle to 90 degree */
if (ioctl(fb, FBIOPUT_VSCREENINFO, &var)<0) {
    perror("Error:FBIOPUT_VSCREENINFO\n");
    exit(4);
}
```

Setting the rotation through sysfs where 0 - 0 degree, 1 - 90 degree, 2 - 180 degree and 3 - 270 degree respectively

```
echo 1 > /sys/class/graphics/fb0/rotate
```

6.2.2.5. Color Keying

There are two types of transparent color keys: Video source transparency and graphics destination transparency key. The encoded pixel color value is compared to the transparency color key. For CLUT bitmaps, the palette index is compared to the transparency color key and not to the palette value pointed out by the palette index.




Figure 6.1. Video source color Keying




Figure 6.2. Video destination color Keying

Constraint: The video source transparency color key and graphics destination transparency color key cannot be active at the same time. Color keys are only available in V4L2 Driver.

Video source transparency color key value allows defining a color that the matching pixels with that color in the video pipelines are replaced by the pixels in graphics pipeline. It is limited to RGB formats only and non-scaling cases.

The Graphics destination color key allows defining a color that the nonmatching pixels in the graphics pipelines prevent video overlay. The destination transparency color key is applicable only in the graphics region when graphics and video overlap. Otherwise, the destination transparency color key is ignored.

One of the colors keys can be activated at a time. This implies both key cannot be used simultaneously. All color key related IOCTLs are not pipeline oriented. An application can configure keys through either of two device nodes. Following example shows how to enable source color key.

```
struct v4l2_framebuffer framebuffer;

ret = ioctl (fd, VIDIOC_G_FBUF, &framebuffer);
```

```

if (ret < 0) {
    perror ("VIDIOC_G_FBUF");
    exit(1);
}
/* Set SRC_COLOR_KEYING if device supports that */
if(framebuffer.capability & V4L2_FBUF_CAP_SRC_CHROMAKEY) {

    framebuffer.flags |= V4L2_FBUF_FLAG_SRC_CHROMAKEY;
    ret = ioctl (fd, VIDIOC_S_FBUF, &framebuffer);
    if (ret < 0) {
        perror ("VIDIOC_S_FBUF");
        exit(1);
    }
}

```

Below example shows how to disable source color keying

```

struct v4l2_framebuffer framebuffer;
ret = ioctl (fd, VIDIOC_G_FBUF, &framebuffer);
if (ret < 0) {
    perror ("VIDIOC_G_FBUF");
    exit(1);
}
if(framebuffer.capability & V4L2_FBUF_CAP_SRC_CHROMAKEY) {

    framebuffer.flags &= ~V4L2_FBUF_FLAG_SRC_CHROMAKEY;

    ret = ioctl (fd, VIDIOC_S_FBUF, &framebuffer);
    if (ret < 0) {
        perror ("VIDIOC_S_FBUF");
        exit(1);
    }
}

```

Below example show how to enable destination color keying

```

struct v4l2_framebuffer framebuffer;

ret = ioctl (fd, VIDIOC_G_FBUF, &framebuffer);
if (ret < 0) {
    perror ("VIDIOC_G_FBUF");
    exit(1);
}
/* Set SRC_COLOR_KEYING if device supports that */
if(framebuffer.capability & V4L2_FBUF_CAP_CHROMAKEY) {

    framebuffer.flags |= V4L2_FBUF_FLAG_CHROMAKEY;
    ret = ioctl (fd, VIDIOC_S_FBUF, &framebuffer);
    if (ret < 0) {
        perror ("VIDIOC_S_FBUF");
        exit(1);
    }
}

```

Below example shows how to disable destination color keying

```
struct v4l2_framebuffer framebuffer;
ret = ioctl (fd, VIDIOC_G_FBUF, &framebuffer);
if (ret < 0) {
    perror ("VIDIOC_G_FBUF");
    exit(1);
}
if(framebuffer.capability & V4L2_FBUF_CAP_CHROMAKEY) {

    framebuffer.flags &= ~V4L2_FBUF_FLAG_CHROMAKEY;

    ret = ioctl (fd, VIDIOC_S_FBUF, &framebuffer);
    if (ret < 0) {
        perror ("VIDIOC_S_FBUF");
        exit(1);
    }
}
```

Below program listing shows how to set the chromakey value. Please note that chroma key value should be set before enabling the chroma keying. Overlay manager should not be changed between the setting up of chroma key and enabling the chroma keying.

```
struct v4l2_format fmt;
u8 chromakey = 0xF800; /* Red color RGB565 format */
fmt.type = V4L2_BUF_TYPE_VIDEO_OVERLAY;

ret = ioctl(fd, VIDIOC_G_FMT, &fmt);
if (ret < 0) {
    perror("VIDIOC_G_FMT\n");
    close(fd);
    exit(0);
}
fmt.fmt.win.chromakey = chromakey;

ret = ioctl(fd, VIDIOC_S_FMT, &fmt);
if (ret < 0) {
    perror("VIDIOC_G_FMT\n");
    close(fd);
    exit(0);
}
```

Below example shows how to get the chromakey value.

```
struct v4l2_format fmt;
fmt.type = V4L2_BUF_TYPE_VIDEO_OVERLAY;

ret = ioctl(fd, VIDIOC_G_FMT, &fmt);
if (ret < 0) {
    perror("VIDIOC_G_FMT\n");
    close(fd);
    exit(0);
}
printf("Global alpha value read is %d\n", fmt.fmt.win.chromakey);
```

6.2.2.6. Alpha Blending

Alpha blending is a process of blending a foreground color with a background color and producing a new blended color. New blended color depends on the transparency factor referred to as alpha factor of the foreground color. If the alpha factor is 100% then blended image will have only foreground color. If the alpha factor is 0% blended image will have only back ground color. Any value between 0 to 100% will blend the foreground and background color to produce new blended color depending upon the alpha factor.




Figure 6.3. Alpha blending with almost 50% transparency




Figure 6.4. Alpha blending with almost 100% transparency




Figure 6.5. Alpha blending with almost 0% transparency

Overlay manager of DSS is capable of supporting the alpha blending. This is done by displaying more than one layer (video and graphics) to the same output device TV or LCD. Overlay manager supports normal mode and alpha mode of operation. In normal mode graphics plane is at bottom on top of it is video1 and video2 is on top of video1. While in

alpha mode video1 plane is at bottom, video2 is on top of video1, and graphics plane is above video2. Alpha mode is selectable on any of the output device TV or LCD.

Video2 and graphics layer of the DSS is capable of supporting alpha blending. Two types of alpha blending is supported global and pixel alpha blending. ARGB and RGBA formats of the video2 and graphics pipeline supports pixel based alpha blending. In which A represent the alpha value for each pixel. Thus, each pixel can have different alpha value. While global alpha is the constant alpha factor for the pipeline for all the pixels. Both can be used in conjunction.

Both V4L2 and Frame buffer driver supports alpha blending based on pixel format for video2 and graphics pipeline respectively. Global alpha blending is also supported through V4L2 and Fbdev ioctls. Before using any of the alpha blending methods alpha blending needs to be enabled on the selected output device through V4L2 ioctl. Alpha blending will be enabled on the output device to which video pipeline is connected

Following program listing will enable alpha blending. Its a V4L2 driver ioctl.

```
struct v4l2_framebuffer framebuffer;

ret = ioctl (fd, VIDIOC_G_FBUF, &framebuffer);
if (ret < 0) {
    perror ("VIDIOC_S_FBUF");
    return 0;
}

framebuffer.flags |= V4L2_FBUF_FLAG_LOCAL_ALPHA;
ret = ioctl (fd, VIDIOC_S_FBUF, &framebuffer);
if (ret < 0) {
    perror ("VIDIOC_S_FBUF");
    return 0;
}
```

Following program listing will disable alpha blending Its a V4L2 driver ioctl.

```
struct v4l2_framebuffer framebuffer;

ret = ioctl (fd, VIDIOC_G_FBUF, &framebuffer);
if (ret < 0) {
    perror ("VIDIOC_S_FBUF");
    return 0;
}

framebuffer.flags &= ~V4L2_FBUF_FLAG_LOCAL_ALPHA;
ret = ioctl (fd, VIDIOC_S_FBUF, &framebuffer);
if (ret < 0) {
    perror ("VIDIOC_S_FBUF");
    return 0;
}
```



```
}
```

V4L2 Driver

V4L2 driver supports alpha blending through ARGB pixel format as well as global alpha value.

To set the pixel alpha value set ARGB format by setting format type to V4L2_PIX_FMT_RGB32. Call VIDIOC_S_FMTioctl of the driver to set it to ARGB format. Note: RGBA format is not supported.

```
struct v4l2_format fmt;
/* Set the video type*/
fmt.type = V4L2_BUF_TYPE_VIDEO_OUTPUT;
/* Set the width and height of the picture*/
fmt.fmt.pix.width = 400;
fmt.fmt.pix.height = 400;
/* Set the format to ARGB */
fmt.fmt.pix.pixelformat = V4L2_PIX_FMT_RGB32;
/* Call set format Ioctl */
ret = ioctl(fd, VIDIOC_S_FMT, &fmt);
if (ret < 0) {
    perror("VIDIOC_S_FMT\n");
    close(fd);
    exit(0);
}
```

Setting the global alpha value is supported through V4L2_BUF_TYPE_VIDEO_OVERLAY format type. Below programlisting shows how to set the global alpha value for video2 pipeline.

```
struct v4l2_format fmt;
u8 global_alpha = 128;
fmt.type = V4L2_BUF_TYPE_VIDEO_OVERLAY;

ret = ioctl(fd, VIDIOC_G_FMT, &fmt);
if (ret < 0) {
    perror("VIDIOC_G_FMT\n");
    close(fd);
    exit(0);
}
fmt.fmt.win.global_alpha = global_alpha;

ret = ioctl(fd, VIDIOC_S_FMT, &fmt);
if (ret < 0) {
    perror("VIDIOC_G_FMT\n");
    close(fd);
    exit(0);
}
```

FBDEV Driver

Frame buffer driver supports setting of pixel alpha value as well as global alpha value

Pixel alpha value is supported through 32 bpp. Setting the offsets correctly will set the pixel format as ARGB or RGBA. Below program listing shows how to set ARGB pixel format.

```
fb_var_screeninfo var;
/* Get variable screen information. Variable screen information
 * gives information like size of the image, bites per pixel,
 * virtual size of the image etc. */
ret = ioctl(display_fd, FBIOGET_VSCREENINFO, &var);
if (ret < 0) {
    perror("Error reading variable information.\n");
    exit(3);
}
/* Set bits per pixel and offsets*/
var.red.length= 8;
var.green.length = 8;
var.blue.length = 8;
var.transp.length= 8;
var.transp.offset = 24;
var.red.offset = 16;
var.green.offset =8;
var.blue.offset = 0;
var.bits_per_pixel = 32;
if (ioctl(display_fd, FBIOPUT_VSCREENINFO, &var)<0) {
    perror("Error:FBIOPUT_VSCREENINFO\n");
    exit(4);
}
```

Below programlisting shows how to set the global alpha value for graphics pipeline

```
struct fb_var_screeninfo var;
int global_alpha = 128;

if (ioctl(fb, FBIOGET_VSCREENINFO, &var)) {
    perror("Error reading variable information.\n");
    exit(3);
}
var.reserved[0] = global_alpha;
if (ioctl(fb, FBIOPUT_VSCREENINFO, &var)) {
    perror("Error writing variable information.\n");
    exit(3);
}
```



Note

Before using the global alpha or pixel based alpha on graphics pipeline. Alpha blending needs to be enabled using V4L2 ioctl described under V4L2 driver in this section.

6.2.2.7. Buffer Format

Buffer format describes the pixel format in the image. It also describes the memory organization of each color component within the pixel format. In all buffer formats, blue value is always stored in least significant bits, then green value and then red value.

V4L2 Driver

Video layer supports following buffer format: YUYV, UYVY, RGB565, RGB24 (packed and unpacked). The corresponding v4l2 defines for pixel format are V4L2_PIX_FMT_YUYV, V4L2_PIX_FMT_UYVY, V4L2_PIX_FMT_RGB565, V4L2_PIX_FMT_RGB24 (packed), V4L2_PIX_FMT_RGB32. (For video1 and video2 V4L2_PIX_FMT_RGB32 corresponds to RGB24 unpacked).

Buffer format can be changed using VIDIOC_S_FMT ioctl with type as V4L2_BUF_TYPE_VIDEO_OUTPUT and appropriate pixel format type. Following example shows how to change pixel format to RGB565

```
struct v4l2_format fmt;
fmt.type = V4L2_BUF_TYPE_VIDEO_OUTPUT;
fmt.fmt.pix.pixelformat = V4L2_PIX_FMT_RGB565;
ret = ioctl(fd, VIDIOC_S_FMT, &fmt);
if (ret < 0) {
    perror("VIDIOC_S_FMT\n");
    close(fd);
    exit(0);
}
```

FBDEV Driver

Graphics layer supports following buffer format: RGB24(un-packed) and RGB565. Buffer format can be changed in FBDEV driver by using bpp, red, green, and blue fields of fb_varscreeninfo structure and ioctl FBIOPUT_VSCREENINFO. Application needs to specify bits per pixel and length and offset of red, green and blue component. Bits-per-pixel and color depth in the pixel aren't quite the same thing. The display controller supports color depths of 1, 2, 4, 8, 12, 16, 24 and 32 bits. Color depth and bits-per-pixel are the same for depths of 1, 2, 4, 8, and 16 bits, but for a color depth of 12 bits the pixel data is padded to 16 bits-per-pixel, and for a color depth of 24 bits the pixel data is padded to 32 bits-per-pixel. So application has to specify bits per pixel 16 and 32 for the color depth 12 and 24. To specify exact color depth, red, green and blue member of the fb_varscreeninfo can be used. Following example shows how to set 12 and 24 bits per pixels.

```
Struct fb_varscreeninfo var;
var.bpp = 16;
var.red.length = var.green.length = var.blue.length = 4;
var.red.offset = 8;
```

```
var.green.offset = 4;
var.blue.offset = 0;
ret = ioctl(fd, FBIOPUT_VSCREENINFO, &var);
if (ret < 0) {
    perror("FBIOPUT_VSCREENINFO\n");
    close(fd);
    exit(0);
}
```

Buffer Formats

Byte 3 Byte 2 Byte 1 Byte 0

P31 P24	P23 P16	P15 P8	P7 P0
-----------	-----------	----------	---------

Figure 6.6. 1-BPP Data Memory Organization

Byte 3 Byte 2 Byte 1 Byte 0

P15 P12	P11 P8	P7 P4	P3 P0
-----------	----------	---------	---------

Figure 6.7. 2-BPP Data Memory Organization

Byte 3 Byte 2 Byte 1 Byte 0

P7 P6	P5 P4	P3 P2	P1 P0
---------	---------	---------	---------

Figure 6.8. 4-BPP Data Memory Organization

Byte 3 Byte 2 Byte 1 Byte 0

P3	P2	P1	P0
----	----	----	----

Figure 6.9. 8-BPP Data Memory Organization

Byte 3		Byte 2		Byte 1		Byte 0	
Unused	R1	G1	B1	Unused	R1	G1	B1

Figure 6.10. 12-BPP Data Memory Organization

Byte 3			Byte 2			Byte 1			Byte 0		
R1			G1			B1			R0		
									G0		
											B0

Figure 6.11. 16-BPP Data Memory Organization

Byte 3		Byte 2		Byte 1		Byte 0	
Unused			R		G		B

Figure 6.12. 24-BPP Data Memory Organization

Byte 3		Byte 2		Byte 1		Byte 0	
	A		R		G		B

Figure 6.13. ARGB 32-BPP Data Memory Organization

Byte 3		Byte 2		Byte 1		Byte 0	
	R		G		B		A

Figure 6.14. RGBA 32-BPP Data Memory Organization

	Byte 3	Byte 2	Byte 1	Byte 0
W0	B1	R0	G0	B0
W1	G2	B2	R1	G1
W2	R3	G3	B3	R2

Figure 6.15. 24-BPP Packed Data Memory Organization

Byte 3	Byte 2	Byte 1	Byte 0
Cr0	Y1	Cb0	Y0

Figure 6.16. UYVY 4:2:2 Data Memory Organization

Byte 3	Byte 2	Byte 1	Byte 0
Y1	Cr0	Y0	Cb0

Figure 6.17. YUV2 4:2:2 Data Memory Organization

6.2.2.8. Display Window

The video pipelines can be connected to either an DVI output LCD output or a TV output through compile time option. Although the display Driver computes a default display window whenever the image size or cropping is changed, an application should position the display window via the VIDIOC_S_FMT I/O control with the V4L2_BUF_TYPE_VIDEO_OVERLAY buffer type. When a switch from LCD to TV or from TV to LCD happens, an application is expected to adjust the display window. V4L2 driver only supports change of display window.

Following example shows how to change display window size.

```
struct v4l2_format fmt;
Fmt.type = V4L2_BUF_TYPE_VIDEO_OVERLAY;
fmt.fmt.win.w.left = 0;
fmt.fmt.win.w.top = 0;
fmt.fmt.win.w.width = 200;
fmt.fmt.win.w.height = 200;
```

```
ret = ioctl(fd, VIDIOC_S_FMT, &fmt);
if (ret < 0) {
    perror("VIDIOC_S_FMT\n");
    close(fd);
    exit(0);
}
/* Display window size and position is changed now */
```

6.2.2.9. Cropping

The V4L2 Driver allows an application to define a rectangular portion of the image to be rendered via the `VIDIOC_S_CROP` ioctl with the `V4L2_BUF_TYPE_VIDEO_OUTPUT` buffer type. When application calls `VIDIOC_S_FMT` ioctl, driver sets default cropping rectangle that is the largest rectangle no larger than the image size and display windows size. The default cropping rectangle is centered in the image. All cropping dimensions are rounded down to even numbers. Changing the size of the cropping rectangle will in general also result in a new default display window. As stated above, an application must adjust the display window accordingly.

Following example shows how to change crop size.

```
struct v4l2_crop crop;
crop.type = V4L2_BUF_TYPE_VIDEO_OUTPUT;
crop.c.left = 0;
crop.c.top = 0;
crop.c.width = 320;
crop.c.height = 320;
ret = ioctl(fd, VIDIOC_S_CROP, &crop);
if (ret < 0) {
    perror("VIDIOC_S_CROP\n");
    close(fd);
    exit(0);
}
/* Image cropping rectangle is now changed */
```

6.2.2.10. Scaling

Video pipe line contains scaling unit which is used when transferring pixels from the system memory to the LCD panel or the TV set. The scaling unit consists of two scaling blocks: The vertical scaling block followed by the horizontal scaling block. The two scaling units are independent: Neither of them, only one, or both can be used simultaneously.

As scaling unit is on video pipeline, scaling is only supported in V4L2 driver. Scaling is not explicitly exposed at the API level. Instead, the horizontal and vertical scaling factors are based on the display window and the image cropping rectangle. The horizontal scaling factor is computed by dividing the width of the display window by the width of the

cropping rectangle. Similarly, the vertical scaling factor is computed by dividing the height of the display window by the height of the cropping rectangle.

Down-scaling is limited upto factor 0.5 and the up-scaling factor to 8 in the software, while hardware supports from 0.25x to 8x both horizontally and vertically . The display Driver makes sure the limits are never exceeded.

Below example shows how to scale image by factor of 2.

```
struct v4l2_format fmt;
struct v4l2_crop crop;
/* Changing display window size to 200x200 */
fmt.type = V4L2_BUF_TYPE_VIDEO_OVERLAY;
fmt.fmt.win.w.left = 0;
fmt.fmt.win.w.top = 0;
fmt.fmt.win.w.width = 200;
fmt.fmt.win.w.height = 200;
ret = ioctl(fd, VIDIOC_S_FMT, &fmt);
if (ret < 0) {
    perror("VIDIOC_S_FMT\n");
    close(fd);
    exit(0);
}
/* Changing crop window size to 400x400 */
crop.type = V4L2_BUF_TYPE_VIDEO_OUTPUT;
crop.c.left = 0;
crop.c.top = 0;
crop.c.width = 400;
crop.c.height = 400;
ret = ioctl(fd, VIDIOC_S_CROP, &crop);
if (ret < 0) {
    perror("VIDIOC_S_CROP\n");
    close(fd);
    exit(0);
}
/* Image should be now scaled by factor 2 */
```

6.2.2.11. Color look table

The graphics pipeline supports the color look up table. The CLUT mode uses the encoded pixel values from the input image as pointers to index the 24-bit-wide CLUT value: 1-BPP pixels address 2 entries, 2-BPP pixels address 4 entries, 4-BPP pixels address 16 entries, and 8-BPP pixels address 256 entries.

Driver supports 1, 2, 4 and 8 bits per pixel image format using color lookup table. FBIOPUTCMAP and FBIOGETCMAP can be used to set and get the color map table. When CLUT is set, the driver makes the hardware to reload the CLUT.

Following example shows how to change CLUT.


```
struct fb_cmap cmap;
unsigned short r[4]={0xFF,0x00, 0x00, 0xFF};
unsigned short g[4]={0x00, 0xFF, 0x00, 0xFF};
unsigned short b[4]={0x00, 0x00, 0xFF, 0x00};
cmap.len = 4;
cmap.red = r;
cmap.green = g;
cmap.blue = b;
if (ioctl(fd, FBIOPUTCMAP, &cmap)) {
    perror("FBIOPUTCMAP\n");
    exit(3);
}
```

6.2.2.12. Streaming

V4L2 driver supports the streaming of the buffer. To do streaming minimum of three buffers should be requested by the application by using VIDIOC_REQBUFS ioctl. Once driver allocates the requested buffers application should call VIDIOC_QUERYBUF and mmap to get the physical address of the buffers and map the kernel memory to user space as explained earlier. Following are the steps to enable streaming.

1. Fill the buffers with the image to be displayed in the proper format.
2. Queue buffers to the driver queue using VIDIOC_QBUF ioctl.
3. Start streaming using VIDIOC_STREAMON ioctl.
4. Call VIDIOC_DQBUF to get the displayed buffer.
5. Repeat steps 1,2,4 and 5 in a loop for the frame count to be displayed.
6. Call VIDIOC_STREAMOFF ioctl to stop streaming.

Following example shows how to do streaming with V4L2 driver.

```
/* Initially fill the buffer */
struct v4l2_requestbuffers req;
struct v4l2_buffer buf;
struct v4l2_format fmt;
/* Fill the buffers with the image */

/* Enqueue buffers */
for (i = 0; i < req.count; i++) {
    buf.type = V4L2_BUF_TYPE_VIDEO_OUTPUT;
    buf.index = i;
    buf.memory = V4L2_MEMORY_MMAP;
    ret = ioctl(fd, VIDIOC_QBUF, &buf);
    if (ret < 0) {
        perror("VIDIOC_QBUF\n");
        for (j = 0; j < req.count; j++){
            /* Unmap all the buffers if call fails */
            exit(0);
        }
    }
}
```

```

    }
    printf("VIDIOC_QBUF = %d\n",i);
}
}
/* Start streaming */
a = 0;
ret = ioctl(fd, VIDIOC_STREAMON, &a);
if (ret < 0) {
    perror("VIDIOC_STREAMON\n");
    for (i = 0; i < req.count; i++)
        /* Unmap all the buffers if call fails */
    exit(0);
}
/* loop for streaming with 500 Frames*/
for(i = 0 ;i < LOOPCOUNT ;i ++) {
    ret = ioctl(fd, VIDIOC_DQBUF, &buf);
    if(ret < 0){
        perror("VIDIOC_DQBUF\n");
        for (j = 0; j < req.count; j++){
            /* Unmap all the buffers if call fails */
        exit(0);
        }
    }
    /* Fill the buffer with new data
    fill(buff_info[buf.index].start, fmt.fmt.pix.width,
    fmt.fmt.pix.height,0);
    /Queue the buffer again */
    ret = ioctl(fd, VIDIOC_QBUF, &buf);
    if(ret < 0){
        perror("VIDIOC_QBUF\n");
        for (j = 0; j < req.count; j++){
            /* Unmap all the buffers if call fails */
        exit(0);
        }
    }
}

/* Streaming off */
ret = ioctl(fd, VIDIOC_STREAMOFF, &a);
if (ret < 0) {
    perror("VIDIOC_STREAMOFF\n");
    for (i = 0; i < req.count; i++){
        /* Unmap all the buffers if call fails */
    exit(0);
    }
}
}

```

6.3. Architecture

This chapter describes the Driver Architecture and Design concepts

6.3.1. Driver Architecture

OMAP35x display hardware integrates one graphics pipeline, two video pipelines, and two overlay managers (one for digital and one for analog interface). Digital interface is used for LCD and DVI output and analog interface is used for TV out.

The primary functionality of the display driver is to provide interfaces to user level applications and management to OMAP35x display hardware. This includes, but is not limited to:

- GUI rendering through the graphics pipeline.
- Static image or video rendering through two video pipelines.
- Connecting each of three pipelines to either LCD or TV output so the display layer is presented on the selected output path.
- Image processing (cropping, rotation, mirroring, color conversion, resizing, and etc).




Figure 6.18. OMAP35x Display Subsystem Architecture

6.3.2. Software Design Interfaces

Above figure shows the major components that makes up the DSS software sub-system

Display Library

This is a HAL/functional layer controlling the bulk of DSS hardware. It exposes the number of APIs controlling the overlay managers, clock, and pipelines to the user interface drivers like V4L2 and FBDEV.

It also exposes the functions for registering and de-registering of the various display devices like LCD and DVI to the DSS overlay managers.

SYSFS interfaces

The SYSFS interfaces are mostly used as the control path for configuring the DSS parameters which are common between FBDEV and V4L2 like the panel size, pixel clock frequency, alpha blending etc.

It is also used for switching the output of the pipeline to either LCD or Digital overlay manager. In future sysfs entries might also be used to switch the modes like NTSC, PAL on TV and 480P, 720P on DVI outputs.



Note

Please note that due to clock source limitation while switching the output DSS2 throws error message "Could not find exact pixel clock" (In order to fix this we need to use DSI input clock source).

Frame Buffer Driver

This driver is registered with the FBDEV subsystem, and is responsible for managing the graphics layer frame buffer. Driver creates `/dev/fb0` as the device node. Application can open this device node to open the driver and negotiate parameters with the driver through frame buffer ioctls. Application maps driver allocated buffers in the application memory space and fills them for the driver to display.

Video Applications & V4L2 subsystem

Video applications (camera, camcorder, image viewer, etc.) use the standard V4L2 APIs to render static images and video to the video layers, or capture/preview camera images.

This driver is responsible for managing the video layers' frame buffers. It is a V4L2 compliant driver with some additions to implement special software requirements that target OMAP35x hardware features. This driver conforms to the Linux driver model. For using the driver, application should create the device nodes `/dev/v4l/video1` and `/dev/v4l/video2` device nodes for two video layers. Application can open the driver by opening these device nodes and negotiate the parameters by V4L2 ioctls. Initially application can request the driver to allocate number of buffers and MMAPs these buffers. Then the application can fill up these buffers and pass them to driver for display by using the standard V4L2 streaming ioctls.

6.4. Software Interfaces

6.4.1. 'fbdev' Driver Interface

6.4.1.1. Application Interface

`open ()`

To open a framebuffer device

`close ()`

To close a framebuffer device

`ioctl ()`

To send ioctl commands to the framebuffer driver.

`mmap ()`

To obtain the framebuffer region as mmap'ed area in user space.

6.4.1.2. Supported Standard IOCTLs

FBIOGET_VSCREENINFO, FBIOPUT_VSCREENINFO

These I/O controls are used to query and set the so-called variable screen info. This allows an application to query or change the display mode, including the color depth, resolution, timing etc. These I/O controls accept a pointer to a struct `fb_var_screeninfo` structure. The video mode data supplied in the `fb_var_screeninfo` struct is translated to values loaded into the display controller registers.

FBIOGET_FSCREENINFO

This I/O control can be used by applications to get the fixed properties of the display, e.g. the start address of the framebuffer memory. This I/O control accepts a pointer to a struct `fb_fix_screeninfo`

FBIOGETCMAP, FBIOPUTCMAP

These I/O controls are used to get and set the color-map for the framebuffer. These I/O controls accept a pointer to a struct `fb_cmap` structure.

FBIO_BLANK

This I/O control is used to blank or unblank the framebuffer console.

6.4.1.3. Data Structures

`fb_var_screeninfo`

This structure is used to query and set the so-called variable screen information. This allows an application to query or change the display mode, including the color depth, resolution, timing etc.

`fb_fix_screeninfo`

This structure is used by applications to get the fixed properties of the display, e.g. the start address of the framebuffer memory, framebuffer length etc.

`fb_cmap`

This structure is used to get/set the color-map for the framebuffer

6.4.2. V4L2 Driver Interface

6.4.2.1. Application Interface

`open`

To open a video device

`close`

To close a video device

`ioctl`

To send ioctl commands to the display driver.

`mmap`

To memory map a driver allocated buffer to user space

6.4.2.2. Supported Standard IOCTLs



Note

This section describes the standard V4L2 IOCTLs supported by the Display Driver. Standard IOCTLs that are not listed here are not supported. The Display Driver handles the unsupported ones by returning `EINVAL` error code.

VIDIOC_QUERYCAP

This is used to query the driver's capability. The video driver fills a `v4l2_capability` struct indicating the driver is capable of output and streaming.

VIDIOC_ENUM_FMT

This is used to enumerate the image formats that are supported by the driver. The driver fills a `v4l2_fmtdesc` struct.

VIDIOC_G_FMT

This is used to get the current image format or display window depending on the buffer type. The driver fills the information to a `v4l2_format` struct.

VIDIOC_TRY_FMT

This is used to validate a new image format or a new display window depending on the buffer type. The driver may change the passed values if they are not supported. Application should check what is granted.

VIDIOC_S_FMT

This is used to set a new image format or a new display window depending on the buffer type. The driver may change the passed values if they are not supported. Application should check what is granted if `VIDIOC_TRY_FMT` is not used first.

VIDIOC_CROPCAP

This is used to get the default cropping rectangle based on the current image size and the current display panel size. The driver fills a `v4l2_cropcap` struct.

VIDIOC_G_CROP

This is used to get the current cropping rectangle. The driver fills a `v4l2_crop` struct.

VIDIOC_S_CROP

This is used to set a new cropping rectangle. The driver fills a `v4l2_crop` struct. Application should check what is granted.

VIDIOC_REQBUFS

This is used to request a number of buffers that can later be memory mapped. The driver fills a `v4l2_requestbuffers` struct. Application should check how many buffers are granted.

VIDIOC_QUERYBUF

This is used to get a buffer's information so mmap can be called for that buffer. The driver fills a v4l2_buffer struct.

VIDIOC_QBUF

This is used to queue a buffer by passing a v4l2_buffer struct associated to that buffer.

VIDIOC_DQBUF

This is used to dequeue a buffer by passing a v4l2_buffer struct associated to that buffer.

VIDIOC_STREAMON

This is used to turn on streaming. After that, any VIDIOC_QBUF results in an image being rendered.

VIDIOC_S_CTRL VIDIOC_G_CTRL VIDIOC_QUERYCTRL

These ioctls are used to set/get and query various V4L2 controls like rotation, mirror and background color. Currently only rotation is supported

VIDIOC_STREAMOFF

This is used to turn off streaming.

6.4.3. SYSFS Software Design Interfaces

Currently we are not supporting the sysfs interfaces for functions like changing the output, changing the mode and alpha blending. But bulk of sysfs entries are exported by DSS library. Please refer to the Migration guide for detailed explanation on sysfs entries supported.

**Note**

SYSFS entries are not included as part of official release and are not tested to the extent of productization.

6.5. Driver Configuration

6.5.1. Configuration Steps

To enable V4L2 video driver:

1. Open menuconfig options from kernel command prompt.
2. Select Device Drivers as shown here:




Figure 6.19. Configure V4L2 video Driver: Step 2

3. Select Device Drivers > Multimedia devices as shown here:




Figure 6.20. configure V4L2 video Driver: Step 3

4. Select Video For Linux

```

----- Multimedia devices -----
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < > module

*** Multimedia core support ***
<Y> Video For Linux
[*] Enable Video For Linux API 1 (DEPRECATED) (NEW)
-*~ Enable Video For Linux API 1 compatible Layer
< > DVB for Linux (NEW)
*** Multimedia drivers ***
[ ] Load and attach frontend and tuner driver modules as needed (NEW)
[ ] Customize analog and hybrid tuner modules to build (NEW) --->
[*] Video capture adapters (NEW) --->
[*] Radio Adapters (NEW) --->
[ ] DAB adapters (NEW)

<Select> < Exit > < Help >

```

Figure 6.21. Configure V4L2 video Driver: Step 4

5. Select Device Drivers > Multimedia devices > Video capture adapters as shown here and go inside the main menu:

```

----- Multimedia devices -----
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < > module

*** Multimedia core support ***
<Y> Video For Linux
[*] Enable Video For Linux API 1 (DEPRECATED) (NEW)
-*~ Enable Video For Linux API 1 compatible Layer
< > DVB for Linux (NEW)
*** Multimedia drivers ***
[ ] Load and attach frontend and tuner driver modules as needed (NEW)
[ ] Customize analog and hybrid tuner modules to build (NEW) --->
[*] Video capture adapters (NEW) --->
[*] Radio Adapters (NEW) --->
[ ] DAB adapters (NEW)

<Select> < Exit > < Help >

```

Figure 6.22. Configure V4L2 video Driver: Step 5

6. Select OMAP2/OMAP3 V4L2-DSS Drivers. Select Videoout library Videoout driver support under OMAP2/OMAP3 V4L2-DSS Drivers

```

--- Video capture adapters ---
Arrow keys navigate the menu. <Enter> selects submenus --->. Highlighted
letters are hotkeys. Pressing <Y> includes, <N> excludes, <M> modularizes
features. Press <Esc><Esc> to exit, <?> for Help, </> for Search. Legend: [*]
built-in [ ] excluded <M> module < > module capable

--- Video capture adapters
[ ] Enable advanced debug functionality
[ ] Enable old-style fixed minor ranges for video devices
[*] Autoselect pertinent encoders/decoders and other helper chips
< > Virtual Video Driver
< > CPlA Video For Linux
< > CPlA2 Video For Linux
< > SAA5246A, SAA5281 Teletext processor
< > SAA5249 Teletext processor
[*] OMAP2/OMAP3 V4L2-DSS drivers
<*> OMAP Video out library
<*> OMAP Video out driver
l(+)
```

<Select> < Exit > < Help >

Figure 6.23. Configure V4L2 video Driver: Step 6

To enable Frame buffer driver.

1. Open menuconfig options from kernel command prompt.
2. Select Device Drivers as shown here:

```

--- Linux Kernel Configuration ---
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < > module

General setup --->
[*] Enable loadable module support --->
[*] Enable the block layer --->
System Type --->
Bus support --->
Kernel Features --->
Boot options --->
CPU Frequency scaling --->
Floating point emulation --->
Userspace binary formats --->
Power management options --->
Networking --->
Device Drivers --->
File systems --->
Kernel hacking --->
l(+)
```

<Select> < Exit > < Help >

Figure 6.24. Configure Graphics display Driver: Step 2

3. Select Device Drivers > Graphics Supports as shown here:

```

Device Drivers
Arrow keys navigate the menu. <Enter> selects submenus --->. Highlighted
letters are hotkeys. Pressing <Y> includes, <N> excludes, <M> modularizes
features. Press <Esc><Esc> to exit, <?> for Help, </> for Search. Legend: [*]
built-in [ ] excluded <M> module <> module capable

^(-)
< > Dallas's 1-wire support --->
< > Power supply class support --->
< > Hardware Monitoring support --->
< > Generic Thermal sysfs driver --->
[*] Watchdog Timer Support --->
    Sonics Silicon Backplane --->
    Multifunction device drivers --->
    Multimedia devices --->
    Graphics support --->
    < > Sound card support --->
    [*] HID Devices --->
    [*] USB support --->
l(+)

<Select> < Exit > < Help >

```

Figure 6.25. configure Graphics display Driver: Step 3

4. Select Support for frame buffer devices under Graphics support as shown.

```

Graphics support
Arrow keys navigate the menu. <Enter> selects submenus --->. Highlighted
letters are hotkeys. Pressing <Y> includes, <N> excludes, <M> modularizes
features. Press <Esc><Esc> to exit, <?> for Help, </> for Search. Legend: [*]
built-in [ ] excluded <M> module <> module capable

< > Lowlevel video output switch controls
<Y> Support for frame buffer devices --->
(2) Consistent DMA memory size (MB) (NEW)
< > OMAP2/3 frame buffer support (EXPERIMENTAL) (NEW)
    OMAP2/3 Display Device Drivers --->
    [ ] Backlight & LCD device support --->
        Display device support --->
        Console display driver support --->
    [ ] Bootup logo (NEW) --->

<Select> < Exit > < Help >

```

Figure 6.26. configure Graphics display Driver: Step 4

5. Select OMAP2/3 Frame buffer support (EXPERIMENTAL) and 1 as Number of Frame buffers. Select 1 will allow the Graphics pipeline of the DSS to be controlled by FBDEV interface and both video pipelines by V4L2 interface. Selecting 2 will allow graphic pipeline and 1 video pipeline to be controlled by FBDEV interface and one video pipeline by V4L2 interface. Selecting 3 will allow all the three DSS pipelines to be controlled by FBDEV interface.

```

Graphics support
Arrow keys navigate the menu. <Enter> selects submenus --->. Highlighted
letters are hotkeys. Pressing <Y> includes, <N> excludes, <M> modularizes
features. Press <Esc><Esc> to exit, <?> for Help, </> for Search. Legend: [*]
built-in [ ] excluded <M> module <> module capable

<> Lowlevel video output switch controls
<*> Support for frame buffer devices --->
(2) Consistent DMA memory size (MB) (NEW)
<*> OMAP2/3 frame buffer support (EXPERIMENTAL)
[ ] Debug support for OMAP2/3 FB
[ ] Force main display to automatic update mode (NEW)
(1) Number of framebuffers
    OMAP2/3 Display Device Drivers --->
[ ] Backlight & LCD device support --->
    Display device support --->
        Console display driver support --->
[ ] Bootup logo (NEW) --->

<Select> < Exit > < Help >

```

Figure 6.27. configure Graphics display Driver: Step 5

There are some other configuration parameters which user can select during building of kernel -

- Select the TV as the default output device for Video1 and Video2 pipeline - Select the NTSC_M as the default mode for TV. Without this default mode will be PAL_BDGI.

1. Open menuconfig options from kernel command prompt. Select Device Drivers > Multimedia devices > Video capture adapters as mentioned in section "V4L2 video driver:"
2. Select "Use TV Managaer" under the VID1 Overlay manager for selecting TV as default output for Video1 or under VID2 Overlay manager for selecting the TV as default output for video2.

```

Video capture adapters
Arrow keys navigate the menu. <Enter> selects submenus --->. Highlighted letters are
hotkeys. Pressing <Y> includes, <N> excludes, <M> modularizes features. Press <Esc><Esc>
to exit, <?> for Help, </> for Search. Legend: [*] built-in [ ] excluded <M> module
<> module capable

--- Video capture adapters
[ ] Enable advanced debug functionality
[ ] Enable old-style fixed minor ranges for video devices
[*] Autoselect pertinent encoders/decoders and other helper chips
<> Virtual Video Driver
<> CPlA Video For Linux
<> CPlA2 Video For Linux
<> SAA5246A, SAA5281 Teletext processor
<> SAA5249 Teletext processor
<> OMAP ISP Previewer
<*> OMAP ISP Resizer
<> OMAP 3 Camera support
[*] OMAP2/OMAP3 V4L2-DSS drivers
<*> OMAP Video out library
<*> OMAP Video out driver
VID1 Overlay manager (Use TV Manager) --->
VID2 Overlay manager (Use TV Manager) --->
TV Mode (Use NTSC_M mode) --->
SoC camera support
l(+)

<Select> < Exit > < Help >

```

Figure 6.28. Select TV as default output device: Step 6

To select the NTSC_M as the default mode for TV. Without this default mode will be PAL_BDGI.

1. Open menuconfig options from kernel command prompt. Select Device Drivers > Multimedia devices > Video capture adaptaters as mentioned in section "V4L2 video driver:"
2. Select "Use NTSC_M Mode" as the TV mode from the choice menu.

```

--- Video capture adapters ---
Arrow keys navigate the menu. <Enter> selects submenus ---. Highlighted letters are
hotkeys. Pressing <Y> includes, <N> excludes, <M> modularizes features. Press <Esc><Esc>
to exit, <?> for Help, </> for Search. Legend: [*] built-in [ ] excluded <M> module
< > module capable

--- Video capture adapters
[ ] Enable advanced debug functionality
[ ] Enable old-style fixed minor ranges for video devices
[*] Autoselect pertinent encoders/decoders and other helper chips
< > Virtual Video Driver
< > CPlA Video For Linux
< > CPlA2 Video For Linux
< > SAA5246A, SAA5281 Teletext processor
< > SAA5249 Teletext processor
< > OMAP ISP Previewer
< * > OMAP ISP Resizer
< > OMAP 3 Camera support
[*] OMAP2/OMAP3 V4L2-DSS drivers
< * > OMAP Video out library
< * > OMAP Video out driver
      VID1 Overlay manager (Use TV Manager) --->
      VID2 Overlay manager (Use TV Manager) --->
  TV Mode (Use NTSC M mode) --->
< > SoC camera support
1 (+)

[Select] < Exit > < Help >

```

Figure 6.29. Select NTSC_M as TV mode: Step 6

To select the Composite or S-Video out as the default TV out interface. The default output interface will be S-Video.

Please note that for OMAP3EVM-1 (<Rev-E) user should set SW1.6 to proper position for selection between S-Vid/CVBS.

ON - Enable S-Video output interface path on OMAP3EVM-1 OFF - Enable CVBS output interface path on OMAP3EVM-1

1. Open menuconfig options from kernel command prompt. Select System Type > TI OMAP Implementations > VENC support.
2. Select "OMAP2_VENC_OUT_TYPE (Use Composite output interface)" as the TV out interface from the choice menu.

```

----- TI OMAP Implementations -----
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < >

^(-)
-* OMAP2/3 Display Subsystem support (EXPERIMENTAL)
[ ] Debug support
[ ] RFBI support
[*] VENC support
  OMAP2 VENC OUT TYPE (Use Composite output interface) ---
[ ] SDI support
[*] DSI support
[*] Use DSI PLL for PCLK (EXPERIMENTAL)
[ ] Fake VSYNC irq from manual update displays
(4) Minimum FCK/PCK ratio (for scaling)

<Select>  < Exit >  < Help >

```

Figure 6.30. Select Composite out as TV out interface: Step 6

6.5.2. Installation

6.5.2.1. Driver built statically

If the v4l2 video driver is built statically into the kernel, it is activated during boot-up. If frame buffer driver is built statically it gets activated during bootup. Modular build of frame buffer is not supported.

6.5.2.2. Driver built as loadable module

If the video driver and video library has been configured to be a loadable modules, then the driver are built as a modules with the name omap_vout.ko and omap_voutlib.ko, which will be placed under directory drivers/media/video/omap/ in the kernel tree.

Copy this driver files on to the target board and issue the following command to insert the driver:

```
insmod omap_vout.ko
insmod omap_voutlib.ko
```

There might be some dependencies for this module on other modules, These modules also need to be inserted before inserting V4L2 video driver.

To remove the driver, issue the following command:

```
rmmod omap_vout.ko
```

```
rmmod omap_voutlib.ko
```


6.6. Sample Application Flow

This chapter describes the application flow using the V4L2 and FBDEV drivers.




Figure 6.31. Application for v4l2 driver using MMAP buffers




Figure 6.32. Application for FBDEV driver

6.7. Revision History

02.01.00	Created for the first git release.
----------	------------------------------------

02.01.01	Updated for the second snapshot release.
----------	--

Resizer Driver

Abstract

Table of Contents

7.1. Introduction	121
7.1.1. References	121
7.1.2. Acronyms	121
7.1.3. Hardware Overview	121
7.2. Features	122
7.2.1. Overview of features supported	122
7.2.2. Usage of Features	122
7.2.3. Constraints	128
7.3. Architecture	130
7.4. Software Interface	131

7.4.1. Application Programming Interface	131
7.4.2. IOCTLs	132
7.4.3. Data Structures	136
7.5. Driver Configuration	141
7.5.1. Configuration Steps	141
7.6. Sample Application Flow	144
7.7. Revision History	145

7.1. Introduction

This section provides overview of the Resizer Hardware.

7.1.1. References

- Video for Linux Two API Specification [<http://v4l2spec.bytesex.org/v4l2spec/v4l2.pdf>]

7.1.2. Acronyms

- V4L2: Video For Linux 2

7.1.3. Hardware Overview

The OMAP Resizer module enables up scaling and down scaling. It resizes YUV422 image and stores output image in the RAM. The following figure shows the block diagram for Resizer module.




Figure 7.1. OMAP Resizer HW Block Diagram

The Resizer module performs digital zoom either up sampling or down sampling on image/video data within a range of 0.25x to 4x resizing. The input source can be sent to either the preview engine/CCDC or memory, and the output is sent to memory.

The Resizer module performs horizontal resizing, then vertical resizing, independently. Between them, there is an optional edge-enhancement feature. This process is shown in the above Figure.

7.2. Features

This section describes features supported by the resizer driver.

7.2.1. Overview of features supported

The Resizer driver supports the following features:

- Resizes input frame stored in RAM and stores output frame in RAM.
- Supports resizing from 1/4x to 4x.
- Supports independent horizontal and vertical resizing.
- Supports YUV422 packed data and Color Separate data.
- Supports driver allocated and user provided buffers.
- Supports Luminance Enhancement.
- Supports configuration of read request cycles.

7.2.2. Usage of Features

Following sections provides details about the drive supported features.

7.2.2.1. Opening and Closing the Driver

The device can be opened using open call from the application with device name and mode of operation as parameters. Mode can be blocking, non-blocking and readwrite. Application can open the driver in either blocking mode or non-blocking mode. If driver is opened in blocking mode, RSZ_RESIZE ioctl will block until resizing task is over for that channel. If the driver is opened in non-blocking mode, RSZ_RESIZE ioctl returns if hardware is busy serving other channel.

Driver can be opened multiple times. Driver maintains software channels for all opened instances. If multiple resizing task is submitted at the same time, driver serializes the resizing task.

To close a specific device, application calls the close function with the file handle.

```
/* call to open a Resizer logical channel in blocking mode */
rszfd_blocking = open ("/dev/omap-resizer", O_RDWR);
/* closing of channels */
close (rszfd_blocking);
```


7.2.2.2. Buffer Management

Resizer Driver requires buffers for storing input/output images. Buffers can be allocated by the driver itself or application can provide the buffers. These buffers need to be virtually contiguous. Physically buffers can be scattered in the memory.

The Resizer Driver supports two memory usage models.

- Memory map/Driver allocated buffer mode
- User Pointer Exchange

7.2.2.2.1. Memory map/Driver Allocated buffer

In Memory map buffer mode, application can request memory from the driver by calling `RSZ_REQBUF` ioctl. With this ioctl, application passes pointer to the structure `v4l2_requestbuffers`. In this structure, buffer exchange mechanism can be specified. For memory map buffer exchange mechanism, it should be `V4L2_MEMORY_MMAP`. Driver always allocates buffer of maximum size required to store input or output image. If output image width is less than input image width, a single buffer can be used to store input and output images. Otherwise, at least, two buffers are required to store input and output images. Application can request as many buffers as it wants. Buffer with the index 0 is always used as the input buffer and other buffer can be used as the output buffer.

The main steps that the application must perform for buffer allocation are:

- Allocating Memory
- Getting Physical Address
- Mapping Kernel Space Address to User Space

Allocating Memory:

Application can allocate buffers using `RSZ_REQBUF` IOCTL. While allocating the buffers, the application have to specify the buffer type, number of buffers and memory type. Here the buffer type must be `V4L2_BUF_TYPE_VIDEO_CAPTURE`. Number of buffers can be greater than or equal to one. If output image is less than input image, number of buffers can be one. Drivers always uses maximum of input and output image size as the buffer size.

This ioctl takes object of `v4l2_request` buffer structure.

```
/* structure to store buffer request parameters */
struct v4l2_requestbuffers reqbuf;
reqbuf.type = V4L2_BUF_TYPE_VIDEO_CAPTURE;
reqbuf.count = 2; /* number of buffers */
reqbuf.memory = V4L2_MEMORY_MMAP; /* Type of buffer exchange
mechanism */
```

```
if(ioctl(rszfd, RSZ_REQBUF, &reqbuf) < 0) {
    perror("RSZ_REQBUF failed\n");
    close(rszfd);
    exit(-1);
}
/* The above example will allocate 2 buffers */
```

Getting Physical Address:

The `RSZ_QUERYBUF` IOCTL can obtain the physical address of the allocated buffer. Application has to specify the index, buffer type and buffer's memory type at time of calling this ioctl. Buffer type must be `V4L2_BUF_TYPE_VIDEO_CAPTURE`. Index of each type of buffer starts from 0. Buffer memory type must be `V4L2_MEMORY_MMAP` for driver allocated buffers. The driver fills the size and physical address, and then returns to the application so that the relevant data can be used to mmap the buffer to user space.

This ioctl takes object of the structure `v4l2_buffer`.

```
/* allocate buffer by RSZ_REQBUF */
/* structure to query the physical address of allocated buffer */
struct v4l2_buffer buffer;
buffer.index = 0; /* buffer index - 0 */
buffer.type = V4L2_BUF_TYPE_VIDEO_CAPTURE; /* Input buffer */
if (ioctl(rszfd, RSZ_QUERYBUF, &buffer) < 0) {
    perror("RSZ_QUERYBUF ioctl failed\n");
    close(rszfd);
    exit(-1);
}
/* The buffer.m.offset will contain the physical address returned
from driver */
```

Mapping Kernel Space Address to User Space:

Mapping the kernel buffer to the user space is done via the Linux `mmap` system call. Application must pass the buffer size and buffer's physical address for getting the user mapped address.

```
/* allocate buffer by RSZ_REQBUF */
/* query the buffer using RSZ_REQBUF */
/* addr hold the user space address */
unsigned long addr;
addr = mmap(NULL, buffer.size, PROT_READ | PROT_WRITE,
            MAP_SHARED, rszfd, buffer.offset);
/* buffer.offset is same as returned from RSZ_QUERYBUF */
```

7.2.2.2. User Pointer Exchange

Application informs driver whether to use memory mapped buffer or user buffer in memory allocation operation (`RSZ_REQBUFS` ioctl). This ioctl is

being used when request for buffer allocation is submitted to the driver. Along with `ioctl`, application has to specify either memory mapped or user buffer to be used. If user provided buffer is used, application has to pass memory type as `V4L2_MEMORY_USERPTR`. Then at the time of en-queueing buffers, application can specify pointer to the virtually contiguous buffer allocated by the application and size of the buffer. This size of the buffer, specified at the time of en-queueing buffer, must be page-aligned. This size must be same for the input and output buffer and must be maximum of input and output image size.

```
/* structure to store buffer request parameters */
struct v4l2_requestbuffers reqbuf;
reqbuf.type = V4L2_BUF_TYPE_VIDEO_CAPTURE;
reqbuf.count = 2; /* number of buffers */
reqbuf.memory = V4L2_MEMORY_USERPTR; /* Type of buffer exchange
mechanism */
if(ioctl(rszfd, RSZ_REQBUF, &reqbuf) < 0) {
    perror("RSZ_REQBUF failed\n");
    close(rszfd);
    exit(-1);
}
/* This above example will allocate 2 buffer descriptors */
```

7.2.2.3. Parameter Configuration

7.2.2.3.1. Resizing

The Resizer module takes input image from RAM, resizes it horizontally and vertically using given resizing ratio and stores output image in RAM. The Resizer module can up scale or down scale image data with independent resizing factors in the horizontal and vertical directions. The resizing ratio is calculated using formula $256/N$ where value of N can range from 64 to 1024. The Resizer module uses the same resampling algorithm for the horizontal and vertical directions. The resizing/resampling algorithm uses a programmable polyphase sample rate converter (resampler). The polyphase filter coefficients are programmable so that any user-specified filter can be implemented.

For horizontal and vertical direction, application has to provide 32 coefficients. These coefficient values are dependent on resizing ratio. The Resizer hardware uses 4 taps and 8 phases filters for the resizing range of $1/2x$ to $4x$ and 7 taps and 4 phases filters for a resizing range of $1/4x$ to $1/2x$ for both the direction. So different set of coefficients must be provided for 4 taps and 8 phases filters and 7 taps and 4 phases filter.

As the hardware uses multi tape poly phase filters, filter requires more input pixel than following equation calculates.

```
Input size = output size * N / 256; /* 256 where N is from 64 to
1024 */
```

Input size is also dependent on the starting phase and rounding issues in the resizing algorithm of the hardware. The input width and height parameters must be programmed strictly according to these equations given in following table otherwise, incorrect hardware operation may occur.

	Ratio 1/2x to 4x	Ratio 1/4x to 1/2x
Input width	$(32 * sph + (ow - 1) * hrsz + 16) >> (8 + 7)$	$(64 * sph + (ow - 1) * hrsz + 32) >> (8 + 7)$
Input height	$(32 * spv + (oh - 1) * vrsz + 16) >> (8 + 4)$	$(64 * spv + (oh - 1) * vrsz + 32) >> (8 + 7)$

Table 7.1. Resizer: Input Size Calculation

Where

sph = horizontal starting phase
 spv = vertical starting phase
 ow = output width
 oh = output height
 hrsz = horizontal resize value
 vrsz = vertical resize value.

Application sets the resizing ratio by providing input size and output size parameters in `RSZ_S_PARAMS` ioctl. This ioctl takes object of `rsz_params` structures. Application provides input width, pitch and height and output width, pitch and height. Driver calculates the resizing ratio for horizontal and vertical direction using below equation.

`Horizontal_ratio = (input_width - N) * 256 / (output_width - 1);`

Where N = 7 for ratio in between 1/4x to 1/2x 4 for ratio in between 1/2x to 4x

Similar equation is used to calculate vertical resizing ratio. So this equation must be used by the application when calculating input and output size for the given resizing ratio.

Actual Resizing operation is performed when application calls `RSZ_RESIZE` ioctl. This ioctl programs Resizer Hardware, submits resizing task and waits for it to be completed. This ioctl will block the application if the resizer driver is opened in blocking mode. If it is opened in non-blocking mode, it will simply return with busy if the hardware is busy. Before submitting resizing task, the input and output buffers must be en-queued to the driver so the drive will come to know which buffers to be used as input and output. Also resize ioctl, as an side effect, removed buffers from the queue. So if resizing task required to be re-submitted, buffers must be en-queued again. So whenever resizing task is submitted, input and output buffers must also be enqueued first.

7.2.2.3.2. Chroma Algorithm

Chroma components, which are 2:1 horizontally down sampled with respect to luma, have two methods of horizontal resizing: `Filtering with luma`, and `Bilinear interpolation`. The Chroma algorithm option can be selected in the `cbilin` field of `rsz_params` structure. However, filtering with luma is only intended for down sampling, and bilinear interpolation is only intended for up sampling.

There are two possible values of `cbilin` member of `rsz_params` structures. 0 and 1. 0 indicates that the chrominance uses the same processing as the luminance and 1 indicates that the chrominance uses bilinear interpolation processing.

7.2.2.3.3. Input/output image format

Resizer module supports two types of image format. One is YUV422 packed data and the other is color separate data. Input image format can be selected by providing one of `RSZ_INTYPE_YCBCR422_16BIT` or `RSZ_INTYPE_PLANAR_8BIT` value to `inptype` member of `rsz_params` structure. Configured input image format is used for both input and output image.

When YUV422 interleaved (packed) image format is selected, resizer module resizes entire image and stores it in output buffer.

When color separate image format is selected, application has to resize each of the color components separately. Application must open three instances of the resizer driver and resize each color components in one instance separately. Application must provide correct input and output size of the each color components when resizing color components.

7.2.2.3.4. Pixel Format

Resizer module supports two pixel format YUYV and UYVY. Pixel format can be selected by providing one of `RSZ_PIX_FMT_YUYV` or `RSZ_PIX_FMT_UYVY` value to `pix_fmt` member of `rsz_params` structure. Configured pixel format is used for both input and output image. When color separate input data is used, this field is ignored.

7.2.2.3.5. Luma Enhancement

Edge enhancement can be applied to the horizontally resized luminance component before the output of the horizontal stage is sent to the line memories and the vertical stage. `type` member of `rsz_yenh` member of `rsz_params` structure can be set to disable edge enhancement, or to select a 3-tap or a 5-tap horizontal high-pass filter (HPF) for luminance enhancement. So possible values of `type` is 0, 1 or 2 for disabling luma enhancement, selecting 3 tap filter or selecting 5 tap filter. If edge enhancement is selected, the two left-most and two right-most pixels in each line are not outputted to the line memories and the vertical

stage. When luma enhancement is enabled, maximum output width can be 1280 when 1/2x to 4x vertical resizing ratio is selected and 640 when 1/4x to 1/2x vertical resizing ratio is selected.

Luma enhancement algorithm is as follows.

HPF (Y_IN) = Y_IN convolved with $\{-0.5, 1, 0.5\}$ or $\{-0.25, -0.5, 1.5, -0.5, -0.25\}$

Implemented as $[-1, 2, -1] \gg 1$, $[-1, -2, 6, -2, -1] \gg 2$

Saturate HPF(Y) between -256 and +255

Hpgain = $(|HPF(Y)| - CORE) * SLOP$

Saturate hpgain between 0 and GAIN

$Y_OUT = Y_IN + (HPF(Y_IN) * hpgain + 8) \gg 4$

Saturate Y_OUT between 0 and 255

Application have to provide core, slope and gain members of rsz_yenh member of rsz_params structure.

7.2.2.3.6. Configuring the Read cycle for Resizer module

ISP module supports configuration of number of clock cycles between two consecutive read request from resizer module. Value supported is 0 - 0x3FF.

```
unsigned int read_exp;
read_exp = 0xe;
ret_val = ioctl(fd, RSZ_S_EXP, &read_exp);
if (ret_val){
    printf("\nUnable to set the read cycle expand register\n");
    return ret_val;
}
```

The default configuration of read cycle is 0xE.

7.2.3. Constraints

- For driver allocated buffers, driver allocates maximum size of buffers for both input and output.
- All input/output buffers addresses and pitch must be 32 bytes aligned.
- Output image size cannot be more than 2047x2047.
- Output width must be even.

- Output width must be 16 byte aligned for vertical resizing.
- The horizontal start pixel must be within the range: 0 to 15 for color interleaved, 0 to 31 for color separate data.

7.3. Architecture

Following block diagram shows the basic architecture of the Resizer Driver -




Figure 7.2. Basic Architecture of Resizer Driver

Resizer Driver provides Resizer Hardware access to a channel by using Linux Character driver interface. Driver supports all the features supported by the hardware. It provides easy way of configuring the hardware. To understand this, that the hardware module driver implements, is briefly described in this section.

7.4. Software Interface

This section describes the Data Structures, Enumerations, and API Specifications used in the OMAP Resizer Driver.

7.4.1. Application Programming Interface

7.4.1.1. open

Description

Opens the device driver for processing.

Prototype

```
int fd = open(device_name, mode);
```

Field	Description
device_name	It is /dev/omap-resizer
mode	O_RDWR or O_RDWR with O_NONBLOCK

Table 7.2. Resizer: open System Call arguments

Return Values

Zero on success, or negative if an error has occurred.

7.4.1.2. close

Description

Close the device.

Prototype

```
close(fd);
```

Field	Description
fd	File descriptor returned from open call.

Table 7.3. Resizer: close system call arguments

Return Values

Zero on success.

EINTR, if driver could not get the handle.

7.4.1.3. mmap

Description

Map the kernel space buffer to user space.

Prototype

```
void * mmap(void *, size_t image_size, int prot, int
            flags, int fd, off_t offset)
```

Field	Description
void *	Generally NULL
image_size	Buffer size that needs to be mapped
flag	PROT_SHARED
fd	File descriptor
offset	Physical address of the buffer

Table 7.4. Resizer: mmap system call arguments

Return Values

Zero on success.

EAGAIN, if the address is not found.

7.4.1.4. munmap

Description

Unmap the frame buffers that were previously mapped to user space using `mmap()` system call.

Prototype

```
void *munmap(void *start_addr, size_t length)
```

Field	Description
start_addr	Start address of buffer which is to be unmapped.
length	Length of buffer.

Table 7.5. Resizer: munmap system call arguments

Return Values

Zero on success, or Negative if an error has occurred.

7.4.2. IOCTLs

7.4.2.1. RSZ_S_PARAMS

Description

Set the resizer parameters necessary for processing.

Prototype

```
int ioctl(int fd, RSZ_S_PARAMS, struct rsz_params *argp)
```

Field	Description
fd	File handle associated with fd.
cmd	RSZ_S_PARAMS ioctl command.
argp	Pointer to <code>rsz_params</code> structure.

Table 7.6. Resizer: ioctl RSZ_S_PARAMS arguments

Return Values

Zero on success,

EINVAL, if parameters are incorrect.

EINTR, if device is in use by the same channel handle.

7.4.2.2. RSZ_G_PARAMS

Description

Get the Resizer parameters that are previously being set.

Prototype

```
int ioctl(int fd, RSZ_G_PARAMS, struct rsz_params *argp)
```

Field	Description
fd	File handle associated with fd.
cmd	RSZ_G_PARAMS ioctl command.
argp	Pointer to <code>rsz_params</code> structure.

Table 7.7. Resizer: ioctl RSZ_G_PARAMS arguments

Return Values

Zero on success,

EINVAL, if device is not configured before calling this API.

7.4.2.3. RSZ_G_STATUS

Description

Get the channel status for the particular current Resizer channel.

Prototype

```
int ioctl(int fd, RSZ_G_STATUS, struct rsz_status *argp)
```

Field	Description
fd	File handle associated with fd.
cmd	RSZ_G_STATUS ioctl command.
argp	Pointer to rsz_status structure.

Table 7.8. Resizer: ioctl RSZ_G_STATUS argument

Return Values

Zero on success,

7.4.2.4. RSZ_S_EXP

Description

Configure the Read cycle required for Resizer module. This configuration is provided per channel.

Prototype

```
int ioctl(int fd, RSZ_S_EXP, unsigned int *argp)
```

Field	Description
fd	File handle associated with fd.
cmd	RSZ_S_EXP ioctl command.
argp	Pointer to unsigned int.

Table 7.9. Resizer: ioctl RSZ_S_EXP argument

Return Values

Zero on success,

7.4.2.5. RSZ_RESIZE

Description

Starts the Resizer processing for the parameters previously set by RSZ_S_PARAMS

Prototype

```
int ioctl(int fd, RSZ_RESIZE, int *argp)
```

Field	Description
fd	File handle associated with fd.
cmd	RSZ_RESIZE ioctl command.
argp	Pointer to int.

Table 7.10. Resizer: ioctl RSZ_RESIZE arguments

Return Values

Zero on success,

EINVAL, if parameters are incorrect.

EBUSY/EINTR, if device is in use by the same channel handle.

7.4.2.6. RSZ_REQBUF

Description

Request to allocate buffers

Prototype

```
int ioctl(int fd, RSZ_REQBUF, struct v4l2_requestbuffers *argp)
```

Field	Description
fd	File handle associated with fd.
cmd	RSZ_REQBUF ioctl command.
argp	Pointer to v4l2_requestbuffers structure.

Table 7.11. Resizer: ioctl RSZ_REQBUF arguments

Return Values

Zero on success,

ENOMEM, if memory is not available.

EINTR, if device is in use by the same channel handle.

7.4.2.7. RSZ_QUERYBUF

Description

Request physical address of buffers allocated by the RSZ_REQBUF

Prototype

```
int ioctl(int fd, RSZ_QUERYBUF, struct v4l2_buffer *argp)
```

Field	Description
fd	File handle associated with fd.
cmd	RSZ_QUERYBUF ioctl command.
argp	Pointer to v4l2_buffer structure.

Table 7.12. Resizer: ioctl RSZ_QUERYBUF arguments

Return Values

Zero on success,

EINVAL/EFAULT, if parameters are incorrect.

EINTR, if device is in use by the same channel handle.

7.4.2.8. RSZ_QUEUEBUF

Description

Queue the buffer for resize operation.

Prototype

```
int ioctl(int fd, RSZ_QUEUEBUF, struct v4l2_buffer *argp)
```

Field	Description
fd	File handle associated with fd.
cmd	RSZ_QUEUEBUF ioctl command.
argp	Pointer to v4l2_buffer structure.

Table 7.13. Resizer: ioctl RSZ_QUEUEBUF arguments

Return Values

Zero on success,

EINVAL/EFAULT, if parameters are incorrect.

EINTR, if device is in use by the same channel handle.

7.4.3. Data Structures

7.4.3.1. Resizer Parameters Configuration Structure

```
struct rsz_params {
    __s32 in_hsize;
    __s32 in_vsize;
    __s32 in_pitch;
    __s32 inptyp;
    __s32 vert_starting_pixel;
```

```

        __s32 horz_starting_pixel;
        __s32 cbilin;
        __s32 pix_fmt;
        __s32 out_hsize;
        __s32 out_vsize;
        __s32 out_pitch;
        __s32 hstph;
        __s32 vstph;
        __u16 tap4filt_coeffs[32];
        __u16 tap7filt_coeffs[32];
    struct rsz_yenh yenh_params;
} ;

```

Name	Description
in_hsize	Width of the input image in pixels.
in_vsize	Height of the input image in pixels.
in_pitch	Pitch of input image in bytes.
inptype	Input image format.
vert_starting_pixel	Vertical starting pixel.
horz_starting_pixel	Horizontal starting pixel.
cbilin	Chroma resizing algorithm.
pix_fmt	Image Pixel format for YUV422 image.
out_hsize	Width of the output image in pixels.
out_vsize	Height of the output image in pixels.
out_pitch	Pitch of the output image in bytes.
hstph	Horizontal starting phase.
vstph	Vertical starting phase.
tap4filt_coeffs	Set of coefficients for scaling ratio 0.5x - 4x.
tap7filt_coeffs	Set of coefficients for scaling ratio 0.25x - 0.5x.
yenh_params	Luma Enhancement parameters.

Table 7.14. Resizer: Parameters Configuration Structure fields

7.4.3.2. Request Buffer Structure

```

struct v4l2_requestbuffer {
    unsigned int type;
    unsigned int count;
    enum v4l2_memory memory;
    ...
}

```

Name	Description
type	Buffer type V4L2_BUF_TYPE_VIDEO_CAPTURE.

Name	Description
count	Number of buffers to be allocated.
memory	Type of the buffer exchange mechanism requested.

Table 7.15. Resizer: Request Buffer Structure fields

7.4.3.3. Buffer structure

```
struct v4l2_buffer {
    unsigned int index;
    unsigned int type;
    enum v4l2_memory memory;
    union {
        unsigned long offset;
        unsigned long userptr;
    }m;
}
```

Name	Description
index	Index of the input/output buffer.
type	Type of the buffer is V4L2_BUF_TYPE_VIDEO_CAPTURE.
offset/userptr	Physical/virtual address of the buffer.
memory	Type of memory, V4L2_MEMORY_MMAP or V4L2_MEMORY_USERPTR.

Table 7.16. Resizer: Buffer structure fields

7.4.3.4. Luma enhancement structure

```
struct rsz_yenh {
    __s32 type;
    __u8 gain;
    __u8 char slop;
    __u8 core;
}
```

Name	Description
type	Luma Enhancement algorithm.
gain	Gain.
slop	Slop.
core	Core.

Table 7.17. Resizer: Luma enhancement structure fields

7.4.3.5. Status structure

```
struct rsz_status {
    __s32 chan_busy;
    __s32 hw_busy;
    __s32 src;
}
```

Name	Description
chan_busy	Status of the channel.
hw_busy	Status of the hardware.
src	Input source.

Table 7.18. Resizer: Status structure fields

7.4.3.6. Crop Size structure

```
struct rsz_cropsiz {
    __u32 hcrop;
    __u32 vcrop;
}
```

Name	Description
hcrop	Number of pixels cropped in horizontal direction.
vcrop	Number of pixels cropped in vertical direction.

Table 7.19. Resizer: Crop Size structure fields

7.4.3.7. Input/Output image format

This describes the input and output image format, which can be YUV interleaved 16 bit or planar 8 bit. This can be specified in `inptype` field of the `rsz_params` structure.

```
#define RSZ_INTYPE_YCBCR422_16BIT 0
#define RSZ_INTYPE_PLANAR_8BIT 1
```

7.4.3.8. Pixel Format

This describes pixel format for the YUV interleaved data. This can be specified in `pix_fmt` member of `rsz_params` structure.

```
#define RSZ_PIX_FMT_UYVY 1 /* cb:y:cr:y */
#define RSZ_PIX_FMT_YUYV 0 /* y:cb:y:cr */
```


7.5. Driver Configuration

7.5.1. Configuration Steps

To enable OMAP Resizer driver:

1. Open menuconfig options from kernel command prompt.
2. Select Device Drivers as shown here:




Figure 7.3. Configure omap-resizer Driver: Step 2

3. Select Device Drivers > Multimedia devices as shown here:




Figure 7.4. configure omap-resizer Driver: Step 3

4. Select Video For Linux

```

----- Multimedia devices -----
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < > module

*** Multimedia core support ***
<Y> Video For Linux
[*] Enable Video For Linux API 1 (DEPRECATED) (NEW)
-*~ Enable Video For Linux API 1 compatible Layer
< > DVB for Linux (NEW)
*** Multimedia drivers ***
[ ] Load and attach frontend and tuner driver modules as needed (NEW)
[ ] Customize analog and hybrid tuner modules to build (NEW) --->
[*] Video capture adapters (NEW) --->
[*] Radio Adapters (NEW) --->
[ ] DAB adapters (NEW)

<Select> < Exit > < Help >

```

Figure 7.5. Configure omap-resizer Driver: Step 4

5. Select Device Drivers > Multimedia devices > Video capture adapters as shown here and go inside the main menu:

```

----- Multimedia devices -----
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < > module

*** Multimedia core support ***
<Y> Video For Linux
[*] Enable Video For Linux API 1 (DEPRECATED) (NEW)
-*~ Enable Video For Linux API 1 compatible Layer
< > DVB for Linux (NEW)
*** Multimedia drivers ***
[ ] Load and attach frontend and tuner driver modules as needed (NEW)
[ ] Customize analog and hybrid tuner modules to build (NEW) --->
[*] Video capture adapters (NEW) --->
[*] Radio Adapters (NEW) --->
[ ] DAB adapters (NEW)

<Select> < Exit > < Help >

```

Figure 7.6. Configure omap-resizer Driver: Step 5

6. Select "OMAP ISP Resizer" option to enable resizer driver,

```

----- Video capture adapters -----
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < >

^(-)
< > CPiA Video For Linux
< > CPiA2 Video For Linux
< > SAA5246A, SAA5281 Teletext processor
< > SAA5249 Teletext processor
< > OMAP ISP Previewer
<Y> OMAP ISP Resizer
<*> OMAP 3 Camera support
[*] OMAP2/OMAP3 V4L2-DSS drivers
<*> OMAP Video out library
<*> OMAP Video out driver
l(+)
```

<Select> < Exit > < Help >

Figure 7.7. Configure omap-resizer Driver: Step 6

7.6. Sample Application Flow

This section shows application flow diagram for resizer application.




Figure 7.8. Resizer Sample Application Flow

7.7. Revision History

0.97	Initial Draft.
02.00.00	Moved to GIT kernel baseline.
02.00.01	Updated for the second snapshot release.

Daughter Card Module

Abstract

Table of Contents

8.1. Mass Market Daughter Card	148
8.1.1. Acronyms & Definitions	148
8.1.2. Introduction	148
8.2. Block Diagram	149
8.3. Board Illustration	150
8.4. Features supported under software	151

8.1. Mass Market Daughter Card

8.1.1. Acronyms & Definitions

Acronym	Definition
MMDC	Multi-Media Daughter Card/Customer Daughter Card

Table 8.1. MMDC Acronyms

8.1.2. Introduction

OMAP35x daughter-card (MMDC) supports following features which are not available on the main OMAP3EVM-1 (<Rev-E).



Note

Please note that all the MMDC components/peripherals have been moved on-board for OMAP3EVM-2 (>=Rev-E). So this section is applicable only for OMAP3EVM-1 (<Rev-E).

1. TVP5146 decoder interface supporting BT656 format.
2. Supports 3 types of video input types - S-Video, Composite and component.
3. Supports 8/10 bit output interface from TVP5146.
4. Supports interface for Micron sensor.
5. HSUSB TRANSCEIVER- USB83320 supporting EHCI on port 2

8.2. Block Diagram

The top level block depicts the features supported on the daughter-card.




Figure 8.1. Block Diagram

8.3. Board Illustration

The various connectors and hardware modules on the daughter card are illustrated in the picture below:




Figure 8.2. Board Illustration

8.4. Features supported under software

- Video capture (BT656 interface) using the TVP5146 decoder.
- Support Composite and S-video interface only.
- EHCI on USB port-2 using HSUSB TRANSCEIVER- USB83320.

Capture Driver

Abstract

Table of Contents

9.1. Introduction	155
9.1.1. References	156
9.1.2. Acronyms & Definitions	157
9.2. Features	158
9.2.1. Supported features	158
9.2.2. Constraints/Limitations	158
9.2.3. Known Issues	158
9.3. Architecture	160
9.3.1. System Diagram	160
9.3.2. Software Design Interfaces	162

9.4. Driver Configuration	178
9.4.1. Configuration Steps	178
9.4.2. Installation	182
9.5. Sample Applications	184
9.5.1. Introduction	184
9.5.2. Hardware Setup	184
9.5.3. Provided Sample Applications	184

9.1. Introduction

The camera ISP is a key component for imaging and video applications such as video preview, video record, and still-image capture with or without digital zooming.

The camera ISP provides the system interface and the processing capability to connect RAW image-sensor modules and video decoders to the OMAP35x device.

The capture module consists of the following interfaces:

- One S-video SD input in BT.656 format.
- One Composite SD input in BT.656 format.

Both these video inputs are connected to one TVP5146 decoder and the application can select between these two inputs using standard V4L2 interface.



Note

Only one input can be captured or selected at any given point of time.

The following figure shows the basic block diagram of capture interface.




Figure 9.1. Capture Driver Component Overview

The following figure shows the physical connection and inputs for TVP5146 decoder.




Figure 9.2. Capture Physical Input Interface

The V4L2 Capture driver model is used for capture module. The V4L2 driver model is widely used across many platforms in the Linux community. V4L2 provides good streaming support and support for many buffer formats. It also has its own buffer management mechanism that can be used.

9.1.1. References

1. OMAP35x Camera Interface Subsystem (ISP) TRM
 Author: Texas Instruments, Inc.
 Literature Number: SPRUFA2
2. OOMAP35x Memory Management Units (MMUs)TRM
 Author: Texas Instruments, Inc.
 Literature Number: SPRUFF5
3. Video for Linux Two API Specification
 Author: Michael H Schimek
 Version: 0.23

9.1.2. Acronyms & Definitions

Acronym	Definition
MMDC	Mass Market Daughter Card/Customer Daughter Card
3A	Auto White Balance, Auto Focus, Auto Exposure
API	Application Programming Interface
CCDC	Input interface block of ISP
DMA	Direct Memory Access
I/O	Input & Output
IOCTL	Input & Output Control
MMU	Memory Management Unit
V4L2	Video for Linux specification version 2
YUV	Luminance + 2 Chrominance Difference Signals (Y, Cr, Cb) Color Encoding

Table 9.1. Capture Driver Acronyms

9.2. Features

9.2.1. Supported features

The ISP Capture Driver provides the following features:

- Supports one software channel of capture and a corresponding device node (/dev/video0) is created.
- Supports single I/O instance and multiple control instances.
- Supports buffer access mechanism through memory mapping and user pointers.
- Supports dynamic switching among input interfaces with some necessary restrictions wherever applicable.
- Supports NTSC and PAL standard on Composite and S-Video interfaces.
- Supports 8-bit BT.656 capture in UYVY and YUYV interleaved formats.
- Supports standard V4L2 IOCTLs to get/set various control parameters like brightness, contrast, saturation, hue and auto gain control.
- TVP5146 (TVP514x) decoder driver module can be used statically or dynamically (insmod and rmmod supported).

9.2.2. Constraints/Limitations

Following are the constraints for ISP Capture Driver:

- The camera ISP driver supports only static module build.
- Dynamic switching of resolution and dynamic switching of interfaces is not supported when streaming is on.
- Driver buffer addresses and pitch must be aligned to 32 byte boundary.
- Cropping and scaling operations and their corresponding V4L2 IOCTLs are not supported.

9.2.3. Known Issues

- In loopback sample application, the video displayed on the LCD has interlacing artifacts when viewing fast moving objects. This is because the input video is in interlaced mode @ 30 FPS while the

LCD works in progressive mode @ 60 FPS. The frame rate conversion and de-interlacing is not done in the current sample application.

- Field id is not coming proper on mass market daughter card. This results in flickering of image.
- Video quality issues observed with video test patterns.
- Buffer Constraints: - IO mapped buffer is not supported.
- Both MMDC and OMAP3EVM-2 (\geq Rev-E) does not work simultaneously, they are mutual exclusive from software point of view.

9.3. Architecture

9.3.1. System Diagram

Following block diagram shows basic architecture of the ISP Capture Driver.




Figure 9.3. Capture Driver Basic Architecture

The system architecture diagram illustrates the software components that are relevant to the Camera Driver. Some components are outside the scope of this design document. The following is a brief description of each component in the figure.

Camera Applications: Camera applications refer to any application that accesses the device node that is served by the Camera Driver. These applications are not in the scope of this design. They are here to present the environment in which the Camera Driver is used.

V4L2 Subsystem: The Linux V4L2 subsystem is used as an infrastructure to support the operation of the Camera Driver. Camera applications mainly use the V4L2 API to access the Camera Driver functionality. A Linux 2.6 V4L2 implementation is used in order to support the standard features that are defined in the V4L2 specification.

Video Buffer Library: This library comes with V4L2. It provides helper functions to cleanly manage the video buffers through a video buffer queue object.

Camera Driver: The Camera Driver allows capturing video through an external decoder. It is a V4L2-compliant driver with addition of an OMAP3 ISP hardware feature. This driver conforms to the Linux driver model for power management. The camera driver is registered to the V4L2 layer as a master device driver. Any slave decoder driver added to the V4L2 layer will be attached to this driver through the new V4L2 master-slave interface layer. The current implementation supports only one slave device.

Decoder Driver: The Camera Driver is designed to be OMAP dependent, but platform and board independent. It is the decoder driver that manages the board connectivity. A decoder driver must implement the new V4L2 master-slave interface. It should register to the V4L2 layer as a slave device. Changing a decoder requires implementation of a new decoder driver; it does not require changing the Camera Driver. Each decoder driver exports a set of IOCTLS to the master device through function pointers.

ISP Library: The ISP library exports APIs to configure ISP module and clocks to the sensor/decoder. It is the central interrupt handler where callback routines for ISP interrupts are handled. This also manages the video buffers.

CCDC library: CCDC is a HW block in Camera ISP which acts as a data input port. It receives data from the sensor/decoder through parallel or serial interface. The CCDC library exports API to configure CCDC module. It is configured by the ISP driver based on the sensor/decoder attached and desired output from the camera driver.

MMU library: MMU is a HW block in Camera ISP that handles the translation from virtual into physical addresses. The camera subsystem issues virtual addresses to the ISP MMU and the ISP MMU translates these virtual addresses into physical addresses to access the actual memory. Using this the camera driver captures video data in fragmented physical memory without moving data. The MMU library exports API to configure MMU module.

Preview library: Preview is a HW block in Camera ISP which is responsible for image processing and color conversion. It has HW blocks for image processing algorithms. Preview library allows camera driver to configure, enable and disable the individual HW blocks in the preview module. This module will be used only when a RAW sensor is connected to the ISP.

Resizer library: Resizer is a HW block in Camera ISP which is responsible for image downscaling and upscaling. It has HW filters which resize the input image based on configuration. Resizer library allows camera driver to query and configure the resizer module. Resizer in OMAP3 ISP supports resizing ratios from 1/4 to 4. Resizer also has

multipass approach which can be used to overcome this limitation. Current camera driver only supports on the fly mode of operation. In this mode image is taken from sensor and passed to application without any memory to memory operations in ISP and so multipass resizer operations are not supported.

H3A library: H3A is a HW block in Camera ISP which is responsible for collecting image statistics that can be used by other algorithms. It generates auto focus, auto white balance, auto exposure and histogram statistics. H3A library allows user space algorithms to configure and request these statistics through custom IOCTLs.

9.3.2. Software Design Interfaces

9.3.2.1. Opening and Closing of driver

The device can be opened using open call from the application, with the device name and mode of operation as parameters. Application should open the driver in blocking mode. In this mode, DQBUF IOCTL will not return until an empty frame is available.

```
/* call to open a video capture logical channel in blocking mode
 */
fd = open("/dev/video0", O_RDWR);
/* closing of channel */
close (fd);
```

9.3.2.2. Buffer Management

ISP Capture driver can work with physically non-contiguous buffers. It uses the ISP MMU to capture data to buffers scattered to a set of page frames. Hence, in user pointer mode the application can allocate buffers in user space, which need not be physically contiguous, and pass this directly to driver for capture operation. The only restriction for the user buffer is that, the buffer should be aligned to 32 bytes boundary. The driver supports both memory usage modes:

- 1) Memory map buffer mode
- 2) User Pointer mode

In Memory map buffer mode, application can request memory from the driver by calling VIDIOC_REQBUFS IOCTL. In user buffer mode, application needs to allocate memory using some other mechanism in user space like malloc or memalign. In driver buffer mode, maximum number of buffers is limited to VIDEO_MAX_FRAME (defined in driver header files) and is limited by the available memory in the kernel.

The main steps that the application must perform for buffer allocation are:

- 1) Allocating Memory
- 2) Getting Physical Address
- 3) Mapping Kernel Space Address to User Space

1. Allocating Memory

This IOCTL is used to allocate memory for frame buffers. This is the necessary IOCTL for streaming IO. It has to be called for both driver buffer mode and user buffer mode. Using this IOCTL, driver will know whether driver buffer mode or user buffer mode will be used.

Ioctl: **VIDIOC_REQBUFS**

It takes a pointer to instance of `v4l2_requestbuffers` structure as an argument.

User should specify buffer type as (`V4L2_BUF_TYPE_VIDEO_CAPTURE`), number of buffers, and memory type (`V4L2_MEMORY_MMAP`, `V4L2_MEMORY_USERPTR`) at the time of buffer allocation.

Constraint: This IOCTL can be called only once from the application. This IOCTL is necessary IOCTL.

Example:

```
/* structure to store buffer request parameters */
struct v4l2_requestbuffers reqbuf;

reqbuf.count = numbuffers;
reqbuf.type = V4L2_BUF_TYPE_VIDEO_CAPTURE;
reqbuf.memory = V4L2_MEMORY_MMAP;
ret = ioctl(fd, VIDIOC_REQBUFS, &reqbuf);
if (ret < 0) {
    printf("cannot allocate memory\n");
    close(fd);
    return -1;
}

printf("Number of buffers allocated = %d\n", reqbuf.count);
```

2. Getting Physical Address

This IOCTL is used to query buffer information like buffer size and buffer physical address. This physical address is used in mmaping the buffers. This IOCTL is necessary for driver buffer mode as it provides the physical address of buffers, which are used to mmap system call the buffers.

Ioctl: **VIDIOC_QUERYBUF**

It takes a pointer to instance of `v4l2_buffer` structure as an argument.

User has to specify buffer type as (V4L2_BUF_TYPE_VIDEO_CAPTURE), buffer index, and memory type (V4L2_MEMORY_MMAP) at the time of querying.

Example:

```
/* allocate buffer by VIDIOC_REQBUFS */
/* structure to query the physical address of allocated buffer */
struct v4l2_buffer buffer;

buffer.index = 0; /* buffer index for querying -0 */
buffer.type = V4L2_BUF_TYPE_VIDEO_CAPTURE;
buffer.memory = V4L2_MEMORY_MMAP;
if (ioctl(fd, VIDIOC_QUERYBUF, &buffer) < -1) {
    printf("buffer query error.\n");
    close(fd);
    exit(-1);
}
```

The buffer.m.offset will contain the physical address returned from driver.

3. Mapping Kernel Space Address to User Space

Mapping the kernel buffer to the user space can be done via mmap. This is only required for MMAP buffer mode. User can pass buffer size and physical address of buffer for getting the user space address.

Example:

```
/* allocate buffer by VIDIOC_REQBUFS */
/* query the buffer using VIDIOC_QUERYBUF */
/* addr hold the user space address */
int addr;
addr = mmap(NULL, buffer.size, PROT_READ | PROT_WRITE,
            MAP_SHARED, fd, buffer.m.offset);

/* buffer.m.offset is same as returned from VIDIOC_QUERYBUF */
```

9.3.2.3. Query Capabilities

This IOCTL is used to verify kernel devices compatibility with V4L2 specification and to obtain information about individual hardware capabilities. In this case, it will return capabilities provided by ISP capture driver and current decoder driver.

Ioctl: VIDIOC_QUERYCAP

Capabilities can be video capture (V4L2_CAP_VIDEO_CAPTURE) and streaming (V4L2_CAP_STREAMING).

It takes pointer to v4l2_capability structure as an argument.

Capabilities can be accessed by capabilities field in the v4l2_capability structure.

Example:

```
struct v4l2_capability capability;

ret = ioctl(fd, VIDIOC_QUERYCAP, &capability);
if (ret < 0) {
    printf("Cannot do QUERYCAP\n");
    return -1;
}

if (capability.capabilities & V4L2_CAP_VIDEO_CAPTURE) {
    printf("Capture capability is supported\n");
}
if (capability.capabilities & V4L2_CAP_STREAMING) {
    printf("Streaming is supported\n");
}
```

9.3.2.4. Input Enumeration

This IOCTL is used to enumerate the information of available inputs (analog interface). It includes information like name of input type and supported standards for that input type.

Ioctl: VIDIOC_ENUMINPUT

It takes pointer to v4l2_input structure. Application provides the index number for which it requires the information, in index member of v4l2_input structure.

Index with value zero indicates first input type of the decoder. It returns combination of the standards supported on this input in the std member of v4l2_input structure.

Example:

```
struct v4l2_input input;

i = 0;
while(1) {
    input.index = i;
    ret = ioctl(fd, VIDIOC_ENUMINPUT, &input);
    if (ret < 0)
        break;

    printf("name = %s\n", input.name);
}
```

```
        i++;  
    }
```

9.3.2.5. Set Input

This IOCTL is used to set input type (analog interface type).

Ioctl: VIDIOC_S_INPUT

This IOCTL takes pointer to integer containing index of the input which has to be set.

Application will provide the index number as an argument.

```
    0 - Composite input,  
    1 - S-Video input.
```

Example:

```
int index = 1; /*To set S-Video input*/  
struct v4l2_input input;  
  
ret = ioctl(fd, VIDIOC_S_INPUT, &index);  
if (ret < 0) {  
    perror("VIDIOC_S_INPUT\n");  
    close(fd);  
    return -1;  
}  
  
input.index = index;  
ret = ioctl(fd, VIDIOC_ENUMINPUT, &input);  
if (ret < 0) {  
    perror("VIDIOC_ENUMINPUT\n");  
    close(fd);  
    return -1;  
}  
  
printf("name of the input = %s\n",input.name);
```

9.3.2.6. Get Input

This IOCTL is used to get the current input type (analog interface type).

Ioctl: VIDIOC_G_INPUT

This IOCTL takes pointer to integer using which the detected inputs will be returned. It will return the first detected inputs. If no inputs are detected, it returns an error to the application.

Application will provide the index number as an output argument.

It will set the detected input as the current input.

Example:

```
int input;
struct v4l2_input input;

ret = ioctl(fd, VIDIOC_G_INPUT, &input);
if (ret < 0) {
    perror("VIDIOC_G_INPUT\n");
    close(fd);
    return -1;
}

input.index = index;
ret = ioctl(fd, VIDIOC_ENUMINPUT, &input);
if (ret < 0) {
    perror("VIDIOC_ENUMINPUT\n");
    close(fd);
    return -1;
}

printf("name of the input = %s\n", input.name);
```

9.3.2.7. Standard Enumeration

This IOCTL is used to enumerate the information regarding video standards.

This IOCTL is used to enumerate all the standards supported by the registered decoder.

Ioctl: VIDIOC_ENUMSTD

This IOCTL takes a pointer to `v4l2_standard` structure. Application provides the index of the standard to be enumerated in the `index` member of this structure. It provides information like standard name, standard ID defined at V4L2 header files (few new standards are included in the respective decoder header files, which were not available in standard V4L2 header files), and numerator and denominator values for frame period and frame lines.

It takes `index` as an argument as a part of `v4l2_standard` structure.

Index with value zero provides information for the first standard among all the standards of all the registered decoders.

If the index value exceeds the number of supported standards, it returns an error.

Example:

```
struct v4l2_standard standard;

i = 0;
```

```
while(1) {
    standard.index = i;
    ret = ioctl(fd, VIDIOC_ENUMSTD, &standard);
    if (ret < 0)
        break;

    printf("name = %s\n", std.name);
    printf("framelines = %d\n", std.framelines);
    printf("numerator = %d\n",
           std.frameperiod.numerator);
    printf("denominator = %d\n",
           std.frameperiod.denominator);
    i++;
}
```

9.3.2.8. Standard Detection

This IOCTL is used to detect the current video standard set in the current decoder.

Ioctl: VIDIOC_QUERYSTD

It takes a pointer to `v4l2_std_id` instance as an output argument. Driver will call the current decoder's function internally (which has been initialized) to detect the current standard set in hardware. Support of this IOCTL depends on decoder device, whether it can detect a standard or not.

Note: This IOCTL should be called by the application so that the camera driver can configure ISP properly with the detected decoder standard.

Standard IDs are defined in the V4L2 header files

Example:

```
v4l2_std_id std;
struct v4l2_standard standard;

ret = ioctl(fd, VIDIOC_QUERYSTD, &std);
if (ret < 0) {
    perror("VIDIOC_QUERYSTD\n");
    close(fd);
    return -1;
}

while(1) {
    standard.index = i;
    ret = ioctl(fd, VIDIOC_ENUMSTD, &standard);
    if (ret < 0)
        break;

    if (standard.std & std) {
        printf("%s standard detected\n",
               standard.name);
    }
}
```

```

        break;
    }
    i++;
}

```

9.3.2.9. Set Standard

This IOCTL is used to set the standard in the decoder.

Ioctl: VIDIOC_S_STD

It takes a pointer to `v4l2_std_id` instance as an input argument. If the standard is not supported by the decoder, the driver will return an error

Standard IDs are defined in the V4L2 header files (few new standards are included in respective decoder header files, which were not available in standard V4L2 header files).

Note: Application need not call this IOCTL as the decoder can auto detect the current standard. This is required only when the application needs to set a particular standard. In this case, the decoder driver auto detect function is disabled. Auto detect can be enabled again only by closing and re-opening the driver.

Example:

```

v4l2_std_id std = V4L2_STD_NTSC;

ret = ioctl(fd, VIDIOC_S_STD, &std);
if (ret < 0) {
    perror("S_STD\n");
    close(fd);
    return -1;
}

while(1) {
    standard.index = i;
    ret = ioctl(fd, VIDIOC_ENUMSTD, &standard);
    if (ret < 0)
        break;

    if (standard.std & std) {
        printf("%s standard is selected\n");
        break;
    }
    i++;
}

```

9.3.2.10. Get Standard

This IOCTL is used to get the current standard in the current decoder.

Ioctl: VIDIOC_G_STD

It takes a pointer to `v4l2_std_id` instance as an output argument.

Standard IDs are defined in the V4L2 header files

Example:

```
v4l2_std_id std;

ret = ioctl(fd, VIDIOC_G_STD, &std);
if (ret < 0) {
    perror("G_STD\n");
    close(fd);
    return -1;
}

while(1) {
    standard.index = i;
    ret = ioctl(fd, VIDIOC_ENUMSTD, &standard);
    if (ret < 0)
        break;

    if (standard.std & std) {
        printf("%s standard is selected\n");
        break;
    }
    i++;
}
```

9.3.2.11. Format Enumeration

This IOCTL is used to enumerate the information of pixel formats. The driver supports only two pixel form at -8-bit UYVY interleaved and 8-bit YUYV interleaved.

Ioctl: VIDIOC_ENUM_FMT

It takes a pointer to instance of `v4l2_fmtdesc` structure as an output parameter.

Application must provide the buffer type in the type argument of `v4l2_fmtdesc` structure as `V4L2_BUF_TYPE_VIDEO_CAPTURE` and index member of this structure as zero.

Example:

```
struct v4l2_fmtdesc fmt;

i = 0;
while(1) {
    fmt.index = i;
    ret = ioctl(fd, VIDIOC_ENUM_FMT, &fmt);
    if (ret < 0)
        break;
}
```



```

printf("description = %s\n",fmt.description);
if (fmt.type == V4L2_BUF_TYPE_VIDEO_CAPTURE)
    printf("Video capture type\n");
if (fmt.pixelformat == V4L2_PIX_FMT_YUYV)
    printf("V4L2_PIX_FMT_YUYV\n");
i++;
}

```

9.3.2.12. Set Format

This IOCTL is used to set the format parameters. The format parameters are line offset, storage format, pixel format, and so on. This IOCTL is one of the necessary IOCTL. If it is not set, it uses the following default values:

- Default storage format - V4L2_FIELD_INTERLACED

This IOCTL expects proper width and height members of the `v4l2_format` structure from application as per the standard selected.

Please note that, `V4L2_FIELD_INTERLACED` is the only storage format supported.

The application can decide the buffer pixel format using `pixelformat` member of this IOCTL. The current driver supports - 8-bit UYVY interleaved and 8-bit YUYV interleaved formats.

The desired pitch of the buffer can be set by using the `bytesperline` member. The pitch should be at least one line size in bytes. When changing the pitch, the application should also modify the `sizeimage` member accordingly - `sizeimage` should be at least `pitch * image height`.

The driver allocates buffer of size `sizeimage` member of the `v4l2_format` structure passed through this IOCTL for both `mmap` buffer and `user pointer` mode. Driver validates the provided buffer size along with the other members and uses this buffer size for calculating offsets for storing video data.

This IOCTL is a necessary IOCTL for the `user buffer` mode because driver will know the buffer size for `user buffer` mode. If it not called for the `user buffer` mode, driver assumes the default buffer size and calculates offsets accordingly.

Ioctl: VIDIOC_S_FMT

It will take pointer to instance of `v4l2_format` structure as an input parameter.

If the type member is `V4L2_BUF_TYPE_VIDEO_CAPTURE`, it checks pixel format, pitch value, and image size. It returns an error, if the parameters are invalid.

Example:

```

struct v4l2_format fmt;

fmt.type = V4L2_BUF_TYPE_VIDEO_CAPTURE;
fmt.fmt.pix.pixelformat = V4L2_PIX_FMT_UYVY;
/* for NTSC standard */
fmt.fmt.pix.width = 720;
fmt.fmt.pix.height = 480;
fmt.fmt.pix.field = V4L2_FIELD_INTERLACED;
ret = ioctl(fd, VIDIOC_S_FMT, &fmt);
if (ret < 0) {
    perror("VIDIOC_S_FMT\n");
    close(fd);
    return -1;
}

```

9.3.2.13. Get Format

This IOCTL is used to get the current format parameters.

Ioctl: VIDIOC_G_FMT

It takes a pointer to instance of `v4l2_format` structure as an input parameter.

Driver provides format parameters in the structure pointer passed as an argument.

`v4l2_format` structure contains parameters like pixel format, image size, bytes per line, and field type.

For type `V4L2_BUF_TYPE_VIDEO_CAPTURE`, the `v4l2_pix_format` structure of `fmt` union is filled.

Example:

```

struct v4l2_format fmt;

fmt.type = V4L2_BUF_TYPE_VIDEO_CAPTURE;
ret = ioctl(fd, VIDIOC_G_FMT, &fmt);
if (ret < 0) {
    perror("VIDIOC_G_FMT\n");
    close(fd);
    return -1;
}

if (fmt.fmt.pix.pixelformat == V4L2_PIX_FMT_UYVY)
    printf("8-bit UYVY pixel format\n");

printf("Size of the buffer = %d\n", fmt.fmt.pix.sizeimage);
printf("Line offset = %d\n", fmt.fmt.pix.bytesperline);

if (fmt.fmt.pix.field == V4L2_FIELD_INTERLACED)
    printf("Storate format is interlaced frame format");

```

9.3.2.14. Try Format

This IOCTL is used to validate the format parameters provided by the application. It checks parameters and returns the correct parameter, if any parameter is incorrect. It returns error only if the parameters passed are ambiguous.

Ioctl: VIDIOC_TRY_FMT

It takes a pointer to instance of `v4l2_format` structure as an input/output parameter

If the type member is `V4L2_BUF_TYPE_VIDEO_CAPTURE`, it checks pixel format, pitch value, and image size. It returns errors to the application, if the parameters are invalid.

Example:

```
struct v4l2_format fmt;

fmt.type = V4L2_BUF_TYPE_VIDEO_CAPTURE;
fmt.fmt.pix.pixelformat = V4L2_PIX_FMT_UYVY;
fmt.fmt.pix.sizeimage = size;
fmt.fmt.pix.bytesperline = pitch;
fmt.fmt.pix.field = V4L2_FIELD_INTERLACED;
ret = ioctl(fd, VIDIOC_TRY_FMT, &fmt);
if (ret < 0) {
    perror("VIDIOC_TRY_FMT\n");
    close(fd);
    return -1;
}
```

9.3.2.15. Query Control

This IOCTL is used to get the information of controls that is, brightness, contrast, and so on supported by the current decoder.

Ioctl: VIDIOC_QUERYCTRL

This IOCTL takes a pointer to the instance of `v4l2_queryctrl` structure as the argument and returns the control information in the same pointer. Application provides the control ID in the `v4l2_queryctrl` `id` member in this structure. This control ID is defined in V4L2 header file, for which information is needed.

If the control command specified by `Id` is not supported in current decoder, driver will return an error.

Example:

```
struct v4l2_queryctrl ctrl;
```

```

ctrl.id = V4L2_CID_CONTRAST;
ret = ioctl(fd, VIDIOC_QUERYCTRL, &ctrl);
if (ret < 0) {
    perror("VIDIOC_QUERYCTRL \n");
    close(fd);
    return -1;
}

printf("name = %s\n", ctrl.name);
printf("min = %d max = %d step = %d default = %d\n",
    ctrl.minimum, ctrl.maximum, ctrl.step, ctrl.default_value);

```

9.3.2.16. Set Control

This IOCTL is used to set the value for a particular control in current decoder. To set the control value, this IOCTL can also be called when streaming is on.

Ioctl: VIDIOC_S_CTRL

It takes a pointer to instance of `v4l2_control` structure as an input parameter.

Application provides control ID and control values in the `v4l2_control` id and value member in this structure. If the control command specified by Id is not supported in the current decoder and if value of the control is out of range, driver returns an error. Otherwise, it sets the control in the registers.

Example:

```

struct v4l2_control ctrl;

ctrl.id = V4L2_CID_CONTRAST;
ctrl.value = 100;
ret = ioctl(fd, VIDIOC_S_CTRL, &ctrl);
if (ret < 0) {
    perror("VIDIOC_S_CTRL\n");
    close(fd);
    return -1;
}

```

9.3.2.17. Get Control

This IOCTL is used to get the value for a particular control in the current decoder.

Ioctl: VIDIOC_G_CTRL

It takes a pointer to instance of `v4l2_control` structure as an output parameter. Application provides the control ID of id member in this

structure. If the control command specified by `Id` is not supported in the current decoder, driver returns an error. Otherwise, it returns the value of the control in the value member of the `v4l2_control` structure.

Example:

```
struct v4l2_control ctrl;

ctrl.id = V4L2_CID_CONTRAST;
ret = ioctl(fd, VIDIOC_G_CTRL, &ctrl);
if (ret < 0) {
    perror("VIDIOC_G_CTRL\n");
    close(fd);
    return -1;
}
printf("value = %x\n", ctrl.value);
```

9.3.2.18. Queue Buffer

This IOCTL is used to enqueue the buffer in buffer queue. This IOCTL will enqueue an empty buffer in the driver buffer queue. This IOCTL is one of necessary IOCTL for streaming IO. If no buffer is enqueued before starting streaming, driver returns an error as there is no buffer available. So at least one buffer must be enqueued before starting streaming. This IOCTL is also used to enqueue empty buffers after streaming is started.

Ioctl: VIDIOC_QBUF

This IOCTL takes a pointer to instance of `v4l2_buffer` structure as an argument. Application has to specify the buffer type (`V4L2_BUF_TYPE_VIDEO_CAPTURE`), buffer index, and memory type (`V4L2_MEMORY_MMAP` or `V4L2_MEMORY_USERPTR`) at the time of queuing. For the user pointer buffer exchange mechanism, application also has to provide buffer pointer in the `m.userptr` member of `v4l2_buffer` structure.

Driver will enqueue buffer in the driver's incoming queue.

It will take pointer to instance of `v4l2_buffer` structure as an input parameter.

Example:

```
struct v4l2_buffer buf;

buf.type = V4L2_BUF_TYPE_VIDEO_CAPTURE;
buf.type = V4L2_MEMORY_MMAP;
buf.index = 0;
ret = ioctl(fd, VIDIOC_QBUF, &buf);
if (ret < 0) {
    perror("VIDIOC_QBUF\n");
    close(fd);
}
```

```

    return -1;
}

```

9.3.2.19. Dequeue Buffer

This IOCTL is used to dequeue the buffer in the buffer queue. This IOCTL will dequeue the captured buffer from buffer queue of the driver. This IOCTL is one of necessary IOCTL for the streaming IO. This IOCTL can be used only after streaming is started. This IOCTL will block until an empty buffer is available.

Note: The application can dequeue all buffers from the driver - the driver will not hold the last buffer to itself. In this case, the driver will disable the capture operation and the capture operation resumes when a buffer is queued to the driver again.

Ioctl: VIDIOC_DQBUF

It takes a pointer to instance of v4l2_buffer structure as an output parameter.

Application has to specify the buffer type (V4L2_BUF_TYPE_VIDEO_CAPTURE) and memory type (V4L2_MEMORY_MMAP or V4L2_MEMORY_USERPTR) at the time of dequeuing.

If this IOCTL is called with the file descriptor, with which VIDIOC_REQBUF is not performed, driver will return an error.

Driver will enqueue buffer, if the buffer queue is not empty.

Example:

```

struct v4l2_buffer buf;

buf.type = V4L2_BUF_TYPE_VIDEO_CAPTURE;
buf.type = V4L2_MEMORY_MMAP;
ret = ioctl(fd, VIDIOC_DQBUF, &buf);
if (ret < 0) {
    perror("VIDIOC_DQBUF\n");
    close(fd);
    return -1;
}

```

9.3.2.20. Stream On

This IOCTL is used to start video capture functionality.

Ioctl: VIDIOC_STREAMON

If streaming is already started, this IOCTL call returns an error.

Example:

```
v4l2_buf_type buftype = V4L2_BUF_TYPE_VIDEO_CAPTURE;
ret = ioctl(fd, VIDIOC_STREAMON, &buftype);
if (ret < 0) {
    perror("VIDIOC_STREAMON \n");
    close(fd);
    return -1;
}
```

9.3.2.21. Stream Off

This IOCTL is used to stop video capture functionality.

Ioctl: VIDIOC_STREAMOFF

If streaming is not started, this IOCTL call returns an error.

Example:

```
v4l2_buf_type buftype = V4L2_BUF_TYPE_VIDEO_CAPTURE;
ret = ioctl(fd, VIDIOC_STREAMOFF, &buftype);
if (ret < 0) {
    perror("VIDIOC_STREAMOFF \n");
    close(fd);
    return -1;
}
```

9.4. Driver Configuration

9.4.1. Configuration Steps

To enable capture driver support in the kernel:

1. Open menuconfig options from kernel command prompt.
2. Select Device Drivers as shown here:




Figure 9.4. Configure Capture Driver: Step 4

3. Select Device Drivers > Multimedia devices as shown here:


```

----- Device Drivers -----
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < >

^(-)
< > Hardware Monitoring support --->
< > Generic Thermal sysfs driver --->
[*] Watchdog Timer Support --->
    Sonics Silicon Backplane --->
    Multifunction device drivers --->
    Multimedia devices --->
    Graphics support --->
< > Sound card support --->
[*] HID Devices --->
[*] USB support --->
l(+)-

<Select>    < Exit >    < Help >

```

Figure 9.5. Configure Capture Driver: Step 5

4. Select Device Drivers > Multimedia devices > Video capture adapters as shown here:

```

----- Multimedia devices -----
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < >

^(-)
<*> Video For Linux
    [*] Enable Video For Linux API 1 (DEPRECATED)
< > DVB for Linux
    *** Multimedia drivers ***
    [ ] Load and attach frontend and tuner driver modules as needed
    [ ] Customize analog and hybrid tuner modules to build --->
    [*] Video capture adapters --->
    [*] Radio Adapters --->
    [*] DAB adapters
< > DABUSB driver

<Select>    < Exit >    < Help >

```

Figure 9.6. Configure Capture Driver: Step 6

5. Select Device Drivers > Multimedia devices > Video capture adapters > OMAP 3 Camera support as shown here:

```

Video capture adapters
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < >

^(-)
< > CPiA Video For Linux
< > CPiA2 Video For Linux
< > SAA5246A, SAA5281 Teletext processor
< > SAA5249 Teletext processor
<*> OMAP 3 Camera support
< > OMAP ISP Previewer
<*> OMAP ISP Resizer
[*] OMAP2/OMAP3 V4L2-DSS drivers
<*> OMAP Video out library
<*> OMAP Video out driver
l(+)
```

<Select> < Exit > < Help >

Figure 9.7. Configure Capture Driver: Step 7

6. Select Device Drivers > Multimedia devices > Video capture adapters > Encoders/decoders and other helper chips as shown here:

```

--- Video capture adapters ---
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < >

--- Video capture adapters
[ ] Enable advanced debug functionality
[ ] Enable old-style fixed minor ranges for video devices
[ ] Autoselect pertinent encoders/decoders and other helper chi
[*] Encoders/decoders and other helper chips --->
< > Virtual Video Driver
< > CPiA Video For Linux
< > CPiA2 Video For Linux
< > SAA5246A, SAA5281 Teletext processor
< > SAA5249 Teletext processor
l(+)_

<Select> < Exit > < Help >

```

Figure 9.8. Configure Capture Driver: Step 8

7. Select Device Drivers > Multimedia devices > Video capture adapters > Encoders/decoders and other helper chips > Texas Instruments TVP514x video decoder as shown here:

```

----- Encoders/decoders and other helper chips -----
Arrow keys navigate the menu. <Enter> selects submenus --->.
Highlighted letters are hotkeys. Pressing <Y> includes, <N> excludes,
<M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < >

^ (-)
< > Philips SAA7111 video decoder
< > Philips SAA7114 video decoder
< > Philips SAA7113/4/5 video decoders
< > Philips SAA7171/3/4 audio/video decoders
< > Philips SAA7191 video decoder
[*] Texas Instruments TVP514x video decoder
< > Texas Instruments TVP5150 video decoder
< > vpx3220a, vpx3216b & vpx3214c video decoders
*** Video and audio decoders ***
< > Conexant CX2584x audio/video decoders
l (+)

<Select>    < Exit >    < Help >

```

Figure 9.9. Configure Capture Driver: Step 9

9.4.2. Installation



Note

Please note that the software detects and configures the peripherals dynamically/run-time depending on EVM revision. In case of OMAP3EVM-1 (<Rev-E) it configures the peripherals on MMDC and in case of OMAP3EVM-2 (>=Rev-E) it configures On-board peripherals.

9.4.2.1. Driver built statically

If the OMAP35x Camera driver and TVP514x driver are built statically into the kernel, it is activated during boot-up. There is no special procedure to install the driver.

9.4.2.2. Driver built as loadable module

The OMAP35x Camera driver and OMAP35x daughter card (applicable for OMAP3EVM-1 (<Rev-E)) driver cannot be build as a loadable module. Only the TVP514x driver can be build as a module. If the driver has been configured to be a loadable module, then the driver is built as a module with the name tvp514x.ko, which will be placed under the directory `drivers/media/video` in the kernel tree.

Copy this driver file on to the target board and issue the following command to insert the driver:

```
insmod tvp514x.ko
```

To remove the driver, issue the following command:

```
rmmod tvp514x.ko
```

9.5. Sample Applications

This chapter describes the sample application provided along with the package. The binary and the source for these sample application can be available in the Examples directory of the Release Package folder.

9.5.1. Introduction

Writing a capture application involves the following steps:

- Opening the capture device.
- Set the parameters of the device.
- Allocate and initialize capture buffer
- Receive video data from the device.
- Close the device.

9.5.2. Hardware Setup

Following are the steps required to run the capture sample application:

- If you are using OMAP3EVM-1 (<Rev-E) revision board, connect the OMAP35x daughter card module containing the TVP5146 deocder to the OMAP35x main board. For OMAP3EVM-2 (>=Rev-E), all the peripherals including TVP5146 decoder is present on board.
- Connect a DVD player/camera generating a NTSC video signal to the S-Video or Composite jack of the daughter card or EVM.
- Run the sample application after booting the kernel.

9.5.3. Provided Sample Applications

Following are the list of capture sample application provided with the release:

- **MMAP Loopback Application (saMmapLoopback.c):**

This sample application using driver allocated buffers to capture video data from any one of the active inputs and displays the video in the LCD using display driver.

USB Driver

Abstract

Table of Contents

10.1. Introduction	187
10.1.1. References	187
10.1.2. Hardware Overview	187
10.2. Features	189
10.2.1. Supported	189
10.2.2. Not supported	189
10.3. Driver configuration	191
10.3.1. USB phy selection for MUSB OTG port	191
10.3.2. USB controller in host mode	191
10.3.3. MUSB OTG controller in gadget mode	192

10.3.4. MUSB OTG controller in OTG mode	193
10.3.5. Host mode applications	194
10.3.6. USB Controller and USB MSC HOST	194
10.3.7. USB HID Class	195
10.3.8. USB Controller and USB HID	196
10.3.9. USB Audio	196
10.3.10. USB Video	197
10.3.11. Gadget Mode Applications	198
10.3.12. CDC/RNDIS gadget	199
10.3.13. USB OTG (HNP/SRP) testing	200
10.4. Software Interface	202
10.4.1. sysfs	202
10.4.2. procfs	202
10.5. Revision history	203

10.1. Introduction

TI OMAP35x has a host cum gadget controller MUSB OTG, an EHCI and its companion OHCI controller. There are three USB ports which are to be controlled by either EHCI or OHCI controller individually.

In ES2.0/2.1 silicon all the three ports can either be configured in PHY mode or in TLL mode at a time. This limitation got resolved in ES3.0/3.1 silicon where PHY/TLL mode selection can be done on a per port basis.

The salient features of the MUSB OTG controller are:

- High/full speed operation as USB peripheral.
- High/full/low speed operation as Host controller.
- The host controller for a multi-point USB system (when connected via hub).
- USB On-The-Go compliant USB controller.
- 15 Transmit and 15 Receive Endpoints other than the mandatory Control Endpoint 0.
- 16 Kilobytes of Endpoint FIFO RAM for USB packet buffering.
- Double buffering FIFO.
- Support for Bulk split and Bulk combine
- Support for high bandwidth Isochronous transfer
- Dual Mode HS DMA controller with 8 channels.

10.1.1. References

1. OMAP35x Technical Reference Manual

10.1.2. Hardware Overview

The OMAP35x MUSB OTG controller sits on the L3 and L4 interconnect. It can be an L3 master while performing DMA transfers and an L4 target when host CPU/DMA engine is the master.

OMAP3EVM-1 (<=Rev-E) has an OTG compliant USB PHY from NXP (ISP 1504) and OMAP3EVM-2 (>=Rev-E) has NXP USB PHY ISP1507.

The USB controller in the SoC is connected to the NXP PHY located on the EVM. A mini-AB USB port connects to the PHY. Hence, there is only one root port for the USB controller.




Figure 10.1. MUSB OTG: Location of Mini-AB receptacle on the EVM




Figure 10.2. MUSB OTG: Location of USB PHY from NXP on the EVM

The OMAP35x HS USB port2 is connected to SMSC USB83320 high speed PHY on Mistral/Multimedia daughter card (MMD) attached to OMAP3EVM-1 (\leq Rev-E) whereas on OMAP3EVM-2 (\geq Rev-E) it is connected to SMSC USB3320 PHY.

Port1 and Port3 are not available either on MMD attached to OMAP3EVM-1 (\leq Rev-E) or OMAP3EVM-2 (\geq Rev-E).

10.2. Features

The MUSB OTG and EHCI drivers supports a significant subset of all the features provided by the USB controller. The following section discusses the supported and unsupported features in this release.

10.2.1. Supported

The Driver supports the following features for MUSB OTG port:

- Can be built in-kernel (part of vmlinux) as well as a driver module (musb_hdrc.ko).
- Audio Class in Host mode.
- Video Class in Host mode.
- Mass Storage Class in Host mode.
- Mass Storage Class in Gadget mode.
- Hub Class in Host mode.
- Human Interface Devices (HID) in Host mode.
- Communication Device Class (CDC) in Gadget mode.
- Remote Network Driver Interface Specification (RNDIS) Gadget support.
- OTG support which includes support for Host Negotiation Protocol (HNP) and Session Request Protocol (SRP).

10.2.2. Not supported

The following features are not currently supported by driver:

- OHCI support as OHCI port is not available either on MMDC attached to OMAP3EVM-1 (\leq Rev-E) or OMAP3EVM-2 (\geq Rev-E).

10.2.2.1. Limitations

- There is a limitation in the power that is supplied by the charge pump on OMAP3EVM-1 (\leq Rev-E).

OMAP3EVM-2 (\geq Rev-E) supports 500mA of power.

- Mentor USB OTG RTL version 1.4 has a hardware issue with Inventra DMA causing DMA lock-up when both TX and RX DMA channels are simultaneously enabled.

We have enabled use of System DMA for all Rx transfers to work around this issue. As system DMA performance is low thus Rx through put is lower.

- Driver doesn't behave as expected when power management is enabled.

10.3. Driver configuration

The MUSB OTG controller is used in Host and Gadget modes while EHCI is used only in Host mode. The following section shows the configuration options for USB and its associated class drivers.

10.3.1. USB phy selection for MUSB OTG port

Please select NOP USB transceiver for MUSB support.

```
Device Drivers --->
USB support --->
*** OTG and related infrastructure ***
[ ] GPIO based peripheral-only VBUS sensing 'transceiver'
[ ] Philips ISP1301 with OMAP OTG
[ ] TWL4030 USB Transceiver Driver
[*] NOP USB Transceiver Driver
```

10.3.2. USB controller in host mode

10.3.2.1. MUSB OTG Host Configuration

```
Device Drivers --->
USB support --->
<*> Support for Host-side USB
*** Miscellaneous USB options ***
[*] USB device filesystem
[*] USB device class-devices (DEPRECATED)
*** USB Host Controller Drivers ***
<*> Inventra Highspeed Dual Role Controller (TI, ...)
*** OMAP 343x high speed USB support ***
Driver Mode (USB Host) --->
[ ] Disable DMA (always use PIO)
[*] Use System DMA for Rx endpoints
[*] Enable debugging messages
```

10.3.2.2. EHCI Configuration

Port-2 will automatically be selected for OMAP3EVM and would be configured in PHY mode.

```
Device Drivers --->
USB support --->
<*> Support for Host-side USB
*** Miscellaneous USB options ***
```

```
[*] USB device filesystem
[*] USB device class-devices (DEPRECATED)
<*> EHCI HCD (USB2.0) Support
[*] Select PHY/TLL mode for USB ports on OMAP24xx/OMAP35xx --->
    Port2 in PHY/TLL mode (PHY mode) --->
[ ] Root hub transaction translators
*** USB Host Controller Drivers ***
```

10.3.3. MUSB OTG controller in gadget mode

10.3.3.1. Configuration

Please do not disable support for host side usb as this will disable EHCI host interface also. Gadget option in driver mode will appear only when gadget support is also selected. Please enable gadget support as given below.

```
Device Drivers --->
  USB support --->
    <*> USB Gadget Support --->
  [ ] Debugging messages (DEVELOPMENT) NEW
  [ ] Debugging information files (DEVELOPMENT) NEW
  (2) Maximum VBUS power usage (2-500mA) NEW
    USB Peripheral Controller (Inventra HDRC Peripheral(TI, ...))
  --->
    <M> USB Gadget Drivers
    <M> File-backed Storage Gadget
```

Please make sure that Inventra HDRC is selected as USB peripheral controller which will appear only when "USB Peripheral (gadget stack)" is selected in driver mode as shown below.

```
Device Drivers --->
  USB support --->
    <*> Support for Host-side USB
      *** Miscellaneous USB options ***
    [*] USB device filesystem
    [*] USB device class-devices (DEPRECATED)
      *** USB Host Controller Drivers ***
    <*> Inventra Highspeed Dual Role Controller (TI, ...)
      *** OMAP 343x high speed USB support ***
        Driver Mode (USB Peripheral (gadget stack)) --->
  [ ] Disable DMA (always use PIO)
  [*] Use System DMA for Rx endpoints
  [*] Enable debugging messages
```

10.3.4. MUSB OTG controller in OTG mode

10.3.4.1. OTG Configuration

Both Host and Gadget driver should be selected for OTG support. If gadget driver is build as module then the host side module will be initialized only after gadget module is inserted after bootup.

If "Rely on targeted peripheral list" is also selected then make sure to update "drivers/usb/core/otg_whitelist.h" with the desired supported device class identification ids.

OTG option in driver mode will appear only when gadget support is also selected. Please enable gadget support as given below.

```
Device Drivers --->
  USB support --->
    <*> USB Gadget Support --->
    [ ] Debugging messages (DEVELOPMENT) NEW
    [ ] Debugging information files (DEVELOPMENT) NEW
    (2) Maximum VBUS power usage (2-500mA) NEW
    USB Peripheral Controller (Inventra HDRC Peripheral(TI, ...))
    --->
    <M> USB Gadget Drivers
    <M> File-backed Storage Gadget
```

Please make sure that Inventra HDRC is selected as USB peripheral controller which will appear only when OTG is selected as below.

```
Device Drivers --->
  USB support --->
    <*> Support for Host-side USB
    *** Miscellaneous USB options ***
    [*] USB device filesystem
    [*] USB device class-devices (DEPRECATED)
    *** USB Host Controller Drivers ***
    <*> Inventra Highspeed Dual Role Controller (TI, ...)
    *** OMAP 343x high speed USB support ***
    Driver Mode (Both Host and peripheral : USB OTG (On
The Go) Device) --->
    [ ] Disable DMA (always use PIO)
    [*] Use System DMA for Rx endpoints
    [*] Enable debugging messages
```

10.3.5. Host mode applications

10.3.5.1. Mass Storage Driver

This figure illustrates the stack diagram of the system with USB Mass Storage class.




Figure 10.3. USB Driver: Illustration of Mass Storage Class

10.3.6. USB Controller and USB MSC HOST

10.3.6.1. Configuration

```

Device Drivers --->
  SCSI device support --->
    <*> SCSI device support
    [*] legacy /proc/scsi/support
    --- SCSI support type (disk, tape, CD-ROM)
    <*> SCSI disk support
  USB support --->
    <*> Support for Host-side USB
    *** Miscellaneous USB options ***
    [*] USB device filesystem
  
```



```
[*] USB device class-devices (DEPRECATED)
*** USB Host Controller Drivers ***
<*> Inventra Highspeed Dual Role Controller (TI, ...)
    *** OMAP 343x high speed USB support ***
    Driver Mode (USB Host) --->
[ ] Disable DMA (always use PIO)
[*] Use System DMA for Rx endpoints
[*] Enable debugging messages
--- USB Device Class drivers
<*> USB Mass Storage support
```

10.3.6.2. Device nodes

The SCSI sub system creates /dev/sd* devices with help of mdev.

10.3.6.3. Limitations

USB Mass Storage Class gadget devices that do not respond to HS PING command during control transfer will not work with this host controller. Some USB MSC devices from Transcend behave this way (idVendor: 0x0ea0, idProduct: 0x2168 from the USB device descriptor).

10.3.7. USB HID Class

USB Mouse and Keyboards that conform to the USB HID specifications are supported.




Figure 10.4. USB Driver: Illustration of HID Class

10.3.8. USB Controller and USB HID

10.3.8.1. Configuration

```
Device Drivers --->
  USB support --->
    <*> Support for Host-side USB
    *** Miscellaneous USB options ***
    [*] USB device filesystem
    [*] USB device class-devices (DEPRECATED)
    *** USB Host Controller Drivers ***
    <*> Inventra Highspeed Dual Role Controller (TI, ...)
        *** OMAP 343x high speed USB support ***
        Driver Mode (USB Host) --->
        [ ] Disable DMA (always use PIO)
        [*] Use System DMA for Rx endpoints
        [*] Enable debugging messages
  HID Devices --->
    <*> Generic HID Support
        *** USB Input Devices ***
    <*> USB Human Interface Device(full HID) support
```

10.3.8.2. Device nodes

The event sub system creates /dev/input/event* devices with the help of mdev.

10.3.9. USB Audio

10.3.9.1. Configuration

```
Device Drivers --->
  Sound --->
    <*> Sound card support
    Advanced Linux Sound Architecture --->
    <*> Advanced Linux Sound Architecture
    [*] Dynamic device file minor number
    [*] Support old ALSA API
    USB devices --->
    <*> USB Audio/MIDI driver
  USB support --->
    <*> Support for Host-side USB
    *** Miscellaneous USB options ***
    [*] USB device filesystem
    [*] USB device class-devices (DEPRECATED)
    *** USB Host Controller Drivers ***
    <*> Inventra Highspeed Dual Role Controller (TI, ...)
        *** OMAP 343x high speed USB support ***
        Driver Mode (USB Host) --->
```

```
[ ] Disable DMA (always use PIO)
[*] Use System DMA for Rx endpoints
[*] Enable debugging messages
```

10.3.9.2. Resources

For testing USB Audio support we need any ALSA compliant audio player/capture application. Kindly read the Audio driver section to get more inputs on this.

10.3.10. USB Video

10.3.10.1. Configuration

```
Device Drivers --->
Multimedia devices --->
    *** Multimedia core support ***
    <*> Video for Linux
    [*] Enable Video for Linux API 1 (DEPRICATED)
    [*] Enable Video for Linux API 1 (compatible) layer
    *** Multimedia Drivers ***
    [*] Video capture adapters --->
        [*] V4L USB devices --->
            <*> USB Video Class (UVC)
USB Support --->
    <*> Support for Host-side USB
    *** Miscellaneous USB options ***
    [*] USB device filesystem
    [*] USB device class-devices (DEPRECATED)
    *** USB Host Controller Drivers ***
    <*> Inventra Highspeed Dual Role Controller (TI, ...)
        *** OMAP 343x high speed USB support ***
        Driver Mode (USB Host) --->
        [ ] Disable DMA (always use PIO)
        [*] Use System DMA for Rx endpoints
        [*] Enable debugging messages
```

10.3.10.2. Resources


For testing USB Video support we need a user level application like mplayer to stream video from an USB camera.

If you are using mplayer as the capture application, then you must export the DISPLAY to a X server. Then, execute the following command:

```
mplayer tv:// -tv driver=v4l2:width=320:height=240
```

10.3.11. Gadget Mode Applications

File Storage Gadget: This is the Mass storage gadget driver.



10.3.11.1. Configuration

```

Device Drivers --->
  USB support --->
    <*> Support for USB Gadgets
    USB Peripheral Controller (Inventra HDRC Peripheral(TI, ...))
    --->
      <M> USB Gadget Drivers
      <M> File-backed Storage Gadget

    <*> Inventra Highspeed Dual Role Controller (TI, ...)
      *** OMAP 343x high speed USB support ***
      Driver Mode (USB Peripheral (gadget stack)) --->
        [ ] Disable DMA (always use PIO)
        [*] Use System DMA for Rx endpoints
        [*] Enable debugging messages
  
```

10.3.11.2. Installation of File Storage Gadget Driver

Let us assume that we are interested in exposing /dev/mmcblk0 block device to the file storage gadget driver. To that effect we need to issue the following command to load the file storage gadget driver.

```
insmod <g_file_storage.ko> file=/dev/mmcblk0 stall=0
```

10.3.12. CDC/RNDIS gadget

The CDC RNDIS gadget driver that is used to send standard Ethernet frames using USB. Please enable "Use System DMA for Rx endpoints" to fix the flood ping hang issue with packet size of more than 16KB.

10.3.12.1. Configuration for USB controller and CDC/RNDIS Gadget

```
Device Drivers --->
USB support --->
<*> Support for USB Gadgets
USB Peripheral Controller (Inventra HDRC Peripheral (TI, ...))
--->
<M> USB Gadget Drivers
<M> Ethernet Gadget
[*] RNDIS support (EXPERIMENTAL) (NEW)

<*> Inventra Highspeed Dual Role Controller (TI, ...)
    *** OMAP 343x high speed USB support ***
    Driver Mode (USB Peripheral (gadget stack)) --->
[ ] Disable DMA (always use PIO)
[*] Use System DMA for Rx endpoints
[*] Enable debugging messages
```

Please do not select RNDIS support for testing ethernet gadget with Linux 2.4, IXIA and MACOS host machine.

```
USB Peripheral Controller (Inventra HDRC Peripheral (TI, ...))
--->
<M> USB Gadget Drivers
<M> Ethernet Gadget
[ ] RNDIS support (EXPERIMENTAL) (NEW)
```

10.3.12.2. Installation of CDC/RNDIS Gadget Driver

Installing the CDC/RNDIS gadget driver is as follows:

```
$ insmod <path to g_ether.ko>
```

10.3.12.3. Setting up USBNet

The CDC/RNDIS Gadget driver will create a Ethernet device by the name usb0. You need to assign an IP address to the device and bring up the device. The typical command for that would be:

```
$ ifconfig usb0 <IP_ADDR> netmask 255.255.255.0 up
```

For details on usage of USBNet, refer this url. [http://embedded.seattle.intel-research.net/wiki/index.php?title=Setting_up_USBnet]

10.3.13. USB OTG (HNP/SRP) testing

Please choose the configuration as described in driver configuration section for OTG and follow the steps below for testing.

1. Boot the OTG build image on two OMAP35xx EVM.
2. If gadget driver is built as module then insert it to complete USB initialization.
3. Connect mini-A side of the OTG cable to one of the EVM (say EVM-1) and mini-B side on the other (say EVM-2).

In this scenario EVM-1 will become initial host or A-device and EVM-2 will become initial device or B-device. A-device will provide bus power throughout the bus communication even if it becomes peripheral using HNP.

There will not be any connect event at this point of time as Vbus power is not yet switched-on. Vbus power can be switched-on from A-device or from B-device using SRP.

4. Request to switch-on the Vbus power using below command on any EVM.

```
$ echo "F" > /proc/driver/musb_hdrc
```

If this command is executed on B-device then SRP protocol will be used to request A-device to switch-on the Vbus power.

5. Now the connect event occurs, enumeration will complete and gadget driver on B-device will be ready to use if this driver is in "Targeted Peripheral List (TPL)" of A-device.

If TPL is disabled on A-device then gadget driver will be ready to use soon after enumeration.

If TPL is enabled and gadget driver of B-device is not in TPL list of A-device then there will be an automatic trial of HNP from usb core by suspending the bus. This will cause a role switch and B-device will enumerate A-device. Now the gadget driver of A-device will be configured if it is on the TPL list of B-device.

Currently this is the only way possible for HNP testing but we have added a suspend proc entry to start HNP in other than this scenario.

6. Complete all the communication between A-device and B-device.
7. Start HNP by executing below command on host side.

```
$ echo "S" > /proc/driver/musb_hdrc
```

It will suspend the bus and role-switch will follow after that.

8. Repeat step 4,5,6 and 7 for further testing.

10.4. Software Interface

The USB driver exposes its state/control through the sysfs and the procfs interfaces. The following sections talk about these.

10.4.1. sysfs

SYSFS attribute	Description
mode	The entry <code>/sys/devices/platform/musb_hdrc.0/mode</code> is a read-only entry. It will show the state of the OTG (though this feature is not supported) state machine. This will be true even if the driver has been compiled without OTG support. Only the states like A_HOST, B_PERIPHERAL, that makes sense for non-OTG will show up.
vbus	The entry <code>/sys/devices/platform/musb_hdrc.0/vbus</code> is a write-only entry. It is used to set the VBUS timeout value during OTG. If the current OTG state is a_wait_bcon then then urb submission is disabled.

Table 10.1. OMAP3 USB Driver: sysfs attributes

10.4.2. procfs

The procfs entry `/proc/driver/musb_hdrc` is used to control the driver behaviour as well as check the status of the driver.

The following command will show the usage of this proc entry

```
$ echo "?" > /proc/driver/musb_hdrc
```

Specifically the most important usage of this entry would be to start an USB session(host mode) by issuing the following command:

```
$ echo "F" > /proc/driver/musb_hdrc
```


10.5. Revision history

02.00.00 Initial release.

02.01.00 Update for OTG and EHCI support.

MMC Driver

Abstract

Table of Contents

11.1. Introduction	206
11.1.1. References	206
11.1.2. Acronyms & Definitions	206
11.2. Features	207
11.2.1. Features Supported	207
11.2.2. Features Not Supported	207
11.2.3. Limitations	207
11.3. Revision History	208

11.1. Introduction

TI OMAP 35x has an multimedia card high-speed/secure data/secure digital I/O (MMC/SD/SDIO) host controller, which provides an interface between microprocessor and either MMC, SD memory cards, or SDIO cards. The current version of the user guide talks about the MMC/SD controller. The MMC driver is implemented on top of host controller as a HSMMC controller driver and supports MMC, SD, SD High Speed and SDHC cards. The salient features of the aforementioned HSMMC host controller are:

- Full compliance with MMC/SD command/response sets as defined in the Specification.
- Support:
 - 1-bit or 4-bit transfer mode specifications for SD and SDIO cards
 - 1-bit, 4-bit, or 8-bit transfer mode specifications for MMC cards
- Built-in 1024-byte buffer for read or write
- 32-bit-wide access bus to maximize bus throughput
- Single interrupt line for multiple interrupt source events
- Two slave DMA channels (1 for TX, 1 for RX)
- Designed for low power and Programmable clock generation

11.1.1. References

1. MMCA Homepage [<http://www.mmca.org/home>]
2. SD ORG Homepage [<http://www.sdcard.org/home>]

11.1.2. Acronyms & Definitions

Acronym	Definition
MMC	Multimedia card
HSMMC	High Speed MMC
SD	Secure Digital
SDHC	SD High Capacity
SDIO	SD Input/Output

Table 11.1. Acronyms

11.2. Features

11.2.1. Features Supported

The Driver supports the following features:

- The driver is built in-kernel (part of vmlinux).
- MMC cards including High Speed cards.
- SD cards including SD High Speed and SDHC cards.
- Uses block bounce buffer to aggregate scattered blocks

11.2.2. Features Not Supported

The following features are not currently supported by driver:

- SDIO functionality is not supported.
- MMC 8-bit mode is not supported.
- MMC/SD cards cannot be removed while mount operation is in progress. If the card is removed, data integrity cannot be guaranteed.

11.2.3. Limitations

- The driver sometimes reports CRC error during read because of hardware issue.

11.3. Revision History

0.97	Document Created.
02.00.00	Moved to open source kernel version 2.6.26.

Power Management

Abstract

`cpuidle`

Table of Contents

12.1. Introduction	211
12.1.1. References	211
12.2. Features	212
12.2.1. Supported	212
12.2.2. Not Supported	212
12.2.3. Limitations	212
12.3. Architecture	213
12.3.1. <code>cpuidle</code>	213
12.3.2. Dynamic Tick Suppression	215

12.3.3. Suspend & Resume	215
12.4. Configuration	216
12.4.1. cpuidle	216
12.4.2. cpufreq	217
12.4.3. SmartReflex	217
12.5. Software Interface	219
12.5.1. cpuidle	219
12.5.2. Suspend & Resume	220
12.5.3. SmartReflex	220
12.6. Revision History	222

12.1. Introduction

OMAP35x silicon provides a rich set of power management features. These features are described in detail in the OMAP35x TRM.

In summary:

- Clock control at the module and clock domain level.
- 16 power domains i.e. 16 sets of one or more hardware modules sharing same power source.
- Control of scalable voltage domains.
- Independent scaling of OPPs for the VDD1 and VDD2.

MPU and IVA (in case of OMAP3530) share the voltage domain VDD1. Other modules are located in VDD2.

- Support for transitioning power and voltage domains to retention/off and wakeup on event.

12.1.1. References

1. Proceedings of the Linux Symposium, June 27-30, 2007 [<http://ols.108.redhat.com/2007/Reprints/pallipadi-Reprint.pdf>]

Authors: Venkatesh Pallipadi, Shaohua Li, Adam Belay

12.2. Features

The power management features available in this release are based on the proposed PM interface for OMAP. This interface is described in the filename `Documentation/arm/OMAP/omap_pm`.

12.2.1. Supported

This is list of features supported in this release:

- Supports Dynamic Tick framework.
- Supports the *cpuidle* framework with MPU and Core transition to RETENTION and OFF states. The *menu* governor is supported.
- Basic implementation for *cpufreq*.
- Support SmartReflex with automatic (hardware-controlled) mode of operation.

12.2.2. Not Supported

This is list of features not supported in the current release:

- Allow drivers and applications to limit the idle state that can be entered.
- Support for SmartReflex with manual (software-controlled) mode of operation.

12.2.3. Limitations

This is list of limitations that exist in the current release:

- Some of the drivers do not leverage the power-saving features supported by the silicon.

They need to enable/ disable corresponding clocks via `clk_enable()` and `clock_disable()` only when the clocks are *really* needed.

- After the system is suspended, the resume operation does not succeed from the keypad and touchscreen.

12.3. Architecture

12.3.1. cpuidle

The *cpuidle* framework consists of two key components:

- A governor that decides the target C-state of the system.
- A driver that implements the functions to transition to target C-state.

12.3.1.1. System Diagram




Figure 12.1. cpuidle overview

The idle loop is executed when the Linux scheduler has no thread to run. When the idle loop is executed, current 'governor' is called to decide the target C-state. Governor decides whether to continue in current state/transition to a different state. Current 'driver' is called to transition to the selected state.

12.3.1.2. C-states

A C-state is used to identify the power state supported through the cpu idle loop. Each C-state is characterized by its:

- Power consumption
- Wakeup latency
- Preservation of processor state while in 'the' state.

The definition of C-states in the OMAP3 are a combination of the MPU and CORE states. Currently these C-states have been defined:

State	Description
C1	MPU WFI + Core active
C2	MPU WFI + Core inactive
C3	MPU CSWR + Core inactive
C4	MPU OFF + Core inactive
C5	MPU RET + CORE RET
C6	MPU OFF + CORE RET
C7	MPU OFF + CORE OFF

Table 12.1. C-states in OMAP3

12.3.1.3. CPU Idle Governor

The current implementation supports the 'menu' governor to decide the target C-state of the system.

12.3.1.4. CPU Idle Driver

The cpuidle driver registers itself with the framework during boot-up and populates the C-states with exit latency, target residency (minimum period for which the state should be maintained for it to be useful) and flag to check the bus activity.

In ACPI implementation, flag `CPUIDLE_FLAG_CHECK_BM` is used to specify the states requiring bus monitoring interface to be checked. In the OMAP3 implementation, this flag is used to identify the C-states that require CORE domain activity to be checked.

Once the governor has decided the target C-state, the control reaches the function `omap3_enter_idle()`. Here, the C-state is adjusted based on the value of *valid* flag corresponding to the chosen state.



Note

The value of *valid* flag for the idle states relates to `/sys/power/enable_off_mode`. If transition to OFF mode is disabled, the idle states that require MPU to be turned OFF are made *valid*.

12.3.1.5. Performance considerations

Once idle power management is enabled, the system will transition across sleep states of varying latency. This transition can impact the runtime performance of the drivers.

The current implementation does not support any mechanism to prevent the idle state transitions. However, function pair `omap2_block_sleep()` and `omap2_allow_sleep()` can be used to prevent transitions away from the C1 state.

**Important**

Functions `omap2_block_sleep()` and `omap2_allow_sleep()` should be used to protect idle state transition in a controlled and narrow scope - where driver is doing **real** work. Else, power consumption will increase.

12.3.2. Dynamic Tick Suppression

The dynamic tick suppression is achieved through generic Linux framework for the same.

A 32K timer (HZ=128) is used by the tick suppression algorithm.

12.3.3. Suspend & Resume

The suspend operation results in the system transitioning to the lowest power state being supported.

The drivers implement the `suspend()` function defined in the LDM. When the suspend for the system is asserted, the `suspend()` function is called for all drivers. The drivers release the clocks to reach the desired low power state.

The actual transition to suspend is implemented in the function `omap3_pm_suspend()`.

12.4. Configuration

To enable/ disable power management start the *Linux Kernel Configuration* tool.

```
$ make menuconfig
```

Select *Power management options* from the main menu.

```
...
...
Kernel Features --->
Boot options --->
CPU Power Management --->
Floating point emulation --->
Userspace binary formats --->
Power management options --->
[*] Networking support --->
Device Drivers --->
...
...
```

Select *Power Management support* to toggle the power management support.

```
[*] Power Management support
[ ] Power Management Debug Support
[*] Suspend to RAM and standby
< > Advanced Power Management Emulation
```

12.4.1. cpuidle

Start the *Linux Kernel Configuration* tool.

```
$ make menuconfig
```

Select *CPU Power Management* from the main menu.

```
...
...
System Type --->
Bus support --->
```

```
Kernel Features --->
Boot options --->
CPU Power Management --->
Floating point emulation --->
Userspace binary formats --->
...
...
```

Select *CPU idle PM support* to enable the cpuidle driver.

```
[ ] CPU Frequency scaling
[*] CPU idle PM support
```

12.4.2. cpufreq

Start the *Linux Kernel Configuration* tool.

```
$ make menuconfig
```

Select *CPU Power Management* from the main menu.

```
...
...
System Type --->
Bus support --->
Kernel Features --->
Boot options --->
CPU Power Management --->
Floating point emulation --->
Userspace binary formats --->
...
...
```

Select *CPU idle PM support* to enable the cpuidle driver.

```
[*] CPU Frequency scaling
[ ] CPU idle PM support
```

12.4.3. SmartReflex

Start the *Linux Kernel Configuration* tool.

```
$ make menuconfig
```

Select *System Type* from the main menu.

```
...
...
[*] Enable the block layer --->
System Type --->
Bus support --->
Boot options --->
CPU Power Management --->
...
...
```

Select *TI OMAP Implementations* from the menu.

```
ARM system type (TI OMAP) --->
TI OMAP Implementations --->
-- OMAP34xx Based System
--   OMAP3430 support
[*] OMAP35x Family
...
...
```

Select *SmartReflex support* from the menu.

```
...
...
[ ] Emit debug messages from clockdomain layer
[*] SmartReflex support
[ ]   SmartReflex testing support
...
...
```


12.5. Software Interface

The *cpuidle* framework defines a standard interface through */sys* interface.

12.5.1. cpuidle

The parameters controlling *cpuidle* can be viewed via */sys* interface.

```
$ ls -l /sys/devices/system/cpu/cpuidle/  
current_driver  
current_governor_ro  
$
```

current_governor_ro lists the current governor.

```
$ cat /sys/devices/system/cpu/cpuidle/current_governor_ro  
menu  
$
```

current_driver lists the current driver.

```
$ cat /sys/devices/system/cpu/cpuidle/current_driver  
omap3_idle  
$
```

The *cpuidle* interface also exports information about each idle state. This information is organized in a directory corresponding to each idle state.

```
$ ls -l /sys/devices/system/cpu/cpu0/cpuidle  
state0  
state1  
state2  
state3  
state4  
state5  
state6  
$
```

```
$ ls -l /sys/devices/system/cpu/cpu0/cpuidle/state0  
desc  
latency  
name
```

```
power  
time  
usage
```

12.5.1.1. Idle state transition

To allow/prevent the processor to enter idle states, execute these commands:

```
$ echo 1 > /sys/power/sleep_while_idle  
$ echo 0 > /sys/power/sleep_while_idle
```

Some of the clocks are not explicitly enabled and disabled on idle. To allow these clocks to be enabled/ disabled execute these commands:

```
$ echo 1 > /sys/power/clocks_off_while_idle  
$ echo 0 > /sys/power/clocks_off_while_idle
```

To allow/ prevent transition to OFF mode:

```
$ echo 1 > /sys/power/enable_off_mode  
$ echo 0 > /sys/power/enable_off_mode
```

12.5.2. Suspend & Resume

The suspend for device can be asserted as follows:

```
$ echo -n "mem" > /sys/power/state
```

To wakeup, press a key on the OMAP3EVM keypad; or tap any on the serial console.

12.5.3. SmartReflex

To enable/ disable SmartReflex for VDD1:

```
$ echo 1 > /sys/power/sr_vdd1_autocomp  
$ echo 0 > /sys/power/sr_vdd1_autocomp
```

To enable/ disable SmartReflex for VDD2:

```
$ echo 1 > /sys/power/sr_vdd2_autocomp  
$ echo 0 > /sys/power/sr_vdd2_autocomp
```

12.6. Revision History

02.00.00	Initial version for this GIT based release.
----------	---

02.01.00	Updated C-state definition.
----------	-----------------------------

02.01.01	Updated C-state definition.
----------	-----------------------------

	Moved configuration information from DataSheet
--	--

	Release specific updates.
--	---------------------------
