

**DSP/BIOS™ LINK**

**PROCESSOR MANAGER**

**LNK 010 DES**

**Version 1.13**

This page has been intentionally left blank.

---

## **IMPORTANT NOTICE**

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Mailing Address:  
Texas Instruments  
Post Office Box 655303  
Dallas, Texas 75265

Copyright ©. 2003, Texas Instruments Incorporated

This page has been intentionally left blank.

---

**TABLE OF CONTENTS**


---

<b>1</b>	<b>Introduction .....</b>	<b>7</b>
1.1	Purpose and Scope .....	7
1.2	Terms and Abbreviations .....	7
1.3	References .....	7
1.4	Overview .....	8
<b>2</b>	<b>High Level Design .....</b>	<b>9</b>
<b>3</b>	<b>PMGR_PROC .....</b>	<b>11</b>
3.1	Resources Available .....	11
3.2	Dependencies .....	11
3.3	Description .....	11
3.4	Typedefs and Data Structures .....	12
3.5	API Definition .....	14
<b>4</b>	<b>PMGR_CHNL .....</b>	<b>24</b>
4.1	Resources Available .....	24
4.2	Description .....	24
4.3	API Definition .....	25
<b>5</b>	<b>PMGR_CODE .....</b>	<b>35</b>
5.1	Description .....	35
5.2	API Definition .....	36
<b>6</b>	<b>PMGR_PARS .....</b>	<b>39</b>
6.1	Resources Available .....	39
6.2	Description .....	39
6.3	Typedefs and Data Structures .....	40
6.4	API Definition .....	43
<b>7</b>	<b>Different Boot Mode support .....</b>	<b>51</b>
7.1	Resources Available .....	51
7.2	Dependencies .....	51
7.3	Description .....	51
7.4	Decision Analysis & Resolution .....	56
7.5	Decision Analysis & Resolution .....	58
7.6	Typedefs and Data Structures .....	60
<b>8</b>	<b>Appendix .....</b>	<b>64</b>
8.1	Concept of Ownership of Components .....	64
8.2	Future Enhancements .....	64

---

**TABLEOFFIGURES**

---

<b>Figure 1.</b>	Relationship Between the Components in Processor Manager and DSP/BIOS™ Link .....	9
<b>Figure 2.</b>	Components involved in parsing a DSP executable.....	35
<b>Figure 3.</b>	DSPLINK_BOOT_MODE: Default .....	53
<b>Figure 4.</b>	DSPLINK_NOLOAD_MODE: Optimized load .....	54
<b>Figure 5.</b>	DSPLINK_NOBOOT_MODE: Optimized start .....	56

# 1 Introduction

## 1.1 Purpose and Scope

This document describes the overall design and architecture of the Processor Manager layer of the DSP/BIOS™ Link. The initial implementation of Processor Manager is intended for the DSP/BIOS™ LINK on the OMAP running Nucleus.

It lists the interfaces that the PMGR layer exposes and also describes the overall design for implementing these interfaces.

Return values as returned by a function in the document may not reflect all possible values that the function returns.

## 1.2 Terms and Abbreviations

CFG	Configuration sub-component
PMGR_CHNL	Channel sub-component
COFF	Common Object File Format
GPP	General Purpose Processor
LDRV	Link Driver sub-component
LIST	A collection of methods that allow list management.
OMAP	TI's multicore chipset
PGMR	Processor Manager component
PMGR_PARS	Parser sub-component
PMGR_PROC	Processor sub-component
User API	Application Programming Interface exposed by DSP/BIOS™ LINK

## 1.3 References

1	LNK 012 DES	DSP/BIOS™ LINK Link Driver Version 1.11, dated JUL 25, 2003
---	-------------	---

## 1.4 Overview

The Processor Manager forms the layer of DSP/BIOS™ Link that is exported to the user. It provides functionality to both, control the DSP i.e., load code, start the DSP image execution, stop it etc., and transfer the data through the data streams or channels between the GPP and the DSP. The Processor Manager is also responsible for parsing the image file before loading it onto the DSP. It uses the services of the Link Driver to perform the tasks for a user.

The Processor Manager's individual subcomponents implement this policy:


- a. The first client that starts using a resource (PMGR\_PROC/PMGR\_CHNL) is designated as the owner of the resource.
- b. It frees the resource only when the owner releases it.

If the owner frees a resource, the resource is released even if the other clients have not yet released the resource. In such a case, the other clients (if any) are notified about the release of the resource.

## 2 HighLevelDesign

The Processor Manager implements its dual functionality of control and communication with the DSP, using services from the Link Driver and the GPP OS services from the OSAL.

Figure 1 shows the relationship of components in the Processor Manager layer with other components of DSP/BIOS™ Link.



**Figure1.** Relationship Between the Components in Processor Manager and DSP/BIOS™ Link

The PMGR\_PROC subcomponent provides services to control the target DSP and uses services from PMGR\_CODE and LDRV\_PROC sub-components to accomplish its tasks.

The PMGR\_CHNL component provides services for transferring data between the GPP and the DSP and uses the services that the LDRV\_CHNL sub-component provides to accomplish its tasks.

The base image of a DSP is stored in COFF file format. PMGR\_CODE uses the services that PMGR\_PARS provides to parse the image and then loads this file onto the DSP. The PMGR\_PARS sub-component is designed to be capable of understanding multiple COFF formats to support multiple and heterogeneous DSPs through DSP/BIOS™ Link. For this, it uses multiple (possibly plug-able) parsers.

## **3 PMGR\_PROC**

### **3.1 ResourcesAvailable**

This subcomponent uses the services from the `PMGR_CODE` sub-component for parsing base image file and from `LDRV_PROC` for interacting/controlling the target DSP. It also uses `OSAL` for performing the OS dependent tasks in an OS independent manner.

### **3.2 Dependencies**

#### **3.2.1 Subordinates**

`PMGR_CODE`, `LDRV_PROC`

#### **3.2.2 Preconditions**

`PMGR_PROC_Attach()` must be called before any other `PMGR_PROC` and `PMGR_CHNL` APIs are called.

### **3.3 Description**

This subcomponent provides services to start, stop, and initialize a DSP. It also provides services to load a base image onto the target DSP. It maintains a list of clients that are attached to the DSP.

The first client (thread/process) that attaches to a DSP is designated as the owner of that DSP. Any number of clients can subsequently attach to and use the DSP. However, only the owner of the DSP has rights to load a base-image on the DSP and effect transitions in the DSP processor's state.

For example, from Idle to Loaded, Loaded to Started. (Refer to the Link Driver design document for details on the DSP's states).

`PMGR_PROC` releases the resources reserved for controlling the DSP only when the owner detaches from the DSP. Also, when the owner detaches from the DSP, all the other clients of the DSP are also detached and the DSP is in an unusable state i.e., is the 'Idle' state.

## 3.4 TypedefsandDataStructures

### 3.4.1 PMGR\_ClientInfo

An element that holds process info and that can be manipulated using LIST.

#### Definition

```
typedef struct PMGR_ClientInfo_tag {
    ListElement  listElement ;
    PrcsObject  * prcsInfo   ;
} PMGR_ClientInfo ;
```

#### Fields

listElement	Structure that allows it to be used by LIST
prcsInfo	Placeholder for process information

#### Comments

None.

### 3.4.2 PMGR\_PROC\_SetupObj

Object containing information regarding setup of this subcomponent.

#### Definition

```
typedef struct PMGR_PROC_SetupObj_tag {
    Uint32      signature          ;
    PrcsObject  * owner            ;
    SyncCsObject * mutex [MAX_PROCESSORS] ;
} PMGR_PROC_SetupObj ;
```

#### Fields

signature	Signature of this object
owner	Identifier of the owner of the subcomponent.
mutex	Critical section object to ensure mutual exclusion

#### Comments

None.

### 3.4.3 PMGR\_PROC\_Object

Object containing information maintained by this subcomponent.

#### Definition

```
typedef struct PMGR_PROC_Object_tag {
    Uint32      signature ;
    PrcsObject  * owner   ;
    List *      clients   ;
    Uint32      entryPoint ;
} PMGR_PROC_Object ;
```

**Fields**

signature	Signature of this object
owner	The owner of the processor
clients	List of clients that have attached to the processor
entryPoint	Entry point of the executable loaded on target processor

**Comments**

None.

## 3.5 API Definition

### 3.5.1 PMGR\_PROC\_Attach

Attaches the client to the specified DSP and also initializes the DSP (if required). The first caller to this function is designated as the owner of the DSP.

#### Syntax

```
DSP_STATUS PMGR_PROC_Attach (ProcessorId procId,
                             ProcAttr * attr) ;
```

#### Arguments

IN	ProcessorId	procId	
			Specifies the index of processor to attach to
OPT	ProcAttr *	attr	
			Attributes for the processor on which the attach must be done

#### Return Values

DSP_SOK	Operation completed successfully.
DSP_SALREADYATTACHED	Successful attach. Also, indicates that another client has already attached to the DSP.
DSP_EACCESSDENIED	Not allowed to access the DSP
DSP_EFAIL	Unable to attach to processor
DSP_EWRONGSTATE	Incorrect state to the completed requested operation

#### Comments

This function calls `LDRV_PROC_Initialize ()` to initialize the DSP if it is not already initialized. This function maintains a list of client's process/thread IDs (as returned by `PRCS_GetInfo ()`) to keep track of all the clients attached to a target DSP.

#### Constraints

Build options can be specified to exclude `PMGR_CHNL` from the system. Therefore, this function initializes the `PMGR_CHNL` component conditionally.

#### See Also

`PMGR_PROC_Detach`

### 3.5.2 PMGR\_PROC\_Detach

This function allows the client to detach from a DSP and indicates the Processor Manager that the target DSP will not be used any longer.

#### Syntax

```
DSP_STATUS PMGR_PROC_Detach (ProcessorId procId) ;
```

**Arguments**

IN	ProcessorId	procId
	Identifier for the target DSP to be detached from.	

**ReturnValues**

DSP_SOK	Operation completed successfully.
DSP_EFAIL	A failure occurred, unable to detach
DSP_ENOTOWNER	Not the owner of DSP
DSP_EATTACHED	Not attached to the target processor
DSP_EWRONGSTATE	Incorrect state to the completed requested operation

**Comments**

This function removes the caller's process/thread ID information from its list. If the caller is the owner of the target DSP, it releases all resources used for managing the DSP calls `LDRV_PROC_Finalize()`.

**Constraints**

The callers must do a `PMGR_PROC_Attach()` before calling this function.

**SeeAlso**

`PMGR_PROC_Attach`

**3.5.3 PMGR\_PROC\_GetState**

This function obtains the current state of the target DSP.

**Syntax**

```
DSP_STATUS PMGR_PROC_GetState (ProcessorId  procId,
                               ProcState *  procState) ;
```

**Arguments**

IN	ProcessorId	procId
	DSP identifier.	
OUT	ProcState *	ProcState
	Buffer to hold the processor's current state. Link Driver defines this type.	

**ReturnValues**

DSP_SOK	Operation successfully completed.
DSP_EPOINTER	Invalid status buffer

### Comments

This function queries the Link Driver to get the current state of DSP by querying the Link Driver. Since this function does not affect a state change on the DSP, all the clients are allowed to make a call to this function.

### Constraints

The caller must do a `PMGR_PROC_Attach()` before calling this function.

### SeeAlso

`PMGR_PROC_Load`  
`PMGR_PROC_Start`  
`PMGR_PROC_Stop`  
`PMGR_PROC_Idle`

### 3.5.4 PMGR\_PROC\_Load

This function loads the specified base image onto the target DSP.

### Syntax

```
DSP_STATUS PMGR_PROC_Load (ProcessorId  procId,
                           Char8 *      imagePath,
                           Uint32      argc,
                           Char8 **    argv) ;
```

### Arguments

IN	ProcessorId	procId	
			Target DSP identifier where the base image must load.
IN	Char8 *	imagePath	
			Full path to the image file to load on DSP
IN	Uint32	argc	
			Number of argument to pass to the base image upon start
IN	Char8 **	argv	
			Arguments to pass to the DSP main application

### ReturnValues

DSP_SOK	Base image successfully loaded.
DSP_EACCESSDENIED	Not allowed to access the DSP
DSP_EFILE	Invalid base image
DSP_EFAIL	Unable to load image on DSP

### Comments

Loads the specified base image onto the target DSP after ensuring that the caller is the owner of the target DSP. It invokes the services from the `PMGR_CODE` component for parsing the DSP image file, which loads the base image onto the DSP using the

LDRV\_PROC interface. It also retrieves the start address of the base image and stores it in a private structure for future use (to be used in PMGR\_PROC\_Start()).

### Constraints

The caller must do a `PMGR_PROC_Attach()` before calling this function.

### SeeAlso

`PMGR_PROC_Attach`  
`PMGR_PROC_LoadSection`

### 3.5.5 PMGR\_PROC\_LoadSection

This function loads a particular section from the base image file onto the target DSP

### Syntax

```
DSP_STATUS PMGR_PROC_LoadSection (ProcessorId procId,
                                  FileName     imagePath,
                                  Uint32      sectID) ;
```

### Arguments

IN	ProcessorId	procId
	DSP identifier.	
IN	FileName	imagePath
	Full path to the image file	
IN	Uint32	sectID
	Section ID of the section to load.	

### ReturnValues

DSP_SOK	Operation successfully completed
DSP_EFILE	Invalid baseImage parameter
DSP_EINVALIDSECTION	Invalid section name
DSP_EACCESSDENIED	Not allowed to access the DSP
DSP_EFAIL	General failure, unable to load section on DSP

### Comments

This function retrieves the specified section from the base image and loads it onto the target DSP using the services from `PMGR_CODE`

### Constraints

The caller must do a `PMGR_PROC_Attach()` before calling this function.

### SeeAlso

`PMGR_PROC_Attach`  
`PMGR_PROC_Load`

### 3.5.6 PMGR\_PROC\_Start

This function starts the execution of the loaded code on the DSP from the starting point specified in the base image.

#### Syntax

```
DSP_STATUS PMGR_PROC_Start (ProcessorId  procId) ;
```

#### Arguments

IN	ProcessorId	procId
----	-------------	--------

DSP identifier.

#### ReturnValues

DSP_SOK	Operation successfully completed
DSP_SALREATEESTARTED	DSP is already in running state
DSP_EACCESSDENIED	Not allowed to access the DSP
DSP_EFAIL	General failure, unable to start the DSP
DSP_EATTACHED	Client has not attached the to the DSP

#### Comments

This function executes the loaded code on the DSP from the starting point specified in the base image. The function retrieves the start address of the base image when parsing the file (during `PMGR_PROC_Load()`).

#### Constraints

A base image must be loaded onto the target DSP before this call.

The caller must do a `PMGR_PROC_Attach()` before calling this function.

#### SeeAlso

`PMGR_PROC_Attach`  
`PMGR_PROC_Load`  
`PMGR_PROC_Stop`

### 3.5.7 PMGR\_PROC\_Stop

The function stops the execution on the target DSP processor by making a call to `LDRV_PROC_Stop ()`.

#### Syntax

```
DSP_STATUS PMGR_PROC_Stop (ProcessorId  procId) ;
```

#### Arguments

IN	ProcessorId	procId
----	-------------	--------

DSP identifier.

**ReturnValues**

DSP_SOK	Operation successfully completed
DSP_SALREADYSTOPPED	DSP has stopped
DSP_EACCESSDENIED	Not allowed to access the DSP
DSP_EFAIL	General failure, unable to stop the DSP
DSP_EATTACHED	Client has not attached the to the DSP

**Comments**

None.

**Constraints**

The caller must do a `PMGR_PROC_Attach()` before calling this function.

**SeeAlso**

PMGR\_PROC\_Attach  
PMGR\_PROC\_Load  
PMGR\_PROC\_Start

**3.5.8 PMGR\_PROC\_Control**

Provides a hook to perform device dependent control operations.

**Syntax**

```
DSP_STATUS PMGR_PROC_Control (ProcessorId dspId,
                               Int32      cmd,
                               Pvoid      arg) ;
```

**Arguments**

IN	ProcessorId	dspId	Identifier for the DSP
IN	Int32	cmd	Command identifier.
IN	Pvoid	arg	Optional argument

**ReturnValues**

DSP_SOK	Operation completed successfully
DSP_EINVALIDARG	Invalid dspId or dspObj specified

**Comments**

None.

**Constraints**

PMGR\_Initialize () must be called before calling this function.

The DSP must not be in the Error state.

**SeeAlso**

None.

**3.5.9 PMGR\_PROC\_Debug**

This function prints the current status of this component for debugging purposes

**Syntax**

```
Void PMGR_PROC_Debug ();
```

**Arguments**

None.

**ReturnValue**

None.

**Comments**

None.

**Constraints**

None.

**SeeAlso**

PMGR\_PROC\_Attach

**3.5.10 PMGR\_PROC\_Instrument**

Gets the instrumentation data associated with PMGR\_PROC sub-component.

**Syntax**

```
DSP_STATUS PMGR_PROC_Instrument(ProcessorId   procId,  
                                ProcInstrument* retVal);
```

**Arguments**

IN	ProcessorId	procId
----	-------------	--------

Identifier for processor for which instrumentation information is to be obtained.

OUT	ProcInstrument *	retVal
-----	------------------	--------

OUT argument to contain the instrumentation information

**ReturnValues**

DSP_SOK	Operation completed successfully
---------	----------------------------------

DSP_EINVALIDARG	retVal is invalid.
-----------------	--------------------

**Comments**

None.

**Constraints**

`procId` must be valid.

`retVal` must be a valid pointer.

**SeeAlso**

None.

**3.5.11 PMGR\_PROC\_IsAttached**

Function to check whether the client identified by the specified 'client' object is attached to the specified processor.

**Syntax**

```
PMGR_PROC_IsAttached (ProcessorId procId,
                      PrcsObject * client,
                      Bool * isAttached) ;
```

**Arguments**

IN	ProcessorId	<code>procId</code>	Identifier for processor for which instrumentation information is to be obtained.
OUT	PrcsObject *	<code>client</code>	Client identifier.
OUT	Bool *	<code>isAttached</code>	Placeholder for flag indicating the client is attached.

**ReturnValues**

DSP_SOK	Operation completed successfully
DSP_EINVALIDARG	Invalid argument

**Comments**

None.

**Constraints**

`procId` must be valid.

**SeeAlso**

`PMGR_PROC_Attach`

**3.5.12 PMGR\_PROC\_Destroy**

Destroys the data structures for the `PMGR_PROC` component, allocated earlier by a call to `PROC_Setup ()`.

---

**Syntax**

```
Void PMGR_PROC_Destroy ( ) ;
```

**Arguments**

None.

**ReturnValues**

DSP_SOK	Operation completed successfully
DSP_EMEMORY	Operation failed due to memory error.
DSP_EACCESSDENIED	Access denied. Only the client who had successfully called PMGR_PROC_Setup( ) can call this function.
DSP_EFAIL	DSP_EFAIL

**Comments**

None.

**Constraints**

None.

**SeeAlso**

PMGR\_PROC\_Setup

**3.5.13 PMGR\_PROC\_Setup**

Sets up the necessary data structures for the PMGR\_PROC sub-component.

**Syntax**

```
Void PMGR_PROC_Destroy ( ) ;
```

**Arguments**

None.

**ReturnValues**

DSP_SOK	Operation completed successfully
DSP_EMEMORY	Operation failed due to memory error.
DSP_EACCESSDENIED	Access denied. Only the client who had successfully called PMGR_PROC_Setup( ) can call this function
DSP_EFAIL	General failure

**Comments**

None.

**Constraints**

None.

**SeeAlso**

PMGR\_PROC\_Destroy

## **4 PMGR\_CHNL**

### **4.1 ResourcesAvailable**

This component uses the services from the LDRV\_CHNL and OSAL components to achieve its tasks.

#### **4.1.1 Subordinates**

None.

#### **4.1.2 Preconditions**

PMGR\_PROC\_Attach () must be done before making any calls from this component

### **4.2 Description**

This component provides the infrastructure to transfer the data buffers between the DSP and the GPP. The current design restricts the usage of a channel by only one process/thread.

## 4.3 APIDefinition

### 4.3.1 PMGR\_CHNL\_Initialize

Sets up all channel objects in Link Driver.

#### Syntax

```
DSP_STATUS PMGR_CHNL_Initialize (ProcessorId procId) ;
```

#### Arguments

IN	ProcessorId	procId
	Processor ID	

#### ReturnValues

DSP_SOK	Operation completed successfully
DSP_EFAIL	General failure
DSP_EMEMORY	Operation failed due to memory error

#### Comments

This function calls `LDRV_CHNL_Initialize ()` to set up all the channel objects in the Link Driver.

#### Constraints

ProcessorId must be valid.

#### SeeAlso

PMGR\_CHNL\_Finalize  
PMGR\_CHNL\_Create

### 4.3.2 PMGR\_CHNL\_Finalize

Releases all channel objects setup in Link Driver.

#### Syntax

```
DSP_STATUS PMGR_CHNL_Finalize (ProcessorId procId) ;
```

#### Arguments

IN	ProcessorId	procId
	Processor ID	

#### ReturnValues

DSP_SOK	Operation completed successfully
DSP_EFAIL	General failure
DSP_EMEMORY	Operation failed due to memory error

**Comments**

None.

**Constraints**

Channels for specified processor must be initialized. Processor Id must be valid.

**SeeAlso**

PMGR\_CHNL\_Initialize  
PMGR\_CHNL\_Create  
PMGR\_CHNL\_Destroy

**4.3.3 PMGR\_CHNL\_Create**

Creates resources used for transferring data between GPP and DSP.

**Syntax**

```
DSP_STATUS PMGR_CHNL_Create (ProcessorId  procId,
                             ChannelId    chnId,
                             ChnlAttrs *  attrs);
```

**Arguments**

IN	ProcessorId	procId
	Processor ID	
IN	ChannelId	chnId
	Channel ID of channel to create	
IN	ChnlAttrs *	attrs
	Channel attributes, if NULL, default attributes are applied	

**ReturnValues**

DSP_SOK	Operation completed successfully
DSP_EFAIL	General failure
DSP_EMEMORY	Operation failed due to memory error

**Comments**

This function calls LDRV\_CHNL\_Open ( ) and creates the resources for transferring the data between the GPP and the DSP.

**Constraints**

Channels for specified processors must be initialized. Processor and channel ids must be valid. Attributes must be valid.

**SeeAlso**

PMGR\_CHNL\_Initialize

**4.3.4 PMGR\_CHNL\_Delete**

Releases channel resources used for transferring data between GPP and DSP.

**Syntax**

```
DSP_STATUS PMGR_CHNL_Delete (ProcessorId  procId,
                             ChannelId    chnId) ;
```

**Arguments**

IN	ProcessorId	procId
	Processor Identifier	
IN	ChannelId	chnId
	Channel Identifier	

**ReturnValues**

DSP_SOK	Operation completed successfully
DSP_EFAIL	General failure
DSP_EMEMORY	Operation failed due to memory error

**Comments**

None.

**Constraints**

Channels for specified processors must be initialized. Processor and channel ids must be valid.

**SeeAlso**

PMGR\_CHNL\_Create

**4.3.5 PMGR\_CHNL\_AllocateBuffer**

Allocates an array of buffers of specified size and returns them to the client.

**Syntax**

```
DSP_STATUS PMGR_CHNL_AllocateBuffer (ProcessorId  procId,
                                     ChannelId    chnId,
                                     Char8 **     bufArray,
                                     Uint32       size,
                                     Uint32       numBufs);
```

**Arguments**

IN	ProcessorId	procId
	Processor Identifier	
IN	ChannelId	chnId
	Channel Identifier	
OUT	Char8 **	bufArray
	Pointer to receive an array of allocated buffers	

IN	Uint32	size
	Size of each buffer	
IN	Uint32	numBufs
	Number of buffers to allocate	

### ReturnValues

DSP_SOK	Operation completed successfully
DSP_EFAIL	General failure, channel not initialized
DSP_EMEMORY	Operation failed due to memory error

### Comments

None.

### Constraints

Channels for specified processors must be initialized. Processor and channel ids must be valid.

### SeeAlso

PMGR\_CHNL\_Initialize  
PMGR\_CHNL\_Create  
PMGR\_CHNL\_FreeBuffer

### 4.3.6 PMGR\_CHNL\_FreeBuffer

Frees buffer(s) allocated by PMGR\_CHNL\_AllocateBuffer.

### Syntax

```
DSP_STATUS PMGR_CHNL_FreeBuffer (ProcessorId procId,
                                  ChannelId   chnId,
                                  Char8 **    bufArray,
                                  Uint32      numBufs);
```

### Arguments

IN	ProcessorId	procId
	Processor ID	
IN	ChannelId	chnId
	Channel ID	
IN	Char8 **	bufArray
	Pointer to the array of buffers to freed	
IN	Uint32	numBufs
	Number of buffers to be freed	

**ReturnValues**

DSP_SOK	Operation completed successfully
DSP_EFAIL	General failure, channel not initialized
DSP_EMEMORY	Operation failed due to memory error

**Comments**

None.

**Constraints**

Channels for specified processors must be initialized. Processor and channel ids must be valid.

**SeeAlso**

PMGR\_CHNL\_Initialize  
PMGR\_CHNL\_Create  
PMGR\_CHNL\_AllocateBuffer

**4.3.7 PMGR\_CHNL\_Issue**

Issues an input or output request on a specified channel.

**Syntax**

```
DSP_STATUS PMGR_CHNL_Issue (ProcessorId procId,
                             ChannelId   chnId,
                             ChannelIOInfo * ioReq
                             ) ;
```

**Arguments**

IN	ProcessorId	procId	Processor Identifier
IN	ChannelId	chnId	Channel Identifier
IN	ChannelIOInfo *	ioReq	IO request packet

**ReturnValues**

DSP_SOK	Operation completed successfully
DSP_EFAIL	General failure
DSP_EMEMORY	Operation failed due to memory error
DSP_EACCESSDENIED	Not the owner of the channel

**Comments**

This function calls `LDRV_CHNL_AddIORequest()` to queue `ioReq` on the channel.

### Constraints

Channels for specified processors must be initialized. Processor and channel ids must be valid.

### SeeAlso

PMGR\_CHNL\_Reclaim

### 4.3.8 PMGR\_CHNL\_Reclaim

Gets the buffer back that has been issued to this channel

### Syntax

```
DSP_STATUS PMGR_CHNL_Reclaim (ProcessorId      procId,
                               ChannelId        chnId,
                               Uint32           timeout
                               ChannelIOInfo *   ioReq );
```

### Arguments

IN	ProcessorId	procId
	Processor Identifier	
IN	ChannelId	chnId
	Channel Identifier	
IN	Uint32	timeout
	Timeout for this operation	
OUT	ChannelIOInfo *	ioReq
	Information needed for doing reclaim	

### ReturnValues

DSP_SOK	Operation completed successfully
DSP_EFAIL	General failure, channel not initialized
DSP_EMEMORY	Operation failed due to memory error
DSP_EACCESSDENIED	Not the owner of the channel
DSP_ETIMEOUT	Timed out. Waiting for a buffer on channel
CHNL_E_NOIOC	Timeout parameter was "NO_WAIT", yet no I/O completions were queued.

### Comments

This function calls LDRV\_CHNL\_AddIORequest ( ) to queue ioReq on the channel.

### Constraints

Channels for specified processors must be initialized. Processor and channel ids must be valid.

**SeeAlso**

PMGR\_CHNL\_Initialize  
PMGR\_CHNL\_Create  
PMGR\_CHNL\_AllocateBuffer

**4.3.9 PMGR\_CHNL\_Idle**

If the channel is an input stream this function resets the channel and causes any currently buffered input data to be discarded. If the channel is an output channel, this function causes any currently queued buffers to be transferred through the channel. It causes the client to wait for as long as it takes for the data to be transferred through the channel.

**Syntax**

```
DSP_STATUS PMGR_CHNL_Idle (ProcessorId  procId,
                           ChannelId    chnId) ;
```

**Arguments**

IN	ProcessorId	procId
	Processor ID	
IN	ChannelId	chnId
	Channel ID	

**ReturnValues**

DSP_SOK	Operation completed successfully
DSP_EFAIL	General failure, channel not initialized
DSP_EMEMORY	Operation failed due to memory error
DSP_EACCESSDENIED	Not the owner of the channel
DSP_ETIMEOUT	Time out occurred before the channel could be idled

**Comments**

None.

**Constraints**

Channels for specified processor must be initialized. Processor and channel ids must be valid.

**SeeAlso**

PMGR\_CHNL\_Initialize  
PMGR\_CHNL\_Create

**4.3.10 PMGR\_CHNL\_Flush**

Discards all the requested buffers that are pending for transfer both in case of input mode channel as well as output mode channel. One must still have to call the PMGR\_CHNL\_Reclaim to get back the discarded buffers.

**Syntax**

```
DSP_STATUS PMGR_CHNL_Flush (ProcessorId  procId,
                             ChannelId     chnId) ;
```

**Arguments**

IN	ProcessorId	procId
	Processor Identifier	
IN	ChannelId	chnId
	Channel Identifier	

**ReturnValues**

DSP_SOK	Operation completed successfully
DSP_EFAIL	General failure, channel not initialized
DSP_EMEMORY	Operation failed due to memory error

**Comments**

None.

**Constraints**

Channels for specified processor must be initialized. Processor and channel ids must be valid.

**SeeAlso**

PMGR\_CHNL\_Initialize  
PMGR\_CHNL\_Create  
PMGR\_CHNL\_Issue

**4.3.11 PMGR\_CHNL\_Control**

Provides a hook to perform device dependent control operations on channels.

**Syntax**

```
DSP_STATUS PMGR_CHNL_Control (ProcessorId  procId,
                              ChannelId     chnId,
                              Int32         cmd,
                              Pvoid         arg) ;
```

**Arguments**

IN	ProcessorId	procId
	Processor Identifier	
IN	ChannelId	chnId
	Channel Identifier	
IN	Int32	cmd
	Command id.	



**Arguments**

IN	ProcessorId	procId	
	Identifier for processor		
IN	ChannelId	chnlId	
	Identifier for channel for which instrumentation information is to be obtained		
OUT	ChnlInstrument *	retVal	
	OUT argument to contain the instrumentation information		

**ReturnValues**

DSP_SOK	Operation completed successfully.
DSP_EINVALIDARG	retVal is invalid.

**Comments**

This function provides a hook to perform the device dependent control operations on channels. Not implemented in current implementation.

**Constraints**

retVal must be a valid pointer

**SeeAlso**


None.

## 5 PMGR\_CODE

### 5.1 Description

This component provides the COFF file parsing services to the DSP/BIOS™ Link. Link is designed to support heterogeneous DSPs and therefore this component creates different parser objects to handle this scenario.

Based on the CFG information of Link, `PMGR_CODE` modifies itself and can load parsers for different file formats. A call to `PMGR_CODE_LoadExecutable()` results in multiple calls to the `PMGR_PARS` sub-component functions. These functions in turn load the data into format independent structures that are used while loading the image onto the DSP.



**Figure2.** ComponentsinvolvedinparsingaDSPexecutable.

## 5.2 APIDefinition

### 5.2.1 PMGR\_CODE\_LoadExecutable

Uses interfaces provided in ParserObj to parse the COFF file and load it onto DSP.

#### Syntax

```
DSP_STATUS PMGR_CODE_LoadExecutable (ProcessorId  procId,
                                     FileName     baseImage,
                                     Uint32      argc,
                                     Char8 **    argv,
                                     Uint32 *    entryAddress) ;
```

#### Arguments

IN	ProcessorId	procId	Target DSP identifier where the base image is to load
IN	FileName	baseImage	File identifier for the base image
IN	Uint32	argc	Number of arguments to pass to the base image upon start
IN	Char8 **	argv	Arguments to pass to the DSP main application.
OUT	Uint32 *	entryAddress	OUT argument for returning entry address for the executable

#### ReturnValues

DSP_SOK	Base image successfully loaded
DSP_EFILE	Invalid base image
DSP_EACCESSDENIED	Not allowed to access the DSP
DSP_EFAIL	General failure, unable to load image onto DSP
DSP_EINVALIDARG	Invalid procId argument.

#### Comments

None.

#### Constraints

- procId must be a valid DSP processor ID.
- baseImage must be a valid file identifier.
- entryAddress must be a valid section identifier.

**SeeAlso**

PMGR\_PROC\_Load

**5.2.2 PMGR\_CODE\_LoadSection**

Uses interfaces provided in ParserObj to parse the COFF file and load it onto DSP.

**Syntax**

```
DSP_STATUS PMGR_CODE_LoadSection (ProcessorId  procId,
                                   fileId *      baseImage,
                                   Uint32       sectId) ;
```

**Arguments**

IN	ProcessorId	procId
	DSP identifier	
IN	FileId *	baseImage
	Full path to the image file.	
IN	Uint32	sectId
	Identifier for the section to load	

**ReturnValues**

DSP_SOK	Operation successfully completed
DSP_EFILE	Invalid base image
DSP_EACCESSDENIED	Not allowed to access the DSP
DSP_EFAIL	General failure, unable to load image onto DSP
DSP_EINVALIDARG	Invalid procId argument.
DSP_EINVALIDSECT	Invalid section name

**Comments**

None.

**Constraints**

procId must be a valid DSP processor ID.

baseImage must be a valid file identifier.

sectId must be a valid section identifier.

**SeeAlso**

PMGR\_PROC\_Load

**5.2.3 PMGR\_CODE\_Debug**

This function prints the current status of the PMGR\_CODE sub-component.

**Syntax**

```
Void PMGR_CODE_Debug ( ) ;
```

**Arguments**

None.

**ReturnValue**

None.

**Comments**

None.

**Constraints**

None.

**SeeAlso**

None.

## **6 PMGR\_PARS**

### **6.1 ResourcesAvailable**

This subcomponent uses services from the parser to get image data in format dependent structures.

#### **6.1.1 Subordinates**

None.

#### **6.1.2 Preconditions**

None.

### **6.2 Description**

This subcomponent provides the `PMGR_CODE` subcomponent with image data in format independent structures to use while loading the image onto the DSP.

## 6.3 TypedefsandDataStructures

### 6.3.1 ImageAttributes

This structure defines a format agnostic definition of attributes that a parser requires.

#### Definition

```
typedef struct ImageAttributes_tag {
    Uint16    version        ;
    Uint16    numSections    ;
    Int32     symTabOffset   ;
    Int32     numSymTabEntries ;
    Uint16    numBytesOptHeader ;
    Uint16    flags         ;
    Uint16    targetId      ;
} ImageAttributes ;
```

#### Fields

<code>version</code>	The version of the file format
<code>numSections</code>	Number of sections in a file
<code>symTabOffset</code>	Symbol table offset in a file
<code>numSymTabEntries</code>	Number of symbol table entries in a file
<code>numBytesOptHeader</code>	Number of bytes in the optional header
<code>flags</code>	Flags associated with the file format
<code>targetId</code>	Target of the DSP base image file

### 6.3.2 OptImageAttributes

Structure defining a format agnostic definition of optional attributes required from a parser. This structure is a placeholder for optional attributes associated with file. These attributes could be useful in debugging.

#### Definition

```
typedef struct OptImageAttributes_tag {
    Int32     dummy ;
} OptImageAttributes ;
```

#### Fields

<code>dummy</code>	Dummy parameter (unused)
--------------------	--------------------------

### 6.3.3 SectionAttributes

Structure defining a format agnostic definition of section related attributes required from a parser.

#### Definition

```
typedef struct SectionAttributes_tag {
    Char8 * name ;
}
```

```

    Uint32  index      ;
    Uint32  size       ;
    Uint32  sectOffset ;
    Uint32  loadAddr   ;
    Uint32  runAddr    ;
    Bool    isLoadSection ;
    Char8 * data       ;
} SectionAttributes ;

```

### Fields

name	Name of the section
index	Index of the section in the DSP base image file
size	Size of the section data in bytes
sectOffset	Offset of the section data in a file
loadAddr	Load address of the section data
runAddr	Run address of the section
isLoadSection	Flag to indicate that the section is loadable
data	Buffer to hold data

### 6.3.4 SymbolAttrs

This structure defines the format agnostic definition of symbols and their attributes.

#### Definition

```

typedef struct SymbolAttrs_tag {
    Uint32  symIndex ;
    Char8 * name     ;
    Uint32  addr     ;
} SymbolAttrs ;

```

### Fields

symIndex	Index of the symbol in the symbol table
name	Name of the symbol
addr	Address of the symbol

### 6.3.5 ParserContext

This structure defines the context of parser. This object is created on initialization of this sub-component and it is required to be passed as a parameter for any subsequent function call.

#### Definition

```

typedef struct ParserContext_tag {
    KFileObject *   fileObj ;
    ProcessorId     procId  ;
}

```

---

```
    Uint32          startAddr  ;
    ImageAttributes *  attrs    ;
    OptImageAttributes * optAttrs ;
    Uint32          numSymbols ;
    SymbolAttrs *    symbols   ;
} ParserContext ;
```

**Fields**

fileObj	File object for the DSP base image file
procId	Processor identifier
startAddr	Entry point address for the DSP base image file
attrs	Attributes associated with the DSP base image file
optAttrs	Optional attributes associated with the DSP base image file
numSymbols	Number of symbols in the DSP base image file
symbols	Symbol table containing all the symbols from the DSP base image file

## 6.4 APIDefinition

### 6.4.1 PMGR\_PARS\_Initialize

Initializes a base image file for parsing. This function is required to be called before any other function is called from this sub-component.

#### Syntax

```
DSP_STATUS PMGR_PARS_Initialize (ProcessorId  procId,
                                FileName      file,
                                Void **      obj) ;
```

#### Arguments

IN	ProcessorId	procId
----	-------------	--------

Processor Id

IN	FileName	file
----	----------	------

Identifier for the file.

OUT	Void **	obj
-----	---------	-----

OUT argument that contains the object to be passed in any subsequent call from this subcomponent.

#### ReturnValues

DSP_SOK	Operation completed successfully
---------	----------------------------------

DSP_EMEMORY	Memory error
-------------	--------------

#### Comments

None.

#### Constraints

file must be valid.

#### SeeAlso

PMGR\_PARS\_Finalize

### 6.4.2 PMGR\_PARS\_Finalize

This function releases the context object obtained through PMGR\_PARS\_Initialize.

#### Syntax

```
DSP_STATUS PMGR_PARS_Finalize (Pvoid  objCtx) ;
```

#### Arguments

IN	Pvoid	objCtx
----	-------	--------

The context object that PMGR\_PARS\_Initialize() obtains

**ReturnValues**

DSP_SOK	Operation completed successfully
DSP_EMEMORY	Operation failed due to memory error

**Comments**

None.

**Constraints**

objCtx must be valid.

**SeeAlso**

PMGR\_PARS\_Initialize

**6.4.3 PMGR\_PARS\_GetImageAttributes**

This function gets the attributes for a particular base image file.

**Syntax**

```
DSP_STATUS PMGR_PARS_GetImageAttributes (Pvoid          objCtx,
                                         ImageAttributes ** attrs);
```

**Arguments**

IN	Pvoid	objCtx
		The context object that PMGR_PARS_Initialize () obtains
OUT	ImageAttributes **	attrs
		Required attributes associated with the DSP base image file

**ReturnValues**

DSP_SOK	Operation completed successfully
DSP_EFILE	File format not supported
DSP_ERANGE	File seek operation failed
DSP_EMEMORY	Operation failed due to memory error
DSP_EINVALIDARG	Invalid arguments

**Comments**

None.

**Constraints**

objCtx must be valid..

**SeeAlso**

PMGR\_PARS\_Initialize

#### 6.4.4 PMGR\_PARS\_GetOptImageAttributes

This function gets the optional attributes for a particular base image file.

##### Syntax

```
DSP_STATUS
PMGR_PARS_GetOptImageAttributes (Pvoid          objCtx,
                                 OptImageAttributes ** optattrs) ;
```

##### Arguments

IN	Pvoid	objCtx	
			The context object that PMGR_PARS_Initialize () obtains
OUT	OptImageAttributes **	optattrs	
			Optional attributes associated with the DSP base image file

##### ReturnValues

DSP_SOK	Operation completed successfully
DSP_EFILE	File format not supported
DSP_ERANGE	File seek operation failed
DSP_EMEMORY	Operation failed due to memory error
DSP_EINVALIDARG	Invalid arguments

##### Comments

None.

##### Constraints

objCtx must be valid.

##### SeeAlso

PMGR\_PARS\_Initialize

#### 6.4.5 PMGR\_PARS\_GetEntryAddress

Gets the entry address for a particular base image file

##### Syntax

```
DSP_STATUS PMGR_PARS_GetEntryAddress (Pvoid      objCtx,
                                       Uint32 *  addr) ;
```

##### Arguments

IN	Pvoid	objCtx	
			The context object obtained through PMGR_PARS_Initialize ()
OUT	Uint32 *	addr	
			OUT argument containing the entry address for the base address

**ReturnValues**

DSP_SOK	Operation completed successfully
DSP_EFILE	File format not supported
DSP_ERANGE	File seek operation failed
DSP_EMEMORY	Operation failed due to memory error
DSP_EINVALIDARG	Invalid arguments

**Comments**

None.

**Constraints**

objCtx must be valid.

**SeeAlso**

PMGR\_PARS\_Initialize

**6.4.6 PMGR\_PARS\_GetSymbolAddress**

This function gets the address of a particular symbol.

**Syntax**

```
DSP_STATUS PMGR_PARS_GetEntryAddress (Pvoid    objCtx,
                                       Char8 *  symName,
                                       Uint32 *  addr) ;
```

**Arguments**

IN	Pvoid	objCtx	
			The context object that PMGR_PARS_Initialize () obtains
IN	Char8 *	symName	
			Name of the symbol
OUT	Uint32 *	addr	
			OUT argument containing the entry address for the base address

**ReturnValues**

DSP_SOK	Operation completed successfully
DSP_EFILE	File format not supported
DSP_ERANGE	File seek operation failed
DSP_EMEMORY	Operation failed due to memory error
DSP_EINVALIDARG	Invalid arguments

**Comments**

None.

**Constraints**

`objCtx` must be valid.  
`symName` must be valid.

**SeeAlso**

`PMGR_PARS_Initialize`

**6.4.7 PMGR\_PARS\_GetSectionAttributes**

Gets the attributes associated with a section. Memory for holding the section attributes must be allocated by the caller.

**Syntax**

```
DSP_STATUS PMGR_PARS_GetEntryAddress(Pvoid          objCtx,
                                     Uint32         sectIndex,
                                     SectionAttributes* sectAttrs);
```

**Arguments**

IN	Pvoid	<code>objCtx</code>
		The context object that <code>PMGR_PARS_Initialize ()</code> obtains
IN	Uint32	<code>sectIndex</code>
		Index of the section
OUT	SectionAttributes *	<code>sectAttrs</code>
		OUT argument containing the attributes associated with a section

**ReturnValues**

<code>DSP_SOK</code>	Operation completed successfully
<code>DSP_EFILE</code>	File format not supported
<code>DSP_ERANGE</code>	File seek operation failed
<code>DSP_EMEMORY</code>	Operation failed due to memory error
<code>DSP_EINVALIDARG</code>	Invalid arguments

**Comments**

None.

**Constraints**

`objCtx` must be valid pointer.  
`sectAttrs` must be a valid pointer.  
The data field in `sectAttrs` must be a valid buffer.

**SeeAlso**

PMGR\_PARS\_Initialize  
PMGR\_PARS\_GetSectionAttributes

**6.4.8 PMGR\_PARS\_GetSectionData**

This function gets the data for a section.

**Syntax**

```
DSP_STATUS PMGR_PARS_GetSectionData (Pvoid objCtx,
                                     SectionAttributes * sectAttrs) ;
```

**Arguments**

IN	Pvoid	objCtx
		The context object through PMGR_PARS_Initialize
IN OUT	SectionAttributes *	sectAttrs
		IN OUT argument containing the section attributes with section data

**ReturnValues**

DSP_SOK	Operation completed successfully
DSP_EFILE	File format not supported
DSP_ERANGE	File seek operation failed
DSP_EMEMORY	Operation failed due to memory error
DSP_EINVALIDARG	Invalid arguments

**Comments**

None.

**Constraints**

objCtx must be valid pointer.  
sectAttrs must be a valid pointer.  
The data field in sectAttrs must be a valid buffer.

**SeeAlso**

PMGR\_PARS\_Initialize  
PMGR\_PARS\_GetSectionAttributes

**6.4.9 PMGR\_PARS\_Debug**

This function prints the current status of the PMGR\_PARS component.

**Syntax**

```
Void PMGR_PARS_Debug () ;
```

**Arguments**

None.

**ReturnValue**

None.

**Comments**

None.

**Constraints**

None.

**SeeAlso**

None.

**6.4.10 PMGR\_PARS\_FillArgsBuffer**

Fills up the data-buffer with the specified arguments to be sent to DSP's "main" function.

**Syntax**

```
PMGR_PARS_FillArgsBuffer (ProcessorId      procId,
                          Uint32          argc,
                          Char8 **        argv,
                          SectionAttributes * sectAttrs) ;
```

**Arguments**

IN	ProcessorId	procId
	Processor Identifier	
IN OUT	SectionAttributes *	sectAttrs
	Attributes of the ".args" section	
IN	Uint32	argc
	Number of arguments to be passed	
IN	Char8 **	argv
	Argument strings to be passed.	

**ReturnValues**

DSP_SOK	Operation completed successfully
DSP_ESIZE	Insufficient space in .args buffer to hold all the arguments
DSP_EMEMORY	Operation failed due to memory error.

**Comments**

None.

**Constraints**

`ProcessorId` must be valid.  
`argc` must be more than 0.  
`argv` must be valid pointer.  
`sectAttrs` must be a valid pointer.

**SeeAlso**

None.

## 7 DifferentBootModesupport

DSPLink PROC module needs to support three different scenarios for DSP boot-loading:

- DSPLINK\_BOOT\_MODE: Default
- DSPLINK\_NOLOAD\_MODE: Optimized load
  - DSPLINK\_NOLOAD\_MODE which powers up the DSP
  - DSPLINK\_NOLOAD\_MODE which does not power up the DSP
- DSPLINK\_NOBOOT\_MODE: Optimized start

### 7.1 ResourcesAvailable

DSPLink configuration will provide the details regarding which boot mode application is currently using.

These details include the DSP control mode and the loader to be used.

### 7.2 Dependencies

#### 7.2.1 Subordinates

Linkcfgdefs, DSP module

#### 7.2.2 Preconditions

- Application will call PROC\_load and PROC\_start for all boot modes.
- The DSPLink configuration will provide the details regarding which boot mode application is currently using. These details include the DSP control mode and the loader to be used.

### 7.3 Description

DSPLink PROC module needs to support three different scenarios for DSP boot-loading:

- DSPLINK\_BOOT\_MODE: Default
  - GPP boots first
  - Uses DSPLink to load the DSP
  - Uses DSPLink to start the DSP running
- DSPLINK\_NOLOAD\_MODE: Optimized load
  - GPP boots first
  - Application/GPP boot-loader pre-loads the DSP
  - Uses DSPLink to optionally power up the DSP
  - Uses DSPLink to start the DSP running
- DSPLINK\_NOBOOT\_MODE: Optimized start: Two situations:
  - GPP-based load
  - GPP boots first
  - Application/GPP boot-loader pre-loads the DSP

- Application/GPP boot-loader starts the DSP running
- Uses DSPLink only for IPC with the DSP

OR

- DSP-based load
- DSP boots first, starts running an application.
- Then ARM comes up later and initializes shared memory
- DSPLink is not used to load or start the DSP
- Uses DSPLink only for IPC with the DSP

### **7.3.1 DSPLINK\_BOOT\_MODE:Default**

This is the default boot mode presently supported within DSPLink. In this boot mode:

- GPP boots first
- Uses DSPLink PROC\_attach API to reset and power up the DSP
- Uses DSPLink PROC\_load API to load the DSP and get the address of c\_int00 from the COFF file
- Uses DSPLink PROC\_start API to release the DSP from reset and start DSP running from c\_int00
- Uses DSPLink PROC\_detach API to reset and power down the DSP




Figure3. DSPLINK\_BOOT\_MODE:Default

### 7.3.2 DSPLINK\_NOLOAD\_MODE:Optimizedload

This is the requirement for a new boot mode support to be added in DSPLink.

- DSPLINK\_NOLOAD\_MODE: Optimized load
  - GPP boots first
  - Application/GPP boot-loader pre-loads the DSP i.e. external non DSPLink entity loads the COFF in DSP memory. The Application/GPP boot-loader must put DSP in reset to avoid DSP to start running.
  - Uses DSPLink PROC\_attach API. This API will always reset the DSP and optionally power up the DSP depending upon configuration specified by the application.
  - Uses DSPLink PROC\_load API with a dummy loader. The application will provide the entry point c\_int00 as parameter to PROC\_load.
  - Uses DSPLink PROC\_start API to release the DSP from reset and start DSP running from c\_int00.
  - Uses DSPLink PROC\_detach API. This API will always reset the DSP and optionally power down the DSP depending upon configuration specified by the application.

- Second run of DSPLink without rebooting the board or re-running application/GPP boot loader is not possible




Figure4. DSPLINK\_NOLOAD\_MODE:Optimizedload

### 7.3.3 DSPLINK\_NOBOOT\_MODE:Optimizedstart

This is the requirement for a new boot mode support to be added in DSPLink.

- DSPLINK\_NOBOOT\_MODE: Optimized start: Two situations:
  - GPP-based load
  - GPP boots first
  - Application/GPP boot-loader pre-loads the DSP
  - Application/GPP boot-loader starts the DSP running
  - Uses DSPLink PROC\_attach API. This API will not reset and power up the DSP as the Application/GPP boot-loader has already done that.
  - Uses DSPLink PROC\_load API with a dummy loader. The application will provide the entry point c\_int00 as parameter to PROC\_load. This is a dummy parameter as it is not needed.

- Uses DSPLink PROC\_start API. This API will do handshake with DSP to ensure compatibility of both sides. It will also send an interrupt to DSP indicating GPP start.
  - Uses DSPLink PROC\_detach API. This API will not reset and power down the DSP.
  - Second run of DSPLink without rebooting the board or re-running application/GPP boot loader is not possible
  - Uses DSPLink only for IPC with the DSP
- OR
- DSP-based load
  - DSP boots first, starts running an application.
  - Uses DSPLink PROC\_attach API. This API will not reset and power up the DSP as the Application/DSP boot-loader has already done that.
  - Uses DSPLink PROC\_load API with a dummy loader. The application will provide the entry point c\_int00 as parameter to PROC\_load. This is a dummy parameter as it is not needed.
  - Uses DSPLink PROC\_start API. This API will do handshake with DSP to ensure compatibility of both sides. It will also send an interrupt to DSP indicating GPP start.
  - Uses DSPLink PROC\_detach API. This API will not reset and power down the DSP.
  - Second run of DSPLink without rebooting the board or re-running application/DSP boot loader is not possible
  - Uses DSPLink only for IPC with the DSP

DSPLink will support both polling of DSP side executable on non NULL value of DSPLINK\_shmBaseAddress as an entry guarantee to call DSPLINK\_init from the task.

DSPLink will also send an interrupt to the DSP in PROC\_start. This will enable a non polling dynamic method where DSP will register an ISR. This ISR will post a semaphore which will waken the task which will call DSPLINK\_init.




Figure 5. DSPLINK\_NOBOOT\_MODE: Optimized start

## 7.4 Decision Analysis & Resolution

There are two options for boot modes support design.

### 7.4.1 DAR Criteria

1. Meets customer needs
2. Consistency with existing DSPLink design and implementation
3. Ease of use

### 7.4.2 Available Alternatives

1. Dynamic configuration of DSPLink with application calling PROC\_load and PROC\_start API for all boot modes.
2. Application will make API calls only as per boot mode requirements. Add new API called PROC\_join for DSPLINK\_NOBOOT\_MODE.

7.4.2.1 *Dynamic configuration of DSPLink with application calling PROC\_load and PROC\_start API for all boot modes.*

#### Summary:

- Applications will call PROC\_load and PROC\_start regardless of boot mode.
- Dynamic configuration of DSPLink using application configuration file will decide loader type and DSP control level.
- Depending on value of DSP control variable, extent of functionality of PROC\_load and PROC\_start will be decided.

**Advantages:**

1. Backward compatibility for application regarding PROC API calls will be maintained. Application will not need to call separate API's for separate boot mode.
2. Configuration provides all boot mode related information required by DSPLink.

**Disadvantages:**

1. GPP side application rebuild will be required to take the value of the DSP control and the type of loader. These changes will be in \$DSPLINK/config/all/<CFG\_platform.c> i.e. the application configuration file DOPOWERCTRL and LOADERNAME fields in the LINKCFG\_Dsp structure.
  - This can be mitigated by using the following approach.
  - Application can decide at run time which boot mode will be used. This could be a run time parameter: For e.g. ./app default or ./app no\_load
  - Application will link in three separate \$DSPLINK/config/all/<CFG\_platform.c> i.e. the application configuration files. Namely CFG\_default.c, CFG\_noload.c, CFG\_noboot.c with relevant DOPOWERCTRL and LOADERNAME fields in the LINKCFG\_Dsp structures in each file at build time.
  - Depending upon the value of the boot mode, PROC\_setup can be called with the bootmode specific LINKCFG\_config structure.
  - Since all configurations are linked in, no application side rebuild will be required to switch between the boot modes.

7.4.2.2 *Application will make API calls only as per boot mode requirements. Add new API called PROC\_joinforDSPLINK\_NOBOOT\_MODE.*

Summary:

1. Application will not call PROC\_load in DSPLINK\_NOLOAD\_MODE.
2. Application will not call PROC\_load and PROC\_start in DSPLINK\_NOBOOT\_MODE since there is no need to call PROC\_load if DSP does not need to be loaded and No need to call PROC\_start if DSP does not need to be started etc.
3. No need to change DSPLink configuration for loader type or DSP control values.

Advantages:

1. The applications needs to only make API calls as per their requirements, and this gives a more logical flow for application writers.

Disadvantages:

1. The following DSPLink requirements are not supported:
  - In DSPLINK\_NO\_LOAD\_MODE: PROC\_load is needed to be called to give the entry point (c\_int00) for PROC\_start to succeed.

- In DSPLINK\_NOBOOT\_MODE: PROC\_start is needed to be called to complete GPP and DSP handshake.
- Calling PROC\_join API does not give complete DSP control information to DSPLink as reset of DSP happens earlier in DSPLink startup sequence in PROC\_attach itself.
- DSPLink configuration related changes are needed anyway.

#### 7.4.3 Decision

Alternative 1 has been chosen based on the advantages and disadvantages listed for each approach.

### 7.5 Decision Analysis & Resolution

There are two options for enhanced COFF loader for DSPLINK\_BOOT\_MODE.

The goal is to reduce coff load time by replacing file operations by memory copy operations

#### 7.5.1 DARC Criteria

1. Meets customer needs
2. Consistency with existing DSPLink design and implementation
3. Ease of use

#### 7.5.2 Available Alternatives

1. Use application provided user space buffer. Use this buffer for PROC\_load. PROC\_load internally replicates the user space buffer in kernel and uses that for enhanced memory based COFF load operations
2. Use POOL\_alloc to get a user space buffer. Use this buffer for PROC\_load.

7.5.2.1 *Use application provided user space buffer. Use this buffer for PROC\_load. PROC\_load internally replicates the user space buffer in kernel and uses that for enhanced memory based COFF load operations.*

Application will call:

- Application specific memory allocation calls to get user space buffer. (non DSPLink operation)
- Application must fill user space buffer with COFF data by performing DMA from ROM to SDRAM (non DSPLink operation)
- Application will use default boot mode i.e. both PROC\_load and PROC\_start will be called.
- Application will change loader type which is dynamically configurable through application configuration file to COFF\_MEM
- Application will pass user space address of buffer as parameter to PROC\_load
- PROC\_load will internally replicate user space buffer in kernel space and use it for COFF memory operations
- After PROC\_load, user can delete the user space buffer. (non DSPLink operation)
- Normal IPC using DSPLink can begin after PROC\_start

#### Advantages:

None

---

**Disadvantages:**

- Application will have to write driver to perform address translation etc

7.5.2.2 *UsePOOL\_alloc to get userspace buffer. Use this buffer for PROC\_load.*

Application will call:

- Application will use default boot mode i.e. both PROC\_load and PROC\_start will be called.
- Application will change loader type which is dynamically configurable through application configuration file to COFF\_MEM
- POOL\_alloc to allocate user space buffer (DSPLink API)
- POOL\_translateAddr to get DSP physical address to perform DMA from ROM to SDRAM and fill buffer with COFF data (DSPLink API)
- POOL\_translateAddr to get kernel virtual address of user space buffer (DSPLink API)
- PROC\_load will be called with kernel virtual address in the second parameter i.e. a structure instead of the imagepath
- Internally PROC\_load implementation will use enhanced COFF loader which does a memory operation instead of file operation
- Normal IPC using DSPLink can begin after PROC\_start

**Advantages:**

- Usage of DSPLink API to get all information including physical address/kernel virtual address.

**Disadvantages:**

- Since POOL is non cached memory it will result in performance degradation. This can be avoided by remapping same area as cached.

**7.5.3 Decision**

Alternative 2 has been chosen based on the advantages and disadvantages listed for each approach.

## 7.6 TypedefsandDataStructures

### 7.6.1 LINKCFG\_Dsp

This structure defines the configuration structure for the DSP.

#### Definition

```
typedef struct LINKCFG_Dsp_tag {
    Char8          name [DSP_MAX_STRLEN] ;
    Uint32         dspArch ;
    Char8          loaderName [DSP_MAX_STRLEN] ;
    Bool          autoStart;
    Char8          execName [DSP_MAX_STRLEN] ;
    enum          doDspCtrl ;
    Uint32         resumeAddr ;
    Uint32         resetVector;
    Uint32         resetCodeSize ;
    Uint32         maduSize;
    Uint32         cpuFreq ;
    Uint32         endian ;
    Uint32         wordSwap ;
    Uint32         memTableId;
    Uint32         memEntries ;
    Uint32         memEntries;
} LINKCFG_Dsp ;
```

#### Fields

Name	Name of DSP processor.
dspArch	Architecture of the DSP.
loaderName	Name of loader to be used for loading the DSP executable.
autoStart	AutoStart flag indicating whether a default DSP image should be loaded on startup. Currently not supported.
execName	Name of executable to load in case autostart is used.
doDspCtrl	Indicates whether DSP/BIOS LINK should do <ul style="list-style-type: none"> <li>o Reset/release for DSP</li> <li>o the power control for DSP</li> </ul>
resumeAddr	The resume address after hibernating.
resetVector	Address of reset vector of DSP.
resetCodeSize	Size of code at DSP Reset Vector.
maduSize	Minimum addressable unit on the DSP.
cpuFreq	The frequency at which the DSP is running (in KHz). Specify -1 if the cpuFreq is not to be set from GPP-side and the default DSP/BIOS setting is to be used.
Endian	Endianism info of DSP.

<code>wordSwap</code>	Indicates whether words need to be swapped while writing into the memory for the DSP.
<code>memTableId</code>	Table number of the MEM entries for this DSP.
<code>memEntries</code>	Number of entries in the MEM table.
<code>linkDrvId</code>	Link Driver table identifier for this DSP.

### Comments

The value of `doDspCtrl` will be updated from `bool` to `enum` in `LDRV_MSGQ_State` as well as `LDRVChnlObject`.

### 7.6.2 Dsp\_BootMode\_Control

This enum defines the level of DSP control for the DSP.

Indicates whether DSP/BIOS LINK should do

- Do Reset/release for DSP
- Do the power control for DSP

### Definition

```
typedef enum {
    DSP_BootMode_Boot_NoPwr = 0x0,
    DSP_BootMode_Boot_Pwr,
    DSP_BootMode_NoLoad_NoPwr,
    DSP_BootMode_NoLoad_Pwr,
    DSP_BootMode_NoBoot}
    DSP_BootMode ;
```

### Fields

`DSP_BootMode_Boot_NoPwr` This is backward compatible with the default `false` i.e. `DSPLINK_BOOT_MODE`.

- `PROC_attach` will put DSP in local reset. It will not power up the DSP.
- `PROC_start` will set entry point for DSP i.e. `c_int00` and release DSP from reset
- `PROC_stop` will put DSP in local reset.
- `PROC_detach` will not power down the DSP.

`DSP_BootMode_Boot_Pwr` This is backward compatible with the default `true` i.e. `DSPLINK_BOOT_MODE`.

- `PROC_attach` will put DSP in local reset. It will power up the DSP.
- `PROC_start` will set entry point for DSP i.e. `c_int00` and release DSP from reset
- `PROC_stop` will put DSP in local reset.
- `PROC_detach` will power down the DSP.

DSP_BootMode_NoLoad_NoPwr	This is added to support DSPLINK_NOLOAD_MODE where DSPLink will do a local reset /release DSP from reset but not do any power management. <ul style="list-style-type: none"> <li>• PROC_attach will put DSP in local reset. It will not power up the DSP.</li> <li>• PROC_start will set entry point for DSP i.e. c_int00 and release DSP from reset</li> <li>• PROC_stop will put DSP in local reset.</li> <li>• PROC_detach will not power down the DSP.</li> </ul>
DSP_BootMode_NoLoad_Pwr	This is added to support DSPLINK_NOLOAD_MODE where DSPLink will a local reset /release DSP from reset as well as power management. <ul style="list-style-type: none"> <li>• PROC_attach will put DSP in local reset. It will power up the DSP.</li> <li>• PROC_start will set entry point for DSP i.e. c_int00 and release DSP from reset</li> <li>• PROC_stop will put DSP in local reset.</li> <li>• PROC_detach will power down the DSP.</li> </ul>
DSP_BootMode_NoBoot	This is added to support DSPLINK_NOBOOT_MODE where DSPLink will neither reset DSP nor release DSP from reset nor do any power management. <ul style="list-style-type: none"> <li>• PROC_attach will not put DSP in local reset. It will not power up the DSP.</li> <li>• PROC_start will not set entry point for DSP i.e. c_int00 and not release DSP from reset</li> <li>• PROC_stop will not put DSP in local reset.</li> <li>• PROC_detach will not power down the DSP.</li> </ul>

### Comments

The value of doDspCtrl will be updated from bool to enum in LINKCFG\_Dsp , LDRV\_MSGQ\_State as well as LDRVChnlObject.

Functionality of DSP\_init, DSP\_start, DSP\_exit will be updated to do DSP control operations based on the value of doDspControl.

Updates in CHNL and MSGQ state diagram regarding the behavior based on the DSP state will need to be updated.

### 7.6.3 NOLOADER\_ImageInfo

This structure defines the DSP address from where DSP will start execution in DSPLINK\_NOLOAD\_MODE. A pointer to this structure is passed during the PROC\_load () function as the imagePath, when the dummy loader is used.

#### Definition

```
typedef struct NOLOADER_ImageInfo_tag {
    Uint32  dspRunAddr  ;
    Uint32  argsAddr    ;
    Uint32  argsSize    ;
    Uint32  shmBaseAddr ;

} NOLOADER_ImageInfo ;
```

**Fields**

dspRunAddr	DSP address of the symbol from where the binary file execution is to be started.
argsAddr	Address of the .args section
argsSize	Size of the .args section
shmBaseAddr	DSP address of the symbol DSPLINK_shmBaseAddress. The value of DSPLink shared memory base address will be written at this address.

**Comments**

Argument related information is optional. Dummy loader will not fill .args section if NULL is specified in the argsAddr. It is the responsibility of application/ GPP loader/DSP loader to fill .args section in that case.

PROC\_load API signature remains unchanged.

## **8 Appendix**

### **8.1 Concept of Ownership of Components**

The concept of ownership in DSP/BIOS™ LINK is defined as:

1. The first user of an instance of a component is designated as the owner for that instance.
2. All the resources used for managing/interfacing the component are released when the owner releases the component.
3. If the owner releases the component, the associated resources are released even when other clients have not released the component.

This is different compared to the 'lock' interface implementation. The 'lock' mechanism allows a client to specify the access rights that it wants.

The current design allows a much simpler way to control the ownership of a component. Especially for `PMGR_PROC`, as the first client is designated as the owner, it simplifies the user side implementation. The client that gets a return code of `DSP_SALREADYATTACHED` can safely assume that some other client has already attached to the DSP and loaded the base image. Also, since state transitions can occur from only one place, the user side code is simplified.

### **8.2 Future Enhancements**

DSP/BIOS™ LINK currently allows a channel to be accessed from only one thread. As a future enhancement, the plan is to allow multiple threads to share a channel for data communication. Threads that belong to a process context can be assumed to be coordinating threads and can be allowed to share a channel. However, we can have a restriction that two processes cannot access the same channel.

In this scenario as well, the first thread that opens a channel can be designated as the owner of that channel. Other threads can also open the same channel but when the owner closes the channel (by a call to `PMGR_CHNL_Close()`) it is unusable.