

2802x C/C++ Header Files and Peripheral Examples Quick Start

1	Device Support:	2
2	Introduction:	2
2.1	Revision History	3
2.2	Where Files are Located (Directory Structure)	4
3	Understanding The Peripheral Bit-Field Structure Approach	6
4	Peripheral Example Projects	7
4.1	Getting Started	7
4.1.1	Getting Started in Code Composer Studio v3.x	7
4.1.2	Getting Started in Code Composer Studio v4	12
4.2	Example Program Structure	18
4.2.1	Source Code	19
4.2.2	Linker Command Files	19
4.3	Example Program Flow	21
4.4	Included Examples:	22
4.5	Executing the Examples From Flash	24
5	Steps for Incorporating the Header Files and Sample Code	28
5.1	Before you begin	28
5.2	Including the DSP2802x Peripheral Header Files	28
5.3	Including Common Example Code	33
6	Troubleshooting Tips & Frequently Asked Questions	37
6.1	Effects of read-modify-write instructions.	39
6.1.1	Registers with multiple flag bits in which writing a 1 clears that flag	40
6.1.2	Registers with Volatile Bits.	40
7	Migration Tips for moving from the TMS320x280x or TMS320x281x header files to the TMS320x2802x header files	41
8	Packet Contents:	42
8.1	Header File Support – DSP2802x_headers	42
8.1.1	DSP2802x Header Files – Main Files	42
8.1.2	DSP2802x Header Files – Peripheral Bit-Field and Register Structure Definition Files	43
8.1.3	Code Composer .gel Files	44
8.1.4	Variable Names and Data Sections	44
8.2	Common Example Code – DSP2802x_common	46
8.2.1	Peripheral Interrupt Expansion (PIE) Block Support	46
8.2.2	Peripheral Specific Files	47
8.2.3	Utility Function Source Files	48
8.2.4	Example Linker .cmd files	48
8.2.5	Example Library .lib Files	49
9	Detailed Revision History:	50

1 Device Support:

This software package supports 2802x devices. This includes the following: TMS320F28027, TMS320F28026, TMS320F28023, TMS320F28022, TMS320F28021, TMS320F28020, and TMS320F280200.

Throughout this document, TMS320F28027, TMS320F28026, TMS320F28023, TMS320F28022, TMS320F28021, TMS320F28020, and TMS320F280200 are abbreviated as F28027, F28026, F28023, F28022, F28021, F28020, and F280200 respectively.

2 Introduction:

The 2802x C/C++ peripheral header files and example projects facilitate writing in C/C++ Code for the Texas Instruments TMS320x2802x DSPs. The code can be used as a learning tool or as the basis for a development platform depending on the current needs of the user.

- Learning Tool:

This download includes several example Code Composer Studio™† projects for a 2802x development platform.

These examples demonstrate the steps required to initialize the device and utilize the on-chip peripherals. The provided examples can be copied and modified giving the user a platform to quickly experiment with different peripheral configurations.

These projects can also be migrated to other devices by simply changing the memory allocation in the linker command file.

- Development Platform:

The peripheral header files can easily be incorporated into a new or existing project to provide a platform for accessing the on-chip peripherals using C or C++ code. In addition, the user can pick and choose functions from the provided code samples as needed and discard the rest.

To get started this document provides the following information:

- Overview of the bit-field structure approach used in the 2802x C/C++ peripheral header files.
- Overview of the included peripheral example projects.
- Steps for integrating the peripheral header files into a new or existing project.
- Troubleshooting tips and frequently asked questions.
- Migration tips for users moving from the DSP280x header files to the DSP2802xheader files.

† Code Composer Studio is a trademark of Texas Instruments (www.ti.com).

Finally, this document does not provide a tutorial on writing C code, using Code Composer Studio, or the C28x Compiler and Assembler. It is assumed that the reader already has a 2802x hardware platform setup and connected to a host with Code Composer Studio installed. The user should have a basic understanding of how to use Code Composer Studio to download code through JTAG and perform basic debug operations.

2.1 Revision History

Version 1.26

- ☐ This version includes minor corrections to the header files and examples. A detailed revision history can be found in Section 9.

Version 1.25

- ☐ This version includes minor corrections to the header files and examples. The most notable change is that gel files and cmd linker files for the 280200 devices now include 1K additional L0 RAM. A detailed revision history can be found in Section 9.

Version 1.21b

- ☐ This version update only updates the V1.21 Quick Start Readme to adjust wording for the controlSUITE software package. No changes to the header file and peripheral example code were made.

Version 1.21

- ☐ This version includes minor corrections and comment fixes to the header files and examples. A detailed revision history can be found in Section 9.

Version 1.20

- ☐ This version includes corrections and comment fixes to the header files and examples. It adds examples pertaining to the ADC temperature sensor and compensation of the oscillator frequency over temperature, and it also fixes an error in the SFO_TI_Build_V6.lib library in the new SFO_TI_Build_V6b.lib library . A detailed revision history can be found in Section 9.

Version 1.10

- ☐ This version includes corrections and comment fixes to the header files and examples, adds 3 new 2802x devices – 28021, 28020, and 280200 - , deletes 2 2802x devices – 28024 and 28025 - and also adds a separate example folder, DSP2802x_examples_ccsv4, with examples supported by the Eclipse-based Code Composer Studio v4. A detailed revision history can be found in Section 9.

Version 1.00

- ☐ This version is the first release of the 2802x header files and examples.

2.2 Where Files are Located (Directory Structure)

As installed, the *2802x C/C++ Header Files and Peripheral Examples* is partitioned into a well-defined directory structure.

Table 1 describes the contents of the main directories used by DSP2802x header files and peripheral examples:




Table 1. DSP2802x Main Directory Structure

Directory	Description
<base>	Base install directory. For the rest of this document <base> will be omitted from the directory names.
<base>\doc	Documentation including the revision history from the previous release.
<base>\DSP2802x_headers	Files required to incorporate the peripheral header files into a project . The header files use the bit-field structure approach described in Section 3. Integrating the header files into a new or existing project is described in Section 5.
<base>\DSP2802x_examples	Example Code Composer Studio projects. These example projects illustrate how to configure many of the on-chip peripherals. An overview of the examples is given in Section 4. This directory not exist in the controlSUITE software package. controlSUITE does not support CCSv3.x example projects.
<base>\DSP2802x_examples_ccsv4	Example Code Composer Studio v4 projects. These examples are identical to those in the \DSP2802x_examples directory, but are generated for CCSv4 and cannot be run in CCSv3.x. An overview of the examples is given in Section 4.
<base>DSP2802x_common	Common source files shared across example projects to illustrate how to perform tasks using header file approach. Use of these files is optional, but may be useful in new projects. A list of these files is in Section 8.

Under the *DSP2802x_headers* and *DSP2802x_common* directories the source files are further broken down into sub-directories each indicating the type of file. Table 2 lists the sub-directories and describes the types of files found within each:

Table 2. DSP2802x Sub-Directory Structure

Sub-Directory	Description
DSP2802x_headers\cmd	Linker command files that allocate the bit-field structures described in Section 3.
DSP2802x_headers\source	Source files required to incorporate the header files into a new or existing project.
DSP2802x_headers\include	Header files for each of the on-chip peripherals.
DSP2802x_common\cmd	Example memory command files that allocate memory on the devices.
DSP2802x_common\include	Common .h files that are used by the peripheral examples.
DSP2802x_common\source	Common .c files that are used by the peripheral examples.
DSP2802x_common\lib	Common library (.lib) files that are used by the peripheral examples.
DSP2802x_common\gel	Code Composer Studio v3.x GEL files for each device. These are optional.
DSP2802x_common\gel\ccsv4	Code Composer Studio v4.x GEL files for each device. These are optional.

3 Understanding The Peripheral Bit-Field Structure Approach

The following application note includes useful information regarding the bit-field peripheral structure approach used by the header files and examples.

This method is compared to traditional #define macros and topics of code efficiency and special case registers are also addressed. The information in this application note is important to understand the impact using bit fields can have on your application code.

Programming TMS320x28xx and 28xxx Peripherals in C/C++ (SPRAA85)

4 Peripheral Example Projects

This section describes how to get started with and configure the peripheral examples included in the 2802x Header Files and Peripheral Examples software package.

4.1 Getting Started

4.1.1 Getting Started in Code Composer Studio v3.x

NOTE: If your peripheral example projects were downloaded with the controlSUITE software package, Code Composer Studio v3.x example projects are not supported. Please skip to section 4.1.2 for Getting Started in Code Composer Studio v4.x

To get started, follow these steps to load the 32-bit CPU-Timer example. Other examples are set-up in a similar manner.

1. Have a hardware platform connected to a host with Code Composer Studio installed.

NOTE: As supplied, the '2802x example projects are built for the '28027 device. If you are using another 2802x device, the memory definition in the linker command file (.cmd) will need to be changed and the project rebuilt.

2. Load the example's GEL file (.gel) or Project file (.pjt).

Each example includes a Code Composer Studio GEL file to help automate loading of the project, compiling of the code and populating of the watch window. Alternatively, the project file itself (.pjt) can be loaded instead of using the included GEL file.

To load the '2802x CPU-Timer example's GEL file follow these steps:

- a. In Code Composer Studio: *File->Load GEL*
- b. Browse to the CPU Timer example directory: *DSP2802x_examples\cpu_timer*
- c. Select *Example_2802xCpuTimer.gel* and click on *open*.
- d. From the Code Composer GEL pull-down menu select
DSP2802x CpuTimerExample-> Load_and_Build_Project

This will load the project and build compile the project.

3. Edit DSP28_Device.h

Edit the DSP2802x_Device.h file and make sure the appropriate device/package combination is selected. By default the 28027 PT package is selected.

```

/*****
* DSP2802x_headers\include\DSP2802x_Device.h
*****/

#define    TARGET    1
//-----
// User To Select Target Device:

define    DSP28_280200PT    0

```

```
#define DSP28_280200DA 0

#define DSP28_28020PT 0
#define DSP28_28020DA 0

#define DSP28_28021PT 0
#define DSP28_28021DA 0

#define DSP28_28022PT 0
#define DSP28_28022DA 0

#define DSP28_28023PT 0
#define DSP28_28023DA 0

#define DSP28_28026PT 0
#define DSP28_28026DA 0

#define DSP28_28027PT TARGET
#define DSP28_28027DA 0
```

4. Edit DSP2802x_Examples.h

Edit DSP2802x_Examples.h and specify the clock rate, the PLL control register value (PLLCR and DIVSEL). These values will be used by the examples to initialize the PLLCR register and DIVSEL bits.

The default values will result in a 60Mhz SYSCLKOUT frequency.

```
/******
 * DSP2802x_common\include\DSP2802x_Examples.h
 *****/
/*-----
   Specify the PLL control register (PLLCR) and divide select (DIVSEL) value.
 -----*/
// #define DSP28_DIVSEL 0 // Enable /4 for SYSCLKOUT(default at reset)
// #define DSP28_DIVSEL 1 // Disable /4 for SYSCLKOUT
#define DSP28_DIVSEL 2 // Enable /2 for SYSCLKOUT
// #define DSP28_DIVSEL 3 // Enable /1 for SYSCLKOUT

#define DSP28_PLLCR 12
// #define DSP28_PLLCR 11
// #define DSP28_PLLCR 10
// #define DSP28_PLLCR 9
// #define DSP28_PLLCR 8
// #define DSP28_PLLCR 7
// #define DSP28_PLLCR 6
// #define DSP28_PLLCR 5
// #define DSP28_PLLCR 4
// #define DSP28_PLLCR 3
// #define DSP28_PLLCR 2
// #define DSP28_PLLCR 1
// #define DSP28_PLLCR 0 // (Default at reset) PLL is bypassed in this mode
//-----
```


In DSP2802x_Examples.h, also specify the SYSCLKOUT rate. This value is used to scale a delay loop used by the examples. The default value is 60 Mhz SYSCLKOUT. If you have a 50 Mhz or 40 MHz device you will need to adjust these settings accordingly.

```

/*****
* DSP2802x_common\include\DSP2802x_Examples.h
*****/
.....
#define CPU_RATE      16.667L    // for a 60MHz CPU clock speed (SYSCLKOUT)
// #define CPU_RATE    20.000L    // for a 50MHz CPU clock speed (SYSCLKOUT)
// #define CPU_RATE    25.000L    // for a 40MHz CPU clock speed (SYSCLKOUT)
// #define CPU_RATE    33.333L    // for a 30MHz CPU clock speed (SYSCLKOUT)
.....

```

In DSP2802x_Examples.h the target device chosen in DSP2802x_Device.h also specifies the maximum SYSCLKOUT frequency (60 MHz/50MHz/40 MHz) by setting it to 1 and the other to 0 via compiler directives. This value is used by those examples with timing dependent code (i.e. baud rates or other timing parameters) to determine whether 60MHz code, 50 Mhz code, or 40MHz code should be run.

The default value is for 60Mhz SYSCLKOUT for the '28027 device. If you have selected a 50 Mhz device or a 40 MHz device in DSP2802x_Device.h, the frequency settings are adjusted accordingly. If you intend to run examples which use these definitions at a different frequency, then the timing parameters in those examples must be directly modified accordingly regardless of the setting here.

```

/*****
* DSP2802x_common\include\DSP2802x_Examples.h
*****/
.....
#if (DSP28_28026PT||DSP28_28026DA||DSP28_28027PT||DSP28_28027DA)    // 28026||28027
devices only
    #define CPU_FRQ_60MHZ      1        // 60 Mhz CPU Freq (10 MHz input clock)
    #define CPU_FRQ_50MHZ      0
    #define CPU_FRQ_40MHZ      0
#elif (DSP28_28023PT||DSP28_28023DA||DSP28_28022PT||DSP28_28022DA) // 28023||28023
devices
    #define CPU_FRQ_60MHZ      0
    #define CPU_FRQ_50MHZ      1        // 50 MHz CPU Freq (10 MHz input clock)
    #define CPU_FRQ_40MHZ      0
#else
    // 28021||28020||280200 devices
    #define CPU_FRQ_60MHZ      0
    #define CPU_FRQ_50MHZ      0
    #define CPU_FRQ_40MHZ      1        // 40 MHz CPU Freq (10 MHz input clock)
#endif
//-----

```

5. Review the comments at the top of the main source file: Example_2802xCpuTimer.c.

A brief description of the example and any assumptions that are made and any external hardware requirements are listed in the comments at the top of the main source file of

each example. In some cases you may be required to make external connections for the example to work properly.

6. Perform any hardware setup required by the example.

Perform any hardware setup indicated by the comments in the main source. The CPU-Timer example only requires that the hardware be setup for “Boot to SARAM” mode. Other examples may require additional hardware configuration such as connecting pins together or pulling a pin high or low.

Table 3 shows a listing of the boot mode pin settings for your reference. Table 4 and Table 5 list the EMU boot modes (when emulator is connected) and the Get Mode boot mode options (mode is programmed into OTP) respectively. Refer to the documentation for your hardware platform for information on configuring the boot mode pins. For more information on the ‘2802x boot modes refer to the device specific *Boot ROM Reference Guide*.

Table 3. 2802x Boot Mode Settings

GPI037 TDO	GPI034 CMP2OUT	TRSTn	Mode
X	X	1	EMU Mode
0	0	0	Parallel I/O
0	1	0	SCI
1	0	0	Wait
1	1	0	“Get Mode”

Table 4. 2802x EMU Boot Modes (Emulator Connected)

EMU_KEY 0x0D00	EMU_BMODE 0x0D01	Boot Mode Selected
!= 0x55AA	x	Wait
0x55AA	0x0000	Parallel I/O
	0x0001	SCI
	0x0002	Wait
	0x0003	Get Mode
	0x0004	SPI
	0x0005	I2C
	0x0006	OTP
	0x0007	Wait
	0x0008	Wait
	0x000A	Boot to RAM
	0x000B	Boot to FLASH
	Other	Wait

Table 5. 2802x GET Boot Modes (Emulator Disconnected)

OTP_KEY 0x3D7BFE	OTP_BMODE 0x3D7BFF	Boot Mode Selected
!= 0x55AA	x	Get Mode - Flash
0x55AA	0x0001	Get Mode - SCI
	0x0003	Get Mode - Flash
	0x0004	Get Mode - SPI
	0x0005	Get Mode - I2C
	0x0006	Get Mode - OTP
	Other	Get Mode - Flash

When the emulator is connected for debugging:

TRSTn = 1, and therefore the device is in EMU boot mode. In this situation, the user must write the key value of 0x55AA to EMU_KEY at address 0x0D00 and the desired EMU boot mode value to EMU_BMODE at 0x0D01 via the debugger window according to Table 4. The 2802x gel files in the DSP2802x_common/gel/ directory have a GEL function – EMU Boot Mode Select -> EMU_BOOT_SARAM() which performs the debugger write to boot to “SARAM” mode when called.

When the emulator is not connected for debugging:

SCI or Parallel I/O boot mode can be selected directly via the GPIO pins, or OTP_KEY at address 0x3D7BFE and OTP_BMODE at address 0x3D7BFF can be programmed for the desired boot mode per Table 5.

7. Load the code

Once any hardware configuration has been completed, from the Code Composer GEL pull-down menu select

DSP2802x CpuTimerExample-> Load_Code (for '2802x devices)

This will load the .out file into the 28x device, populate the watch window with variables of interest, reset the part and execute code to the start of the main function. The GEL file is setup to reload the code every time the device is reset so if this behavior is not desired, the GEL file can be removed at this time. To remove the GEL file, right click on its name and select *remove*.

8. Run the example, add variables to the watch window or examine the memory contents.
9. Experiment, modify, re-build the example.

If you wish to modify the examples it is suggested that you make a copy of the entire header file packet to modify or at least create a backup of the original files first. New examples provided by TI will assume that the base files are as supplied.

Sections 4.2 and 4.3 describe the structure and flow of the examples in more detail.

10. When done, remove the example's GEL file and project from Code Composer Studio.

To remove the GEL file, right click on its name and select *remove*. The examples use the header files in the *DSP2802x_headers* directory and shared source in the *DSP2802x_common* directory. Only example files specific to a particular example are located within in the example directory.

Note: Most of the example code included uses the *.bit* field structures to access registers. This is done to help the user learn how to use the peripheral and device. Using the bit fields has the advantage of yielding code that is easier to read and modify. This method will result in a slight code overhead when compared to using the *.all* method. In addition, the example projects have the compiler optimizer turned off. The user can change the compiler settings to turn on the optimizer if desired.

4.1.2 Getting Started in Code Composer Studio v4

To get started, follow these steps to load the 32-bit CPU-Timer example. Other examples are set-up in a similar manner.

1. Have a hardware platform connected to a host with Code Composer Studio installed.

NOTE: As supplied, the '2802x example projects are built for the '28027 device. If you are using another 2802x device, the memory definition in the linker command file (.cmd) will need to be changed and the project rebuilt.

2. Open the example project.

Each example has its own project directory which is "imported"/opened in Code Composer Studio v4.

To open the '2802x CPU-Timer example project directory, follow the following steps:

- a. In Code Composer Studio v 4.x: Project->Import Existing CCS/CCE Eclipse Project.
- b. Next to "Select Root Directory", browse to the CPU Timer example directory: *DSP2802x_examples_ccsv4\cpu_timer*. Select the *Finish* button.

This will import/open the project in the CCStudio v4 C/C++ Perspective project window.

3. Edit DSP28_Device.h

Edit the *DSP2802x_Device.h* file and make sure the appropriate device/package combination is selected. By default the 28027 PT package is selected.

```

/*****
* DSP2802x_headers\include\DSP2802x_Device.h
*****/

#define TARGET 1

```

```
//-----
// User To Select Target Device:

define    DSP28_280200PT    0
#define    DSP28_280200DA    0

#define    DSP28_28020PT    0
#define    DSP28_28020DA    0

#define    DSP28_28021PT    0
#define    DSP28_28021DA    0

#define    DSP28_28022PT    0
#define    DSP28_28022DA    0

#define    DSP28_28023PT    0
#define    DSP28_28023DA    0

#define    DSP28_28026PT    0
#define    DSP28_28026DA    0

#define    DSP28_28027PT    TARGET
#define    DSP28_28027DA    0
```

4. Edit DSP2802x_Examples.h

Edit DSP2802x_Examples.h and specify the clock rate, the PLL control register value (PLLCR and DIVSEL). These values will be used by the examples to initialize the PLLCR register and DIVSEL bits.

The default values will result in a 60Mhz SYSCLKOUT frequency.

```

/*****
* DSP2802x_common\include\DSP2802x_Examples.h
*****/
/*-----
Specify the PLL control register (PLLCCR) and divide select (DIVSEL) value.
-----*/
// #define DSP28_DIVSEL    0    // Enable /4 for SYSCLKOUT (default at reset)
// #define DSP28_DIVSEL    1    // Disable /4 for SYSCLKOUT
#define DSP28_DIVSEL      2    // Enable /2 for SYSCLKOUT
// #define DSP28_DIVSEL    3    // Enable /1 for SYSCLKOUT

#define DSP28_PLLCCR      12
// #define DSP28_PLLCCR    11
// #define DSP28_PLLCCR    10
// #define DSP28_PLLCCR    9
// #define DSP28_PLLCCR    8
// #define DSP28_PLLCCR    7
// #define DSP28_PLLCCR    6
// #define DSP28_PLLCCR    5
// #define DSP28_PLLCCR    4
// #define DSP28_PLLCCR    3
// #define DSP28_PLLCCR    2
// #define DSP28_PLLCCR    1
// #define DSP28_PLLCCR    0    // (Default at reset) PLL is bypassed in this mode
//-----

```

In DSP2802x_Examples.h, also specify the SYSCLKOUT rate. This value is used to scale a delay loop used by the examples. The default value is for a 60 Mhz SYSCLKOUT. If you have a 50 Mhz device or a 40 MHz device you will need to adjust these settings accordingly.

```

/*****
* DSP2802x_common\include\DSP2802x_Examples.h
*****/
.....
#define CPU_RATE          16.667L    // for a 60MHz CPU clock speed (SYSCLKOUT)
// #define CPU_RATE        20.000L    // for a 50MHz CPU clock speed (SYSCLKOUT)
// #define CPU_RATE        25.000L    // for a 40MHz CPU clock speed (SYSCLKOUT)
// #define CPU_RATE        33.333L    // for a 30MHz CPU clock speed (SYSCLKOUT)
.....

```

In DSP2802x_Examples.h the target device chosen in DSP2802x_Device.h also specifies the maximum SYSCLKOUT frequency (60 MHz, 50 Mhz, or 40 MHz) by setting it to 1 and the other to 0 via compiler directives. This value is used by those examples with timing dependent code (i.e. baud rates or other timing parameters) to determine whether 60MHz code, 50 Mhz code, or 40MHz code should be run.

The default value is for 60Mhz SYSCLKOUT for the '28027 device. If you have selected a 50 Mhz device or a 40 MHz device in DSP2802x_Device.h, the frequency settings are adjusted accordingly. If you intend to run examples which use these definitions at a different frequency, then the timing parameters in those examples must be directly modified accordingly regardless of the setting here.

```

/*****
* DSP2802x_common\include\DSP2802x_Examples.h
*****/
.....
#if (DSP28_28026PT||DSP28_28026DA||DSP28_28027PT||DSP28_28027DA) // 28026||28027
devices only
#define CPU_FRQ_60MHZ 1 // 60 Mhz CPU Freq (10 MHz input clock)
#define CPU_FRQ_50MHZ 0
#define CPU_FRQ_40MHZ 0
#elif (DSP28_28023PT||DSP28_28023DA||DSP28_28022PT||DSP28_28022DA) // 28023||28023
devices
#define CPU_FRQ_60MHZ 0
#define CPU_FRQ_50MHZ 1 // 50 MHz CPU Freq (10 MHz input clock)
#define CPU_FRQ_40MHZ 0
#else // 28021||28020||280200 devices
#define CPU_FRQ_60MHZ 0
#define CPU_FRQ_50MHZ 0
#define CPU_FRQ_40MHZ 1 // 40 MHz CPU Freq (10 MHz input clock)
#endif//-----

```

5. Review the comments at the top of the main source file: Example_2802xCpuTimer.c.

A brief description of the example and any assumptions that are made and any external hardware requirements are listed in the comments at the top of the main source file of each example. In some cases you may be required to make external connections for the example to work properly.

6. Perform any hardware setup required by the example.

Perform any hardware setup indicated by the comments in the main source. The CPU-Timer example only requires that the hardware be setup for “Boot to SARAM” mode. Other examples may require additional hardware configuration such as connecting pins together or pulling a pin high or low.

Table 3 shows a listing of the boot mode pin settings for your reference. Table 4 and Table 5 list the EMU boot modes (when emulator is connected) and the Get Mode boot mode options (mode is programmed into OTP) respectively. Refer to the documentation for your hardware platform for information on configuring the boot mode pins. For more information on the ‘2802x boot modes refer to the device specific *Boot ROM Reference Guide*.

Table 6. 2802x Boot Mode Settings

GPIO37 TDO	GPIO34 CMP2OUT	TRSTn	Mode
X	X	1	EMU Mode
0	0	0	Parallel I/O
0	1	0	SCI
1	0	0	Wait
1	1	0	“Get Mode”

Table 7. 2802x EMU Boot Modes (Emulator Connected)

EMU_KEY 0x0D00	EMU_BMODE 0x0D01	Boot Mode Selected
!= 0x55AA	x	Wait
0x55AA	0x0000	Parallel I/O
	0x0001	SCI
	0x0002	Wait
	0x0003	Get Mode
	0x0004	SPI
	0x0005	I2C
	0x0006	OTP
	0x0007	Wait
	0x0008	Wait
	0x000A	Boot to RAM
	0x000B	Boot to FLASH
	Other	Wait

Table 8. 2802x GET Boot Modes (Emulator Disconnected)

OTP_KEY 0x3D7BFE	OTP_BMODE 0x3D7BFF	Boot Mode Selected
!= 0x55AA	x	Get Mode - Flash
0x55AA	0x0001	Get Mode - SCI
	0x0003	Get Mode - Flash
	0x0004	Get Mode - SPI
	0x0005	Get Mode - I2C
	0x0006	Get Mode - OTP
	Other	Get Mode - Flash

When the emulator is connected for debugging:

TRSTn = 1, and therefore the device is in EMU boot mode. In this situation, the user must write the key value of 0x55AA to EMU_KEY at address 0x0D00 and the desired EMU boot mode value to EMU_BMODE at 0x0D01 via the debugger window according to Table 4. The 2802x gel files in the DSP2802x_common/gel/ directory have a GEL function – EMU Boot Mode Select -> EMU_BOOT_SARAM() which performs the debugger write to boot to “SARAM” mode when called.

When the emulator is not connected for debugging:

SCI or Parallel I/O boot mode can be selected directly via the GPIO pins, or OTP_KEY at address 0x3D7BFE and OTP_BMODE at address 0x3D7BFF can be programmed for the desired boot mode per Table 5.

7. Build and Load the code

Once any hardware configuration has been completed, in Code Composer Studio v4, go to *Target->Debug Active Project*.

This will open the “Debug Perspective” in CCSv4, build the project, load the .out file into the 28x device, reset the part, and execute code to the start of the main function. By default, in Code Composer Studio v4, every time *Debug Active Project* is selected, the code is automatically built and the .out file loaded into the 28x device.

8. Run the example, add variables to the watch window or examine the memory contents.

At the top of the code in the comments section, there should be a list of “Watch variables”. To add these to the watch window, highlight them and right-click. Then select *Add Watch expression*. Now variables of interest are added to the watch window.

9. Experiment, modify, re-build the example.

If you wish to modify the examples it is suggested that you make a copy of the entire header file packet to modify or at least create a backup of the original files first. New examples provided by TI will assume that the base files are as supplied.

Sections 4.2 and 4.3 describe the structure and flow of the examples in more detail.


10. When done, delete the project from the Code Composer Studio v4 workspace.

Go to *View->C/C++ Projects* to open up your project view. To remove/delete the project from the workspace, right click on the project’s name and select *delete*. Make sure the *Do not delete contents* button is selected, then select *Yes*. This does not delete the project itself. It merely removes the project from the workspace until you wish to open/import it again.

The examples use the header files in the *DSP2802x_headers* directory and shared source in the *DSP2802x_common* directory. Only example files specific to a particular example are located within in the example directory.

Note: Most of the example code included uses the .bit field structures to access registers. This is done to help the user learn how to use the peripheral and device. Using the bit fields has the advantage of yielding code that is easier to read and modify. This method will result in a slight code overhead when compared to using the .all method. In addition, the example projects have the compiler optimizer turned off. The user can change the compiler settings to turn on the optimizer if desired.

4.2 Example Program Structure



Each of the example programs has a very similar structure. This structure includes unique source code, shared source code, header files and linker command files.

```

/*****
* DSP2802x_examples\cpu_timer\Example_2802xCpuTimer.c
*****/

#include "DSP28x_Project.h"    // Device Headerfile and Examples Include File

```

- **DSP28x_Project.h**

This header file includes **DSP2802x_Device.h** and **DSP2802x_Examples.h**. Because the name is device-generic, example/custom projects can be easily ported between different device header files. With this file included in the example source files, only the example/custom project (.pjt) file and **DSP28x_Project.h** file would need to be modified when porting source code between different devices. This file is found in the **<base>\DSP2802x_common\include** directory.

- **DSP2802x_Device.h**

This header file is required to use the header files. This file includes all of the required peripheral specific header files and includes device specific macros and typedef statements. This file is found in the **<base>\DSP2802x_headers\include** directory.

- **DSP2802x_Examples.h**

This header file defines parameters that are used by the example code. This file is not required to use just the DSP2802x peripheral header files but is required by some of the common source files. This file is found in the `<base>\DSP2802x_common\include` directory.

4.2.1 Source Code

Each of the example projects consists of source code that is unique to the example as well as source code that is common or shared across examples.

- **DSP2802x_GlobalVariableDefs.c**

Any project that uses the DSP2802x peripheral header files must include this source file. In this file are the declarations for the peripheral register structure variables and data section assignments. This file is found in the `<base>\DSP2802x_headers\source` directory.

- **Example specific source code:**

Files that are specific to a particular example have the prefix `Example_2802x` in their filename. For example `Example_2802xCpuTimer.c` is specific to the CPU Timer example and not used for any other example. Example specific files are located in the `<base>\DSP2802x_examples\<example>` directory.

- **Common source code:**

The remaining source files are shared across the examples. These files contain common functions for peripherals or useful utility functions that may be re-used. Shared source files are located in the `DSP2802x_common\source` directory. Users may choose to incorporate none, some, or the entire shared source into their own new or existing projects.

4.2.2 Linker Command Files

Each example uses two linker command files. These files specify the memory where the linker will place code and data sections. One linker file is used for assigning compiler generated sections to the memory blocks on the device while the other is used to assign the data sections of the peripheral register structures used by the DSP2802x peripheral header files.

- **Memory block linker allocation:**

The linker files shown in 0 are used to assign sections to memory blocks on the device. These linker files are located in the `<base>\DSP2802x_common\cmd` directory. Each example will use one of the following files depending on the memory used by the example.

Table 9. Included Memory Linker Command Files

Memory Linker Command File Examples	Location	Description
28027_RAM_Ink.cmd	DSP2802x_common\cmd	28027 memory linker command file. Includes all of the internal SARAM blocks on 28027 device. "RAM" linker files do not include flash or OTP blocks.
28026_RAM_Ink.cmd	DSP2802x_common\cmd	28026 SARAM memory linker command file.
28023_RAM_Ink.cmd	DSP2802x_common\cmd	28023 SARAM memory linker command file.
28022_RAM_Ink.cmd	DSP2802x_common\cmd	28022 SARAM memory linker command file.
28021_RAM_Ink.cmd	DSP2802x_common\cmd	28021 SARAM memory linker command file.
28020_RAM_Ink.cmd	DSP2802x_common\cmd	28020 SARAM memory linker command file.
280200_RAM_Ink.cmd	DSP2802x_common\cmd	280200 SARAM memory linker command file.
F28027.cmd	DSP2802x_common\cmd	F28027 memory linker command file. Includes all Flash, OTP and CSM password protected memory locations.
F28026.cmd	DSP2802x_common\cmd	F28026 memory linker command file.
F28023.cmd	DSP2802x_common\cmd	F28023 memory linker command file.
F28022.cmd	DSP2802x_common\cmd	F28022 memory linker command file.
F28021.cmd	DSP2802x_common\cmd	F28021 memory linker command file.
F28020.cmd	DSP2802x_common\cmd	F28020 memory linker command file.
F280200.cmd	DSP2802x_common\cmd	F280200 memory linker command file.

- **Header file structure data section allocation:**

Any project that uses the header file peripheral structures must include a linker command file that assigns the peripheral register structure data sections to the proper memory location. These files are described in Table 10.

Table 10. DSP2802x Peripheral Header Linker Command File

Header File Linker Command File	Location	Description
DSP2802x_Headers_nonBIOS.cmd	DSP2802x_headers\cmd	Linker .cmd file to assign the header file variables in a non-BIOS project. This file must be included in any non-BIOS project that uses the header files. Refer to section 5.2.
DSP2802x_Headers_nonBIOS.cmd	DSP2833x_headers\cmd	Linker .cmd file to assign the header file variables in a non-BIOS project. This file must be included in any non-BIOS project that uses the header files. Refer to section 5.2.

4.3 Example Program Flow

All of the example programs follow a similar recommended flow for setting up a 2802x device. Figure 1 outlines this basic flow:




Figure 1. Flow for Example Programs

4.4 Included Examples:

Table 11. Included Examples

Example	Description
adc_soc	ADC example to convert two channels: ADCINA4 and ADCINA2. Interrupts are enabled and PWM1 is configured to generate a periodic ADC SOC – ADCINT1.
adc_temp_sensor	ADC example – periodically performs conversions on internal channel ADCINA5 which is connected to the ADC temperature sensor.
adc_temp_sensor_conv	ADC example – periodically performs conversions on internal channel ADCINA5, connected to the ADC temperature sensor, and converts the ADC result value to Celsius or Kelvins. Only works on TMS 2802x devices.
cpu_timer	Configures CPU Timer0 and increments a count each time the ISR is serviced.
ecap_apwm	This example sets up the alternate eCAP pins in the APWM mode
ecap_capture_pwm	Captures the edges of a ePWM signal.
epwm_blanking_window	Demonstrates blanking window by filtering out digital compare events around CTR = 0.
epwm_deadband	Example deadband generation via ePWM3
epwm_dceventtrip	Sets up digital compare events, and uses combinations of these events to set ePWM signals to a particular state.
epwm_dcevent_trip_comp	Sets up digital compare events with comparator inputs and uses combinations of these events to set ePWM signals to a particular state.
epwm_timer_interrupts	Starts ePWM1-ePWM6 timers. Every period an interrupt is taken for each ePWM.
epwm_trip_zone	Uses the trip zone signals to set the ePWM signals to a particular state.
epwm_up_aq	Generate a PWM waveform using an up count time base ePWM1-ePWM3 are used.
epwm_updown_aq	Generate a PWM waveform using an up/down time base. ePWM1- ePWM3 are used.
eqep_freqcal	Frequency cal using eQEP1
eqep_pos_speed	Pos/speed calculation using eQEP1
external_interrupt	Configures GPIO0 as XINT1 and GPIO1 as XINT2. The interrupts are fired by toggling GPIO30 and GPIO31 which are connected to XINT1 (GPIO0) and XINT2 (GPIO1) externally by the user.
flash	ePWM timer interrupt project moved from SARAM to Flash. Includes steps that were used to convert the project from SARAM to Flash. Some interrupt service routines are copied from FLASH to SARAM for faster execution.
gpio_setup	Three examples of different pinout configurations.
gpio_toggle	Toggles all of the I/O pins using different methods – DATA, SET/CLEAR and TOGGLE registers. The pins can be observed using an oscilloscope.
hrpwm	Sets up ePWM1-ePWM4 and controls the edge of output A using the HRPWM extension. Both rising edge and falling edge are controlled.
hrpwm_duty_sfo_v6	Use TI's MEP Scale Factor Optimizer (SFO) library to change the HRPWM duty cycle.
hrpwm_prdup_sfo_v6	Use TI's MEP Scale Factor Optimizer (SFO) library to change the HRPWM period in up-count mode.
hrpwm_prdupdown_sfo_v56	Use TI's MEP Scale Factor Optimizer (SFO) library to change the HRPWM period in up-down count mode.

Included Examples Continued...

hrpwm_slider	This is the same as the hrpwm example except the control of CMPAHR is now controlled by the user via a slider bar. The included .gel file sets up the slider.
i2c_eeprom	Communicate with an EEPROM via I2C
lpm_haltwake	Puts device into low power halt mode. GPIO0 is configured to wake the device from halt when an external high-low-high pulse is applied to it.
lpm_idlewake	Puts device into low power idle mode. GPIO0 is configured as XINT1 pin. When an XINT1 interrupt occurs due to a falling edge on GPIO0, the device is woken from idle.
lpm_standbywake	Puts device into low power standby mode. GPIO0 is configured to wake the device from halt when an external high-low-high pulse is applied to it.
osc_comp	Runs the oscillator compensation function on internal oscillator 1 or 2 to maintain oscillator frequency across temperature. Only works on TMS 2802x devices.
sci_echoback	SCI-A example that can be used to echoback to a terminal program such as hyperterminal. A transceiver and a connection to a PC is required.
scia_loopback	SCI-A example that uses the peripheral's loop-back test mode to send data.
scia_loopback_interrupts	SCI-A example that uses the peripheral's loop-back test mode to send data. Both interrupts and FIFOs are used in this example.
spi_loopback	SPI-A example that uses the peripherals loop-back test mode to send data.
spi_loopback_interrupts	SPI-A example that uses the peripherals loop-back test mode to send data. Both interrupts and FIFOs are used in this example.
sw_prioritized_interrupts	The standard hardware prioritization of interrupts can be used for most applications. This example shows a method for software to re-prioritize interrupts if required.
timed_led_blink	This example blinks GPIO34 (LED on the control card) at a rate of 1 Hz using CPU Timer 0.
watchdog	Illustrates feeding the dog and re-directing the watchdog to an interrupt.

4.5 Executing the Examples From Flash

Most of the DSP2802x examples execute from SARAM in “boot to SARAM” mode. One example, *DSP2802x_examples(_ccsv4)\Flash*, executes from flash memory in “boot to flash” mode. This example is the PWM timer interrupt example with the following changes made to execute out of flash:

- 1. Change the linker command file to link the code to flash.**

Remove 28027_RAM_Ink.cmd from the project and add one of the flash based linker files (ex: F28027.cmd, F28026.cmd, F28023.cmd, or F28022.cmd, F28021.cmd, F28020.cmd, F280200.cmd). These files are located in the *<base>DSP2802x_common\cmd* directory.

- 2. Add the *DSP2802x_common\source\DSP2802x_CSMPasswords.asm* to the project.**

This file contains the passwords that will be programmed into the Code Security Module (CSM) password locations. Leaving the passwords set to 0xFFFF during development is recommended as the device can easily be unlocked. For more information on the CSM refer to the appropriate *System Control and Interrupts Reference Guide*.

- 3. Modify the source code to copy all functions that must be executed out of SARAM from their load address in flash to their run address in SARAM.**

In particular, the flash wait state initialization routine must be executed out of SARAM. In the DSP2802x, functions that are to be executed from SARAM have been assigned to the ramfuncs section by compiler CODE_SECTION #pragma statements as shown in the example below.

```

/*****
* DSP2802x_common\source\DSP2802x_SysCtrl.c
*****/

#pragma CODE_SECTION(InitFlash, "ramfuncs");

```

The ramfuncs section is then assigned to a load address in flash and a run address in SARAM by the memory linker command file as shown below:

```

/*****
* DSP2802x_common\include\F28027.cmd
*****/
SECTIONS
{
    ramfuncs          : LOAD = FLASHA,
                      RUN  = PRAML0,
                      LOAD_START(_RamfuncsLoadStart),
                      LOAD_END(_RamfuncsLoadEnd),
                      RUN_START(_RamfuncsRunStart),
                      PAGE = 0
}

```


The linker will assign symbols as specified above to specific addresses as follows:

Address	Symbol
Load start address	RamfuncsLoadStart
Load end address	RamfuncsLoadEnd
Run start address	RamfuncsRunStart

These symbols can then be used to copy the functions from the Flash to SARAM using the included example MemCopy routine or the C library standard memcpy() function.

To perform this copy from flash to SARAM using the included example MemCopy function:

- a. Add the file *DSP2802x_common\source\DSP2802x_MemCopy.c* to the project.
- c. Add the following function prototype to the example source code. This is done for you in the *DSP2802x_Examples.h* file.

```

/*****
* DSP2802x_common\include\DSP2802x_Examples.h
*****/

MemCopy(&RamfuncsLoadStart, &RamfuncsLoadEnd, &RamfuncsRunStart);

```

- d. Add the following variable declaration to your source code to tell the compiler that these variables exist. The linker command file will assign the address of each of these variables as specified in the linker command file as shown in step 3. For the DSP2802x example code this has already been done in *DSP2802x_Examples.h*.

```

/*****
* DSP2802x_common\include\DSP2802x_GlobalPrototypes.h
*****/

extern Uint16 RamfuncsLoadStart;
extern Uint16 RamfuncsLoadEnd;
extern Uint16 RamfuncsRunStart;

```

- e. Modify the code to call the example MemCopy function for each section that needs to be copied from flash to SARAM.

```

/*****
* DSP2802x_examples\Flash source file
*****/

MemCopy(&RamfuncsLoadStart, &RamfuncsLoadEnd, &RamfuncsRunStart);

```

4. Modify the code to call the flash initialization routine:

This function will initialize the wait states for the flash and enable the Flash Pipeline mode.

```

/*****
* DSP2802x peripheral example .c file
*****/

InitFlash();

```

5. Set the required jumpers for “boot to Flash” mode.

The required jumper settings for each boot mode are shown in Table 12, Table 13, and Table 14.

Table 12. 2802x Boot Mode Settings

GPIO37 TDO	GPIO34 CMP2OUT	TRSTn	Mode
X	X	1	EMU Mode
0	0	0	Parallel I/O
0	1	0	SCI
1	0	0	Wait
1	1	0	“Get Mode”

Table 13. 2802x EMU Boot Modes (Emulator Connected)

EMU_KEY 0x0D00	EMU_BMODE 0x0D01	Boot Mode Selected
!= 0x55AA	x	Wait
0x55AA	0x0000	Parallel I/O
	0x0001	SCI
	0x0002	Wait
	0x0003	Get Mode
	0x0004	SPI
	0x0005	I2C
	0x0006	OTP
	0x0007	Wait
	0x0008	Wait
	0x000A	Boot to RAM
	0x000B	Boot to FLASH
	Other	Wait

Table 14. 2802x GET Boot Modes (Emulator Disconnected)

OTP_KEY 0x3D7BFE	OTP_BMODE 0x3D7BFF	Boot Mode Selected
!= 0x55AA	x	Get Mode - Flash
0x55AA	0x0001	Get Mode - SCI
	0x0003	Get Mode - Flash
	0x0004	Get Mode - SPI
	0x0005	Get Mode - I2C
	0x0006	Get Mode - OTP
	Other	Get Mode - Flash

When the emulator is connected for debugging:

TRSTn = 1, and therefore the device is in EMU boot mode. In this situation, the user must write the key value of 0x55AA to EMU_KEY at address 0x0D00 and the desired EMU boot mode value to EMU_BMODE at 0x0D01 via the debugger window according to Table 4.

When the emulator is not connected for debugging:

SCI or Parallel I/O boot mode can be selected directly via the GPIO pins, or OTP_KEY at address 0x3D7BFE and OTP_BMODE at address 0x3D7BFF can be programmed for the desired boot mode per the tables above

Refer to the documentation for your hardware platform for information on configuring the boot mode selection pins.

For more information on the '2802x boot modes refer to the appropriate *Boot ROM Reference Guide*.

6. Program the device with the built code.

In Code Composer Studio v4, when code is loaded into the device during debug, it automatically programs to flash memory.

This can also be done using SDFlash available from Spectrum Digital's website (www.spectrumdigital.com). In addition the C2000 On-chip Flash programmer plug-in for Code Composer Studio v3.x can be used.

These tools will be updated to support new devices as they become available. Please check for updates.

7. In Code Composer Studio v3, to debug, load the project in CCS, select *File->Load Symbols->Load Symbols Only*.

It is useful to load only symbol information when working in a debugging environment where the debugger cannot or need not load the object code, such as when the code is in ROM or flash. This operation loads the symbol information from the specified file.

5 Steps for Incorporating the Header Files and Sample Code

Follow these steps to incorporate the peripheral header files and sample code into your own projects. If you already have a project that uses the DSP280x or DSP281x header files then also refer to Section 7 for migration tips.

5.1 Before you begin

Before you include the header files and any sample code into your own project, it is recommended that you perform the following:

1. **Load and step through an example project.**

Load and step through an example project to get familiar with the header files and sample code. This is described in Section 4.

2. **Create a copy of the source files you want to use.**

DSP2802x_headers: code required to incorporate the header files into your project
DSP2802x_common: shared source code much of which is used in the example projects.

DSP2802x_examples(_ccsv4): '2802x example projects that use the header files and shared code.

5.2 Including the DSP2802x Peripheral Header Files

Including the DSP2802x header files in your project will allow you to use the bit-field structure approach in your code to access the peripherals on the DSP. To incorporate the header files in a new or existing project, perform the following steps:

1. **#include "DSP2802x_Device.h" (or #include "DSP28x_Project.h") in your source files.**

The DSP2802x_Device.h include file will in-turn include all of the peripheral specific header files and required definitions to use the bit-field structure approach to access the peripherals.

```

/*****
* User's source file
*****/

#include "DSP2802x_Device.h"

```

Another option is to #include "DSP28x_Project.h" in your source files, which in-turn includes "DSP2802x_Device.h" and "DSP2802x_Examples.h" (if it is not necessary to include common source files in the user project, the #include "DSP2802x_Examples.h" line can be deleted). Due to the device-generic nature of the file name, user code is easily ported between different device header files. With this file included in the user's source files, only the project (.pj) file and DSP28x_Project.h file would need to be modified when porting source code between different devices.

```

/*****
* User's source file
*****/

#include "DSP28x_Project.h"

```

Edit DSP2802x_Device.h and select the target you are building for:

In the below example, the file is configured to build for the '28027 device.

```

/*****
* DSP2802x_headers\include\DSP2802x_Device.h
*****/

#define TARGET 1
#define DSP28_28027 TARGET // Selects '28027
#define DSP28_28026 0 // Selects '28026
#define DSP28_28023 0 // Selects '28023... etc

```

By default, the '28027 device is selected.

2. Add the source file *DSP2802x_GlobalVariableDefs.c* to the project.

This file is found in the *DSP2802x_headers\source* directory and includes:

- Declarations for the variables that are used to access the peripheral registers.
- Data section #pragma assignments that are used by the linker to place the variables in the proper locations in memory.

3. Add the appropriate DSP2802x header linker command file to the project.

As described in Section 3, when using the DSP2802x header file approach, the data sections of the peripheral register structures are assigned to the memory locations of the peripheral registers by the linker.

To perform this memory allocation in your project, one of the following linker command files located in *DSP2802x_headers\cmd* must be included in your project:

- For non-DSP/BIOS[†] projects: *DSP2802x_Headers_nonBIOS.cmd*
- For DSP/BIOS projects: *DSP2802x_Headers_BIOS.cmd*


[†] DSP/BIOS is a trademark of Texas Instruments

The method for adding the header linker file to the project depends on the version of Code Composer Studio being used.

Code Composer Studio V2.2 and later:

As of CCS 2.2, more than one linker command file can be included in a project.

Add the appropriate header linker command file (BIOS or nonBIOS) directly to the project.



Code Composer Studio prior to V2.2

Prior to CCS 2.2, each project contained only one main linker command file. This file can, however, call additional .cmd files as needed. To include the required memory allocations for the DSP2802x header files, perform the following two steps:

1) Update the project's main linker command (.cmd) file to call one of the supplied DSP2802x peripheral structure linker command files using the -l option.

```

/*****
* User's linker .cmd file
*****/

/* Use this include file only for non-BIOS applications */
-l DSP2802x_Headers_nonBIOS.cmd
/* Use this include file only for BIOS applications */
/* -l DSP2802x_Headers_BIOS.cmd */

```

2) Add the DSP2802x peripheral linker .cmd file to your project.

Code Composer Studio 3.x:

- Right-click on your project.
- Select *Add Files to Project*
- Navigate to the *DSP2802x_headers\cmd* directory on your system and select the desired .cmd file.

Code Composer Studio 4.x:

Method #1:

- Right-click on the project in the project window of the C/C++ Projects perspective.
- Select *Link Files to Project...*
- Navigate to the *DSP2802x_headers\cmd* directory on your system and select the desired .cmd file.

Note: The limitation with Method #1 is that the path to <install directory>\DSP2802x_headers\cmd\<cmd file>.cmd is fixed on your PC. If you move the installation directory to another location on your PC, the project will

“break” because it still expects the .cmd file to be in the original location. Use **Method #2** if you are using “linked variables” in your project to ensure your project/installation directory is portable across computers and different locations on the same PC. (For more information, see:

[http://tiexpressdsp.com/index.php/Portable Projects in CCSv4 for C2000](http://tiexpressdsp.com/index.php/Portable%20Projects%20in%20CCSv4%20for%20C2000))

Method #2:


- Right-click on the project in the project window of the C/C++ Projects perspective.
- Select *New->File*.
- Click on the *Advanced>>* button to expand the window.
- Check the *Link to file in the file system* checkbox.
- Select the *Variables...* button. From the list, pick the linked variable (macro defined in your *macros.ini* file) associated with your installation directory. (For the 2802x header files, this is `INSTALLROOT_2802X_V<version #>`). For more information on linked variables and the *macros.ini* file, see:
[http://tiexpressdsp.com/index.php/Portable Projects in CCSv4 for C2000#Method .232 for Linking Files to Project](http://tiexpressdsp.com/index.php/Portable%20Projects%20in%20CCSv4%20for%20C2000#Method%20232%20for%20Linking%20Files%20to%20Project):
- Click on the *Extend...* button. Navigate to the desired .cmd file and select *OK*.

4. Add the directory path to the DSP2802x header files to your project.

Code Composer Studio 3.x:

To specify the directory where the header files are located:

- Open the menu:
Project->Build Options
- Select the *Compiler* tab
- Select *pre-processor*.
- In the *Include Search Path*, add the directory path to the location of *DSP2802x_headers\include* on your system.




Code Composer Studio 4.x:

To specify the directory where the header files are located:

- Open the menu: *Project->Properties*.
- In the menu on the left, select “C/C++ Build”.
- In the “*Tool Settings*” tab, Select “*C2000 Compiler -> Include Options:*”

- d. In the “Add dir to #include search path (--include_path, -I)” window, select the “Add” icon in the top right corner.
- e. Select the “File system...” button and navigate to the directory path of *DSP2802x_headers\include* on your system.



5. Additional suggested build options:

The following are additional compiler and linker options. The options can all be set via the *Project->Build Options* menu.

– **Compiler Tab:**

- ☐ **-ml** **Select *Advanced* and check *-ml***

Build for large memory model. This setting allows data sections to reside anywhere within the 4M-memory reach of the 28x devices.

- ☐ **-pdr** **Select *Diagnostics* and check *-pdr***

Issue non-serious warnings. The compiler uses a warning to indicate code that is valid but questionable. In many cases, these warnings issued by enabling -pdr can alert you to code that may cause problems later on.

– **Linker Tab:**

- ☐ **-w** **Select *Advanced* and check *-w***

Warn about output sections. This option will alert you if any unassigned memory sections exist in your code. By default the linker will attempt to place any unassigned code or data section to an available memory location without alerting the user. This can cause problems, however, when the section is placed in an unexpected location.

- ☐ **-e** **Select *Basic* and enter Code Entry Point *-e***

Defines a global symbol that specifies the primary entry point for the output module. For the DSP2802x examples, this is the symbol “code_start”. This

symbol is defined in the DSP2802x_common\source\DSP2802x_CodeStartBranch.asm file. When you load the code in Code Composer Studio, the debugger will set the PC to the address of this symbol. If you do not define a entry point using the –e option, then the linker will use _c_int00 by default.

5.3 Including Common Example Code

Including the common source code in your project will allow you to leverage code that is already written for the device. To incorporate the shared source code into a new or existing project, perform the following steps:

1. #include “DSP2802x_Examples.h” (or “DSP28x_Project.h”) in your source files.

The “DSP2802x_Examples.h” include file will include common definitions and declarations used by the example code.

```

/*****
* User's source file
*****/

#include "DSP2802x_Examples.h"

```

Another option is to #include “DSP28x_Project.h” in your source files, which in-turn includes “DSP2802x_Device.h” and “DSP2802x_Examples.h”. Due to the device-generic nature of the file name, user code is easily ported between different device header files. With this file included in the user’s source files, only the project (.pj) file and DSP28x_Project.h file would need to be modified when porting source code between different devices.

```

/*****
* User's source file
*****/

#include "DSP28x_Project.h"

```

2. Add the directory path to the example include files to your project.


Code Composer Studio 3.x

To specify the directory where the header files are located:

- Open the menu:
Project->Build Options
- Select the *Compiler* tab
- Select *pre-processor*.
- In the *Include Search Path*, add the directory path to the location of DSP2802x_common/include on your system.
Use a semicolon between directories.

For example the directory path for the included projects is:


`..\..\DSP2802x_headers\include;..\..\DSP2802x_common\include`



Code Composer Studio 4.x:

To specify the directory where the header files are located:

- Open the menu: *Project->Properties*.
- In the menu on the left, select "C/C++ Build".
- In the "Tool Settings" tab, Select "C2000 Compiler -> Include Options."
- In the "Add dir to #include search path (--include_path, -I)" window, select the "Add" icon in the top right corner.
- Select the "File system..." button and navigate to the directory path of *DSP2802x_headers\include* on your system.



3. Add a linker command file to your project.

The following memory linker .cmd files are provided as examples in the *DSP2802x_common\cmd* directory. For getting started the basic *28027_RAM_Ink.cmd* file is suggested and used by most of the examples.

Table 15. Included Main Linker Command Files

Memory Linker Command File Examples	Location	Description
28027_RAM_Ink.cmd	DSP2802x_common\cmd	28027 memory linker command file. Includes all of the internal SARAM blocks on a 28027 device. "RAM" linker files do not include flash or OTP blocks.
28026_RAM_Ink.cmd	DSP2802x_common\cmd	28026 SARAM memory linker command file.
28023_RAM_Ink.cmd	DSP2802x_common\cmd	28023 SARAM memory linker command file.
28022_RAM_Ink.cmd	DSP2802x_common\cmd	28022 SARAM memory linker command file.
28021_RAM_Ink.cmd	DSP2802x_common\cmd	28021 SARAM memory linker command file.
28020_RAM_Ink.cmd	DSP2802x_common\cmd	28020 SARAM memory linker command file.
280200_RAM_Ink.cmd	DSP2802x_common\cmd	280200 SARAM memory linker command file.
F28027.cmd	DSP2802x_common\cmd	F28027 memory linker command file. Includes all Flash, OTP and CSM password protected memory locations.
F28026.cmd	DSP2802x_common\cmd	F28026 memory linker command file.
F28023.cmd	DSP2802x_common\cmd	F28023 memory linker command file.
F28022.cmd	DSP2802x_common\cmd	F28022 memory linker command file.
F28021.cmd	DSP2802x_common\cmd	F28021 memory linker command file.
F28020.cmd	DSP2802x_common\cmd	F28020 memory linker command file.
F280200.cmd	DSP2802x_common\cmd	F280200 memory linker command file.

4. Set the CPU Frequency

In the *DSP2802x_common\include\DSP2802x_Examples.h* file specify the proper CPU frequency. Some examples are included in the file.

```

/*****
* DSP2802x_common\include\DSP2802x_Examples.h
*****/
.....
#define CPU_RATE    16.667L    // for a 60MHz CPU clock speed (SYSCLKOUT)
// #define CPU_RATE    20.000L    // for a 50MHz CPU clock speed (SYSCLKOUT)
// #define CPU_RATE    25.000L    // for a 40MHz CPU clock speed (SYSCLKOUT)
.....

```

5. Add desired common source files to the project.

The common source files are found in the *DSP2802x_common\source* directory.

6. Include .c files for the PIE.

Since all catalog '2802x applications make use of the PIE interrupt block, you will want to include the PIE support .c files to help with initializing the PIE. The shell ISR functions can be used directly or you can re-map your own function into the PIE vector table provided. A list of these files can be found in section 8.2.1.

6 Troubleshooting Tips & Frequently Asked Questions

- **In the examples, what do “EALLOW;” and “EDIS;” do?**

EALLOW; is a macro defined in DSP2802x_Device.h for the assembly instruction EALLOW and likewise EDIS is a macro for the EDIS instruction. That is EALLOW; is the same as embedding the assembly instruction `asm(“ EALLOW”);`

Several control registers on the 28x devices are protected from spurious CPU writes by the EALLOW protection mechanism. The EALLOW bit in status register 1 indicates if the protection is enabled or disabled. While protected, all CPU writes to the register are ignored and only CPU reads, JTAG reads and JTAG writes are allowed. If this bit has been set by execution of the EALLOW instruction, then the CPU is allowed to freely write to the protected registers. After modifying the registers, they can once again be protected by executing the EDIS assembly instruction to clear the EALLOW bit.

For a complete list of protected registers, refer to *TMS320x2802x System Control and Interrupts Reference Guide*.

- **Peripheral registers read back 0x0000 and/or cannot be written to.**

There are a few things to check:

- Peripheral registers cannot be modified or unless the clock to the specific peripheral is enabled. The function `InitPeripheralClocks()` in the DSP2802x_common\source directory shows an example of enabling the peripheral clocks.
- Some peripherals are not present on all 2802x family derivatives. Refer to the device datasheet for information on which peripherals are available.
- The EALLOW bit protects some registers from spurious writes by the CPU. If your program seems unable to write to a register, then check to see if it is EALLOW protected. If it is, then enable access using the EALLOW assembly instruction. *TMS320x2802x System Control and Interrupts Reference Guide* for a complete list of EALLOW protected registers.

- **Memory block L0, L1 read back all 0x0000.**

In this case most likely the code security module is locked and thus the protected memory locations are reading back all 0x0000. Refer to the for information on the code security module.

- **Code cannot write to L0 or L1 memory blocks.**

In this case most likely the code security module is locked and thus the protected memory locations are reading back all 0x0000. Code that is executing from outside of the protected cannot read or write to protected memory while the CSM is locked. Refer to the *TMS320x2802x Control and Interrupts Reference Guide* for information on the code security module

- **A peripheral register reads back ok, but cannot be written to.**

The EALLOW bit protects some registers from spurious writes by the CPU. If your program seems unable to write to a register, then check to see if it is EALLOW protected. If it is, then enable access using the EALLOW assembly instruction. *TMS320x2802x System Control and Interrupts Reference Guide* for a complete list of EALLOW protected registers.

- **I re-built one of the projects to run from Flash and now it doesn't work. What could be wrong?**

Make sure all initialized sections have been moved to flash such as .econst and .switch.

If you are using SDFlash, make sure that all initialized sections, including .econst, are allocated to page 0 in the linker command file (.cmd). SDFlash will only program sections in the .out file that are allocated to page 0.

- **Why do the examples populate the PIE vector table and then re-assign some of the function pointers to other ISRs?**

The examples share a common default ISR file. This file is used to populate the PIE vector table with pointers to default interrupt service routines. Any ISR used within the example is then remapped to a function within the same source file. This is done for the following reasons:

- The entire PIE vector table is enabled, even if the ISR is not used within the example. This can be very useful for debug purposes.
- The default ISR file is left un-modified for use with other examples or your own project as you see fit.
- It illustrates how the PIE table can be updated at a later time.

- **When I build the examples, the linker outputs the following: warning: entry point other than _c_int00 specified. What does this mean?**

This warning is given when a symbol other than _c_int00 is defined as the code entry point of the project. For these examples, the symbol code_start is the first code that is executed after exiting the boot ROM code and thus is defined as the entry point via the -e linker option. This symbol is defined in the DSP2802x_CodeStartBranch.asm file. The entry point symbol is used by the debugger and by the hex utility. When you load the code, CCS will set the PC to the entry point symbol. By default, this is the _c_int00 symbol which marks the start of the C initialization routine. For the DSP2802x examples, the code_start symbol is used instead. Refer to the source code for more information.

- **When I build many of the examples, the compiler outputs the following: remark: controlling expression is constant. What does this mean?**

Some of the examples run forever until the user stops execution by using a while(1) {} loop. The remark refers to the while loop using a constant and thus the loop will never be exited.

- **When I build some of the examples, the compiler outputs the following: warning: statement is unreachable. What does this mean?**

Some of the examples run forever until the user stops execution by using a while(1) {} loop. If there is code after this while(1) loop then it will never be reached.

- **I changed the build configuration of one of the projects from “Debug” to “Release” and now the project will not build. What could be wrong?**

When you switch to a new build configuration (*Project->Configurations*) the compiler and linker options changed for the project. The user must enter other options such as include search path and the library search path. Open the build options menu (*Project->Build Options*) and enter the following information:

- Compiler Tab, Preprocessor: Include search path
- Linker Tab, Basic: Library search path
- Linker Tab, Basic: Include libraries (ie rts2800_ml.lib)

Refer to section 5 for more details.

- **In the flash example I loaded the symbols and ran to main. I then set a breakpoint but the breakpoint is never hit. What could be wrong?**

In the Flash example, the InitFlash function and several of the ISR functions are copied out of flash into SARAM. When you set a breakpoint in one of these functions, Code Composer will insert an ESTOP0 instruction into the SARAM location. When the ESTOP0 instruction is hit, program execution is halted. CCS will then remove the ESTOP0 and replace it with the original opcode. In the case of the flash program, when one of these functions is copied from Flash into SARAM, the ESTOP0 instruction is overwritten code. This is why the breakpoint is never hit. To avoid this, set the breakpoint after the SARAM functions have been copied to SARAM.

- **The eCAN control registers require 32-bit write accesses.**

The compiler will instead make a 16-bit write accesses if it can in order to improve codesize and/or performance. This can result in unpredictable results.

One method to avoid this is to create a duplicate copy of the eCAN control registers in RAM. Use this copy as a shadow register. First copy the contents of the eCAN register you want to modify into the shadow register. Make the changes to the shadow register and then write the data back as a 32-bit value. This method is shown in the DSP2802x_examples\ecan_back2back example project.

6.1 Effects of read-modify-write instructions.

When writing any code, whether it be C or assembly, keep in mind the effects of read-modify-write instructions.

The '28x DSP will write to registers or memory locations 16 or 32-bits at a time. Any instruction that seems to write to a single bit is actually reading the register, modifying the single bit, and then writing back the results. This is referred to as a read-modify-write instruction. For most registers this operation does not pose a problem. A notable exception is:

6.1.1 Registers with multiple flag bits in which writing a 1 clears that flag.

For example, consider the PIEACK register. Bits within this register are cleared when writing a 1 to that bit. If more than one bit is set, performing a read-modify-write on the register may clear more bits than intended.

The below solution is incorrect. It will write a 1 to any bit set and thus clear all of them:

```

/*****
* User's source file
*****/

PieCtrl.PIEACK.bit.Ack1 = 1;    // INCORRECT! May clear more bits.

```

The correct solution is to write a mask value to the register in which only the intended bit will have a 1 written to it:

```

/*****
* User's source file
*****/

#define PIEACK_GROUP1 0x0001
.....
PieCtrl.PIEACK.all = PIEACK_GROUP1;    // CORRECT!

```

6.1.2 Registers with Volatile Bits.

Some registers have volatile bits that can be set by external hardware.

Consider the PIEIFRx registers. An atomic read-modify-write instruction will read the 16-bit register, modify the value and then write it back. During the modify portion of the operation a bit in the PIEIFRx register could change due to an external hardware event and thus the value may get corrupted during the write.

The rule for registers of this nature is to never modify them during runtime. Let the CPU take the interrupt and clear the IFR flag.

7 Migration Tips for moving from the TMS320x280x or TMS320x281x header files to the TMS320x2802x header files

This section includes suggestions for moving a project from the 280x header files to the 2802x header files.

1. **Create a copy of your project to work with or back-up your current project.**
2. **Open the project file(s) in a text editor**

In Code Composer Studio v3.x:

Open the .pj1 project file for your project. Replace all instances of 280x with 2803x so that the appropriate source files and build options are used. Check the path names to make sure they point to the appropriate header file and source code directories.

In Code Composer Studio v4.x:

Open the .project, .cdtbuild, and macros.ini files in your example folder. Replace all instances of 280x with 2803x so that the appropriate source files and build options are used. Check the path names to make sure they point to the appropriate header file and source code directories. Also replace the header file version number for the paths and macro names as well where appropriate. For instance, if a macro name was **INSTALLROOT_280X_V170** for your 280x project using 280x header files V1.70, change this to **INSTALLROOT_2802X_V110** to migrate to the 2802x header files V1.10. If not using the default macro name for your header file version, be sure to change your macros according to your chosen macro name in the .project, .cdtbuild, and macros.ini files.

3. **Load the project into Code Composer Studio**

Use the Edit-> find in files dialog to find instances of DSP280x_Device.h and DSP280x_Example.h for 280x header files. Replace these with DSP2802x_Device.h and DSP2802x_Example.h respectively (or instead with one DSP2802x_Project.h file).

4. **Make sure you are using the correct linker command files (.cmd) appropriate for your device and for the DSP2802x header files.**

You will have one file for the memory definitions and one file for the header file structure definitions. Using a 280x memory file can cause issues since the H0 memory block has been split, renamed, and/or moved on the 2802x.

5. **Build the project.**

The compiler will highlight areas that have changed. If migrating from the TMS320x280x header files, code should be mostly compatible after all instances of DSP280x are replaced with DSP2802x in all relevant files, and the above steps are taken. Additionally, several bits have been removed and/or replaced. See Table 16.

**Table 16. Summary of Register and Bit-Name Changes from DSP280x V1.60
DSP2802x V1.00**

		Bit Name	
--	--	----------	--

Peripheral	Register	Old	New	Comment
SysCtrlRegs				
	XCLK	Reserved(bit 6)	XCLKINSEL(bit 6)	On 2802x devices, XCLKIN can be fed via a GPIO pin. This bit selects either GPIO38 (default) or GPIO19 as XCLKIN input source.
	PLLSTS	CLKINDIV(bit 1)	DIVSEL (bits 8,7)	DIVSEL allows more values by which CLKIN can be divided.

Additionally, unlike the DSP280x devices, the DSP2802x devices run off an internal oscillator (INTOSC1) by default. To switch between the 2 available internal clock sources and the traditional external oscillator clock source, a new register in the System Control register space – CLKCTL – is available.

8 Packet Contents:

This section lists all of the files included in the release.

8.1 Header File Support – DSP2802x_headers

The DSP2802x header files are located in the `<base>\DSP2802x_headers\` directory.

8.1.1 DSP2802x Header Files – Main Files

The following files must be added to any project that uses the DSP2802x header files. Refer to section 5.2 for information on incorporating the header files into a new or existing project.

Table 17. DSP2802x Header Files – Main Files

File	Location	Description
DSP2802x_Device.h	DSP2802x_headers\include	Main include file. Include this one file in any of your .c source files. This file in-turn includes all of the peripheral specific .h files listed below. In addition the file includes typedef statements and commonly used mask values. Refer to section 5.2.
DSP2802x_GlobalVariableDefs.c	DSP2802x_headers\source	Defines the variables that are used to access the peripheral structures and data section #pragma assignment statements. This file must be included in any project that uses the header files. Refer to section 5.2.
DSP2802x_Headers_nonBIOS.cmd	DSP2802x_headers\cmd	Linker .cmd file to assign the header file variables in a non-BIOS project. This file must be included in any non-BIOS project that uses the header files. Refer to section 5.2.
DSP2802x_Headers_nonBIOS.cmd	DSP2802x_headers\cmd	Linker .cmd file to assign the header file variables in a non-BIOS project. This file must be included in any non-BIOS project that uses the header files. Refer to section 5.2.

8.1.2 DSP2802x Header Files – Peripheral Bit-Field and Register Structure Definition Files

The following files define the bit-fields and register structures for each of the peripherals on the 2802x devices. These files are automatically included in the project by including *DSP2802x_Device.h*. Refer to section 4.2 for more information on incorporating the header files into a new or existing project.

Table 18. DSP2802x Header File Bit-Field & Register Structure Definition Files

File	Location	Description
DSP2802x_Adc.h	DSP2802x_headers\include	ADC register structure and bit-field definitions.
DSP2802x_BootVars.h	DSP2802x_headers\include	External boot variable definitions.
DSP2802x_Comp.h	DSP2802x_headers\include	Comparator register structure and bit-field definitions.
DSP2802x_CpuTimers.h	DSP2802x_headers\include	CPU-Timer register structure and bit-field definitions.
DSP2802x_DevEmu.h	DSP2802x_headers\include	Emulation register definitions
DSP2802x_ECap.h	DSP2802x_headers\include	eCAP register structures and bit-field definitions.
DSP2802x_EPwm.h	DSP2802x_headers\include	ePWM register structures and bit-field definitions.
DSP2802x_Gpio.h	DSP2802x_headers\include	General Purpose I/O (GPIO) register structures and bit-field definitions.
DSP2802x_I2c.h	DSP2802x_headers\include	I2C register structure and bit-field definitions.
DSP2802x_NmiIntrupt.h	DSP2802x_headers\include	NMI interrupt register structure and bit-field definitions
DSP2802x_PieCtrl.h	DSP2802x_headers\include	PIE control register structure and bit-field definitions.
DSP2802x_PieVect.h	DSP2802x_headers\include	Structure definition for the entire PIE vector table.
DSP2802x_Sci.h	DSP2802x_headers\include	SCI register structure and bit-field definitions.
DSP2802x_Spi.h	DSP2802x_headers\include	SPI register structure and bit-field definitions.
DSP2802x_SysCtrl.h	DSP2802x_headers\include	System register definitions. Includes Watchdog, PLL, CSM, Flash/OTP, Clock registers.
DSP2802x_XIntrupt.h	DSP2802x_headers\include	External interrupt register structure and bit-field definitions.

8.1.3 Code Composer .gel Files

The following Code Composer Studio .gel files are included for use with the DSP2802x Header File peripheral register structures.

Table 19. DSP2802x Included GEL Files

File	Location	Description
DSP2802x_Peripheral.gel	DSP2802x_headers\gel	<p>This is relevant for CCSv3.3 only.</p> <p>Provides GEL pull-down menus to load the DSP2802x data structures into the watch window.</p> <p>You may want to have CCS load this file automatically by adding a GEL_LoadGel("<base>DSP2802x_headers\gel\ DSP2802x_peripheral.gel") function to the standard F28027.gel that was included with CCS.</p>

8.1.4 Variable Names and Data Sections

This section is a summary of the variable names and data sections allocated by the DSP2802x_headers\source\DSP2802x_GlobalVariableDefs.c file. Note that all peripherals may not be available on a particular 2802x device. Refer to the device datasheet for the peripheral mix available on each 2802x family derivative.

Table 20. DSP2802x Variable Names and Data Sections

Peripheral	Starting Address	Structure Variable Name
ADC	0x007100	AdcRegs
ADC Mirrored Result Registers	0x000B00	AdcMirror
Code Security Module	0x000AE0	CsmRegs
Code Security Module Password Locations	0x3F7FF8-0x3F7FFF	CsmPwl
COMP1	0x006400	Comp1Regs
COMP2	0x006420	Comp2Regs
CPU Timer 0	0x000C00	CpuTimer0Regs
CPU Timer 1	0x000C08	CpuTimer1Regs
CPU Timer 2	0x000C10	CpuTimer2Regs
Device and Emulation Registers	0x000880	DevEmuRegs
ePWM1	0x006800	EPwm1Regs
ePWM2	0x006840	EPwm2Regs
ePWM3	0x006880	EPwm3Regs
ePWM4	0x0068C0	EPwm4Regs
eCAP1	0x006A00	ECap1Regs
External Interrupt Registers	0x007070	XIntruptRegs
Flash & OTP Configuration Registers	0x000A80	FlashRegs
General Purpose I/O Data Registers	0x006fC0	GpioDataRegs
General Purpose Control Registers	0x006F80	GpioCtrlRegs

General Purpose Interrupt Registers	0x006fE0	GpioIntRegs
I2C	0x007900	I2caRegs
NMI Interrupt	0x7060	NmiIntruptRegs
PIE Control	0x000CE0	PieCtrlRegs
SCI-A	0x007050	SciaRegs
SPI-A	0x007040	SpiaRegs

8.2 Common Example Code – DSP2802x_common

8.2.1 Peripheral Interrupt Expansion (PIE) Block Support

In addition to the register definitions defined in DSP2802x_PieCtrl.h, this packet provides the basic ISR structure for the PIE block. These files are:

Table 21. Basic PIE Block Specific Support Files

File	Location	Description
DSP2802x_DefaultIsr.c	DSP2802x_common\source	Shell interrupt service routines (ISRs) for the entire PIE vector table. You can choose to populate one of functions or re-map your own ISR to the PIE vector table. Note: This file is not used for DSP/BIOS projects.
DSP2802x_DefaultIsr.h	DSP2802x_common\include	Function prototype statements for the ISRs in DSP2802x_DefaultIsr.c. Note: This file is not used for DSP/BIOS projects.
DSP2802x_PieVect.c	DSP2802x_common\source	Creates an instance of the PIE vector table structure initialized with pointers to the ISR functions in DSP2802x_DefaultIsr.c. This instance can be copied to the PIE vector table in order to initialize it with the default ISR locations.

In addition, the following files are included for software prioritization of interrupts. These files are used in place of those above when additional software prioritization of the interrupts is required. Refer to the example and documentation in *DSP2802x_examples\sw_prioritized_interrupts* for more information.

Table 22. Software Prioritized Interrupt PIE Block Specific Support Files

File	Location	Description
DSP2802x_SWPrioritizedDefaultIsr.c	DSP2802x_common\source	Default shell interrupt service routines (ISRs). These are shell ISRs for all of the PIE interrupts. You can choose to populate one of functions or re-map your own interrupt service routine to the PIE vector table. Note: This file is not used for DSP/BIOS projects.
DSP2802x_SWPrioritizedIsrLevels.h	DSP2802x_common\include	Function prototype statements for the ISRs in DSP2802x_SWPrioritizedDefaultIsr.c. Note: This file is not used for DSP/BIOS projects.
DSP2802x_SWPrioritizedPieVect.c	DSP2802x_common\source	Creates an instance of the PIE vector table structure initialized with pointers to the default ISR functions that are included in DSP2802x_SWPrioritizedDefaultIsr.c. This instance can be copied to the PIE vector table in order to initialize it with the default ISR locations.

8.2.2 Peripheral Specific Files

Several peripheral specific initialization routines and support functions are included in the peripheral .c source files in the *DSP2802x_common\src* directory. These files include:

Table 23. Included Peripheral Specific Files

File	Description
DSP2802x_GlobalPrototypes.h	Function prototypes for the peripheral specific functions included in these files.
DSP2802x_Adc.c	ADC specific functions and macros.
DSP2802x_Comp.c	Comparator specific functions and macros
DSP2802x_CpuTimers.c	CPU-Timer specific functions and macros.
DSP2802x_ECap.c	eCAP module specific functions and macros.
DSP2802x_EPwm.c	ePWM module specific functions and macros.
DSP2802x_EPwm_defines.h	#define macros that are used for the ePWM examples
DSP2802x_Gpio.c	General-purpose IO (GPIO) specific functions and macros.
DSP2802x_I2C.c	I2C specific functions and macros.
DSP2802x_I2c_defines.h	#define macros that are used for the I2C examples
DSP2802x_PieCtrl.c	PIE control specific functions and macros.
DSP2802x_Sci.c	SCI specific functions and macros.
DSP2802x_Spi.c	SPI specific functions and macros.
DSP2802x_SysCtrl.c	System control (watchdog, clock, PLL etc) specific functions and macros.

Note: The specific routines are under development and may not all be available as of this release. They will be added and distributed as more examples are developed.

8.2.3 Utility Function Source Files

Table 24. Included Utility Function Source Files

File	Description
DSP2802x_CodeStartBranch.asm	Branch to the start of code execution. This is used to re-direct code execution when booting to Flash, OTP or M0 SARAM memory. An option to disable the watchdog before the C init routine is included.
DSP2802x_DBGIER.asm	Assembly function to manipulate the DEBIER register from C.
DSP2802x_DisInt.asm	Disable interrupt and restore interrupt functions. These functions allow you to disable INTM and DBGM and then later restore their state.
DSP2802x_usDelay.asm	Assembly function to insert a delay time in microseconds. This function is cycle dependant and must be executed from zero wait-stated RAM to be accurate. Refer to <i>DSP2802x_examples/adc</i> for an example of its use.
DSP2802x_CSMPasswords.asm	Include in a project to program the code security module passwords and reserved locations.

8.2.4 Example Linker .cmd files

Example memory linker command files are located in the *DSP2802x_common\cmd* directory. For getting started the basic 28027_RAM_Ink.cmd file is suggested and used by many of the included examples.

The L0 SARAM block is mirrored on these devices. For simplicity these memory maps only include one instance of these memory blocks.

Table 25. Included Main Linker Command Files

Memory Linker Command File Examples	Location	Description
28027_RAM_Ink.cmd	DSP2802x_common\cmd	28027 memory linker command file. Includes all of the internal SARAM blocks on a 28027 device. "RAM" linker files do not include flash or OTP blocks.
28026_RAM_Ink.cmd	DSP2802x_common\cmd	28026 SARAM memory linker command file.
28023_RAM_Ink.cmd	DSP2802x_common\cmd	28023 SARAM memory linker command file.
28022_RAM_Ink.cmd	DSP2802x_common\cmd	28022 SARAM memory linker command file.
28021_RAM_Ink.cmd	DSP2802x_common\cmd	28021 SARAM memory linker command file.
28020_RAM_Ink.cmd	DSP2802x_common\cmd	28020 SARAM memory linker command file.
280200_RAM_Ink.cmd	DSP2802x_common\cmd	280200 SARAM memory linker command file.
F28027.cmd	DSP2802x_common\cmd	F28027 memory linker command file. Includes all Flash, OTP and CSM password protected memory locations.
F28026.cmd	DSP2802x_common\cmd	F28026 memory linker command file.

F28023.cmd	DSP2802x_common\cmd	F28023 memory linker command file.
F28022.cmd	DSP2802x_common\cmd	F28022 memory linker command file.
F28021.cmd	DSP2802x_common\cmd	F28021 memory linker command file.
F28020.cmd	DSP2802x_common\cmd	F28020 memory linker command file.
F280200.cmd	DSP2802x_common\cmd	F280200 memory linker command file.

8.2.5 Example Library .lib Files

Example library files are located in the *DSP2802x_common\lib* directory. For this release the IQMath library is included for use in the example projects. Please refer to the *C28x IQMath Library - A Virtual Floating Point Engine* (SPRC087) for more information on IQMath and the most recent IQMath library. The SFO libraries are also included for use in the example projects. Please refer to *TMS320x2802x HRPWM Reference Guide* (SPRUGE8) for more information on SFO library usage and the HRPWM module.

Table 26. Included Library Files

Main Liner Command File Examples	Description
IQmath.lib	Please refer to the <i>C28x IQMath Library - A Virtual Floating Point Engine</i> (SPRC087) for more information on IQMath. This is a fixed-point compiled library.
IQmathLib.h	IQMath header file.
SFO_TI_Build_V6.lib	Please refer to the <i>TMS320x2802x HRPWM Reference Guide</i> (SPRUGE8) for more information on the SFO V6 library.
SFO_V6.h	SFO V6 header file

9 Detailed Revision History:

Changes from V1.25 to V1.26

Changes to Header Files:

- a) **DSP2802x_Adc.h** – In the ADCREFTRIM register – changed BG_FINE_TRIM to 5 bits and BG_COARSE_TRIM to 4 bits for Rev. A silicon.

Changes from V1.21 to V1.25

Changes to Header Files:

- a) **DSP2802x_Adc.h** – Added ADCCTL2 register to structure (this register does not apply to Rev. 0 silicon).

Changes to Common Files:

- b) **DSP2802x_Adc.c** – Added functions for re-calibrating the ADC trim registers.
- c) **DSP2802x_GlobalPrototypes.h** – Added function prototypes for ADC re-calibration functions.
- d) **f280200.gel** – Added 1K L0 SARAM at 0x8000 mirrored at 0x3f8000
- e) **F280200.cmd and 280200_RAM_Ink.cmd** – Added 1K L0 SARAM at 0x8000.
- f) **f28027.gel, f28026.gel, f28023.gel, f28022.gel, f28021.gel, f28020.gel, f280200.gel** – Modified GEL_Toolbar5() function for ccsv4 version of gels to support CCSv4. Also modified gel so that Device_Cal does not run when only symbols are loaded.

Changes from V1.20 to V1.21

Changes to Header Files:

- g) **DSP2802x_SysCtrl.h** – Added SysPwrCtrlRegs structure with BORCFG register.
- h) **DSP2802x_DevEmu.h** – Removed BORCFG register (does not belong in this space).
- i) **DSP2802x_Headers_BIOS.cmd/DSP2802x_Headers_nonBIOS.cmd** – Added SysPwrCtrlRegs to 0x985-0x987, and reduced DevEmuRegs to 0x880-0x984.
- j) **DSP2802x_GlobalVariableDefs.c** – Added SysPwrCtrlRegs declaration.
- k) **DSP2802x_Adc.c** – Added changes to be implemented in Rev. A silicon (documented in ADC reference guide. Not implemented in Rev. 0 silicon). Added ONESHOT bit to SOCPRICTL register.

Changes to Common Files:

- l) **DSP2802x_TempSensorConv.c** – changed return type to “int” instead of “unsigned int”.
- m) **f28027.gel, f28026.gel, f28023.gel, f28022.gel, f28021.gel, f28020.gel, f280200.gel** – Changed Bypass() function such that PLLCR changed to 0 before DIVSEL set to divide by 1 to prevent overshooting SYSCLKOUT frequency.
- n) **DSP2802x_Examples.h** – add 50 Mhz support for 28022 and 28023 devices

Changes to Example Files:

- o) **Example_2802xHRPWM_Duty_SFO_V6.c**- Equations corrected. “0.5” in Q-format should be added after MEP_ScaleFactor multiplied by fractional duty cycle.
- p) **Example_2802xSCI_Echoback.c, Example_2802xCpuTimer.c, Example_2802xI2C_eeprom.c** – support 50 MHz timings.

Changes from V1.10 to V1.20

Changes to Common Files:

- q) **SFO_TI_Build_V6.lib (SFO_TI_Build_V6b.lib)** – Original SFO_TI_Build_V6.lib did not automatically write the MEP_ScaleFactor into the HRMSTEP register. SFO_TI_Build_V6b.lib now updates the HRMSTEP register with the MEP_ScaleFactor value automatically. Additionally, added an errata document to the /doc directory explaining the difference.
- r) **DSP2802x_OscComp.c** – Adds functions required for internal oscillator frequency compensation over temperature. The file is added to the /DSP2802x_common/source/ directory. Also added document in /doc directory explaining various functions defined in this file.
- s) **DSP2802x_TempSensorConv.c**- Adds functions required for ADC temp sensor to convert digital ADC samples to Kelvin and Celsius temperature value. The file is added to the /DSP2802x_common/source/ directory.
- t) **DSP2802x_GlobalPrototypes.h** – Added function prototypes from DSP2802x_OscComp.c and DSP2802x_TempSensorConv.c files.
- u) **DSP2802x_SysCtrl.c**- Added “EALLOW” for XtalOscSel and ExtOscSel functions so the bit settings take effect when calling these functions.
- v) **DSP2802x_Comp.c** – Fixed typo in comments referring to SDAA and SCLA operation – changed this to CMP1OUT and CMP2OUT.
- w) **DSP2802x_Epwm.c** – Fixed typo in comments such that GPIO3 refers to EPWM2B and not EPWM3B.
- x) **F28026.cmd, F28022.cmd, F280200.cmd** – Split sectors A and B (size 0x2000) into sectors A, B, C, and D (size 0x1000).
- y) **F280200.cmd**- Split sector A (size 0x2000) into sector A and B (size 0x1000).

Changes to Example Files:

- z) **All CCSv4 example .cdtbuild Files-** Replaced any hardcoded references to "C:/tidcs/c28/DSP2802x/<version>" for OBJ and ASM directories and replaced with "\${INSTALLROOT_2802X_<version>}" macro. This did not affect CCSv4 project build in previous version, but improves portability.
- aa) **Example_28021_Flash.pjt, Example_28020_Flash.pjt, Example_280200_Flash.pjt** – Added PJT files for 28021, 28020, and 280200 devices in the flash example directory.
- bb) **Example_2802xHRPWM_Duty_SFO_V6.c** – Made "temp" a "Uint32" (unsigned long) variable for proper operation.
- cc) **Example_2802xHRPWM_Duty_SFO_V6.pjt, Example_2802xHRPWM_PrdUp_SFO_V6.pjt, Example_2802xHRPWM_PrdUpDown_SFO_V6.pjt** – Replaced SFO_TI_Build_V6.lib with SFO_TI_Build_V6b.lib under source files.
- dd) **Example_2802xAdc_TempSensorConv**– Added new example to convert ADC temp sensor samples to Celsius or Kelvin temperature values.
- ee) **Example_2802xOscComp**- Added new example to demonstrate oscillator frequency compensation with temperature variation.
- ff) **Added DSP2802x_examples_ccsv4 directories** - Added directories for CCSv4.x projects. The example projects in these directories are identical to those found in the normal CCSv3.x DSP2802x_examples directory with the exception that the examples now support the Code Composer Studio v4.x project folder format instead of the Code Composer Studio v3.x PJT files. The example gel files have also been removed for the CCSv4 example projects because the gel file functions used in the example gels are no longer supported.

Changes from V1.00 to V1.10

Changes to Header Files:

- a) **DSP2802x_Device.h** – Removed 28024 and 28025 devices. Added 28021, 28020, 280200 devices.
- b) **DSP2802x_Gpio.h** – Removed XCLKINSEL register (bit exists in XCLK register in DSP2802x_SysCtrl.h file). Removed GPBPUD register structure.
- c) **DSP2802x_EPwm.h** – Removed PWMSYNCSEL bit from HRPCTL register.
- d) **DSP2802x_Headers_BIOS.cmd** – Added file (previously missing) to support DSP/BIOS for 2802x.
- e) **DSP2802x_SysCtrl.h** – Removed JTAGDEBUG register.
- f) **DSP2802x_DevEmu.h**- Added BORCFG register.

- g) **DSP2802x_DefaultIsr.h**- Added #defines for TINT1 to INT13 and TINT2 to INT14 so change from TINT1 and TINT2 to INT13 and INT14 does not break pre-existing projects.

Changes to Common Files:

- h) **SFO_TI_Build_V6.lib and SFO_V6.h** – SFO library updated to generate error code of “2” when MEP_ScaleFactor>255 (previously returned “2” for MEP_ScaleFactor>254). Additionally, the library now only updates the HRMSTEP register used for auto-conversion with the calibrated MEP_ScaleFactor if MEP_ScaleFactor<=255. Otherwise it will use the last “good” value written to HRMSTEP for auto-conversions (previously, if the MEP_ScaleFactor>255, auto-conversion could not be used).
- i) **f28024.gel and f28025.gel, 28024_RAM_Ink.cmd, 28025_RAM_Ink.cmd, DSP2802x_Examples.h** – Removed the 28024 and 28025 devices.
- j) **f28020.gel, f28021.gel, and f280200.gel, DSP2802x_Examples.h** – Added the 28021, 28020, and 280200 devices.
- k) **All device gel files** – Added HRPWR and HRMSTEP registers (previously missing), fixed COMP register addresses. Removed PF3 from memory map. Removed MAPCNF register. Added 0xD00-0xE00 to Page 0 memory map (specifically to allow CCStudio to access these memories when using DSP/BIOS)
- l) **F28027.cmd**- Changed CSM_PWL_PROG to CSM_PWL_P0 SECTION name to match other devices.
- m) **All device .cmd files**- Moved BOOT_RSVD to PAGE1 data space
- n) **CCSv4 gel files** – Added ccsv4 directory in /gel directory for CCSv4-specific device gel files (GEL_WatchAdd() functions removed).
- o) **DSP2802x_Adc.c** – Change US_DELAY to 1000L instead of 5000L.
- p) **DSP2802x_SysCtrl.c** – Replaced ExtClkSel() with XtalOscSel() and ExtOscSel() functions.
- q) **DSP2802x_PieVect.c** - Fix comment typos for ADCINT's.
- r) **DSP2802x_PieVect.c, DSP2802x_SWPrioritizedPieVect.c, DSP2802x_DefaultIsr.c, DSP2802x_SWPrioritizedDefaultIsr.c** – Changed TINT1 and TINT2 to INT13 and INT14, respectively.
- s) **Example_2802xAdcTempSensor** - Added ADC temperature sensor project.
- t) **DSP2802x_CpuTimers.c** – Corrected note that DSP/BIOS reserved CpuTimer2 only and user must comment out CpuTimer2 code when using DSP/BIOS. CpuTimer0 and 1 have no such restriction.

Changes to Example Files:

- u) **All PJT Files**- Removed the line: Tool="DspBiosBuilder" from all example PJT files for easy migration path to CCSv4 Microcontroller-only (code-size limited) version users.

- v) **Example_28022_Flash.pjt** – Replaced F28023.cmd with F28022.cmd.
- w) **All Flash example PJT files** – Removed extra DSP2802x_usDelay.asm file.
- x) **Example_2802xAdcSoc.c** – Added 2802x boot rom table to the top of the file.
- y) **Example_2802xHRPWM_Duty_SFO_V6.c and Example_2802xHRPWM_PrdUpDown_SFO_V6.c** – Removed references to 2804 and replaced with 2802.
- z) **Example_2802xLPMHaltWake.c** – Updated description comments for wakeup.
- aa) **Example_2802xLEDBlink-** Added new example.
- bb) **Added DSP2802x_examples_ccsv4 directories** - Added directories for CCSv4.x projects. The example projects in these directories are identical to those found in the normal CCSv3.x DSP2802x_examples directory with the exception that the examples now support the Code Composer Studio v4.x project folder format instead of the Code Composer Studio v3.x PJT files. The example gel files have also been removed for the CCSv4 example projects because the gel file functions used in the example gels are no longer supported.

V1.00

- ☐ This version is the first customer release of the DSP2802x header files and examples.