

**DSP/BIOS™ LINK****ENHANCED MULTIPROCESS SUPPORT****LNK 157 DES****Version 0.30**

This page has been intentionally left blank.

## **IMPORTANT NOTICE**

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Mailing Address:  
Texas Instruments  
Post Office Box 655303  
Dallas, Texas 75265

Copyright ©. 2003, Texas Instruments Incorporated

This page has been intentionally left blank.

---

**TABLE OF CONTENTS**

---

<b>1</b>	<b>Introduction .....</b>	<b>6</b>
1.1	Purpose & Scope .....	6
1.2	Terms & Abbreviations .....	6
1.3	References .....	6
1.4	Overview .....	6
<b>2</b>	<b>Requirements .....</b>	<b>7</b>
<b>3</b>	<b>Assumptions .....</b>	<b>8</b>
<b>4</b>	<b>Constraints .....</b>	<b>8</b>
<b>5</b>	<b>High Level Design .....</b>	<b>9</b>
5.1	Features .....	9
5.2	Use case scenario .....	9
5.3	Design details .....	10
<b>6</b>	<b>Low Level Design .....</b>	<b>13</b>
6.1	Constants & Enumerations .....	13
6.2	Typedefs & Data Structures .....	13
6.3	API Definition .....	15

## 1 Introduction

### 1.1 Purpose&Scope

This document describes the design of enhanced multi-process support for DSP/BIOS™ LINK.

The document is targeted at the development team of DSP/BIOS™ LINK.

### 1.2 Terms&Abbreviations

<i>DSPLINK</i>	DSP/BIOS™ LINK
	This bullet indicates important information. Please read such text carefully.
<input type="checkbox"/>	This bullet indicates additional information.

### 1.3 References

1.	LNK 001 PRD	DSP/BIOS™ LINK Generic Product Requirement Document
2.	LNK 147 PRD	DSP/BIOS™ LINK Version-specific Product Requirement Document

### 1.4 Overview

DSP/BIOS™ LINK is runtime software, analysis tools, and an associated porting kit that simplifies the development of embedded applications in which a general-purpose microprocessor (GPP) controls and communicates with a TI DSP. DSP/BIOS™ LINK provides control and communication paths between GPP OS threads and DSP/BIOS™ tasks, along with analysis instrumentation and tools.

This module provides the design for enhanced multi-process support within *DSPLINK*. This allows multiple applications/processes to use *DSPLINK* independently, and without being aware of each other.

## 2 Requirements

### SR110. (1.50) Enhanced multi-process support

DSP/BIOS Link must offer enhanced multi-process support. This must include the following:

- Multiple unrelated processes must be able to come and go. There must be no hidden dependencies based on which process, for example, first used PROC\_attach as there are in the current version. The first process to attach to the DSP must not be required to be the last to detach.

- \* A reference count shall be used to ensure that the last PROC\_detach () cleans up the system instead of processor ownership checks.

- Multiple independent applications must be able to gain access to, and utilize the resources provided by the DSP for the PROC module.

- \* Multiple applications must be able to make calls to PROC\_load () or PROC\_start (). However, based on reference count, and if the applications are attempting to load the same DSP executable, a corresponding status code must be returned instead of re-loading the DSP. Reference count shall be checked for PROC\_start () and PROC\_stop () also.

### **3 Assumptions**

None.

### **4 Constraints**

1. Since PrOS only supports threads and not processes, PROC\_attach () must not be called for each thread in PrOS applications.

## 5 HighLevelDesign

Multiple applications may wish to use the services provided by *DSPLINK* to control and communicate with the DSP. In such scenarios, with existing versions of DSP/BIOS™ LINK, the applications must be integrated by a system integrator, to ensure that the first application initializes *DSPLINK*, and loads and starts the DSP before the second application can communicate with the DSP.

It is desirable to avoid such integration and allow independently developed applications to use *DSPLINK* without being aware of other applications doing the same.

In addition, if multiple different applications using *DSPLINK* are running on the target processor, a crash in one of these must not affect the execution of the other application.

### 5.1 Features

The following features shall be provided for enhanced multi-process support:

1. An application can be written to execute singly using *DSPLINK* to control and communicate with the DSP.
2. The same application can be used without any changes in the applications source code, to run simultaneously along with another application also using *DSPLINK*. The only consideration to be used while writing the application, is that the *DSPLINK* resources (e.g RingIO/MSGQ names) used by the applications must be unique for the system.
3. The applications shall use the same integrated DSP executable containing DSP-side content required for all the co-existing GPP-side applications.

### 5.2 Usecasescenario

The following use-case scenario shall be supported:

Two applications contain source as follows:

```
PROC_setup (...) ;
PROC_attach (...) ;
POOL_open (poolId, poolParams) ;
PROC_load (... , dspExec, ...) ;
PROC_start (...) ;
/* Application-specific code */
PROC_stop (...) ;
POOL_close (...) ;
PROC_detach (...) ;
PROC_destroy (...) ;
```

Both the applications can start-up and run independently if run singly. They can also start-up and run independently if run at the same time on Linux.

The behavior seen by the applications shall be the same irrespective of the sequence in which the calls actually get made to *DSPLINK*. An overview of the activities occurring in each API, depending on the sequence in which it gets called, is given below. It may not be necessary that the first occurrence for all APIs occurs only for the first application.

API	First occurrence	Second occurrence
PROC_setup	Sets up GPP-side of DSPLINK	No activity. Does not result in actually allocating any resources for <i>DSPLINK</i> .
PROC_attach	Performs all activities required to be able to access the DSP resources from this process.	Performs all activities required to be able to access the DSP resources from this process.
POOL_open	Configures the specified pool with the specified parameters	If the same pool is opened, it is made available to the process. No change is made in the pool configuration and the parameters are ignored.
PROC_load	Loads the specified DSP executable on the DSP.	If the same DSP executable is specified, the DSP state is not changed, and the executable is not actually loaded on the DSP.
PROC_start	Starts the DSP executing from its entry point.	The DSP state is not changed, and this call does not result in actually starting the DSP execution.
PROC_stop	Does not actually stop the execution of the DSP, since it is still being used by the second application.	Stops execution of the DSP and places it in reset.
POOL_close	Does not result in actually closing the pool. Only makes the pool unavailable to this process.	Closes the pool and makes it unavailable to any process/DSP.
PROC_detach	Releases all resources that were acquired for this process in PROC_attach.	Releases all resources that were acquired for this process in PROC_attach.
PROC_destroy	No activity. Does not result in freeing any resources in <i>DSPLINK</i> .	Releases all allocated resources on the GPP-side of <i>DSPLINK</i> . Following this, no further calls can be made to <i>DSPLINK</i> APIs.

## 5.3 Designdetails

### 5.3.1 Changestoownershipconcept:

1. The first process to attach shall not be designated as the owner of the DSP.
2. PROC\_setup ()/PROC\_destroy (): PMGR\_IsSetup flag shall be replaced by PMGR\_SetupRefCount reference count. This reference count shall be incremented in PROC\_setup () and decremented in PROC\_destroy. If refCount is 0, actual setup is done. When the reference count reaches 0, actual destroy is done.
3. PROC\_attach ()/PROC\_detach (): PMGR\_PROC\_Object shall be modified to include an attachRefCount field. This reference count shall be incremented in

`PROC_attach ()` and decremented in `PROC_detach ()`. If reference count is 0, actual attach is done. When reference count reaches 0, actual detach is done, and DSP is powered down if power control is enabled in the configuration.

4. `PROC_load ()`: The DSP state shall be used to identify whether it has been already loaded. If already loaded, this call does not result in any actual load on the DSP.
5. `PROC_start ()/PROC_stop ()`: `PMGR_PROC_Object` shall be modified to include a `startRefCount` field. The reference count shall be incremented in `PROC_start ()` and decremented in `PROC_stop ()`. If reference count is 0, actual start is done. When reference count reaches 0, actual stop is done.

### 5.3.2 Multi-processcleanuponLinux:

To support cleanup in a multi-processing scenario, the PROC resources allocated by the process getting terminated shall be freed during cleanup. The system state shall not be polluted, and other applications can continue using *DSPLINK* to communicate with the DSP.

For every process, PROC, MSGQ and POOL setup and shutdown calls shall be tracked. It shall be tracked whether the following APIs have been called by the process:

- `PROC_setup`
- `PROC_attach`
- `POOL_open` (for all the max. possible pools)
- `PROC_start`
- `MSGQ_transportOpen`
- `MSGQ_transportClose`
- `PROC_stop`
- `POOL_close`
- `PROC_detach`
- `PROC_destroy`

With this tracking, it shall be checked in shutdown APIs, whether the corresponding startup call had been made for that process. This shall ensure that an errant process does not corrupt the reference count for each API, resulting in causing a crash in other processes.

There are two scenarios, for which cleanup is to be performed:

1. **Abnormal process termination:** When an application process ends abnormally, all threads within it are killed. This can happen for any of the following scenarios:
  - Application crash
  - Segmentation fault
  - Any other crash resulting in kernel still remaining usable
  - User kills the process with Ctrl C
  - User kills the process through kill command

In all these scenarios, it must be possible to:

- Continue execution of other applications using *DSPLINK*.
- Perform basic shutdown calls for PROC, POOL and MSGQ to free these basic resources allocated by this process.

- Minimize memory or resource leaks.
- Allow stopping & restarting *DSPLINK* without having to reinsert the kernel module or reboot the hardware.

On Linux, this shall be done by registering a signal handler for process termination signals. This signal handler shall make all shutdown API calls.

- Signal handling shall be enabled by default
- Whether *DSPLINK* should handle signals for cleanup shall be dynamically configurable
- The signals to be handled shall be dynamically configurable

2. **Normal exit:** When an application exits, it performs the shutdown calls for PROC, POOL and MSGQ to free these basic resources allocated by it. If this is not done, the kernel resources and shared memory resources become unavailable to other applications, and are lost. *DSPLINK* shall allow applications to exit, making a minimum of exit API calls to free up all resources allocated by that process.

On Linux, this shall be done by registering an atexit handler that makes all shutdown APIs calls.

## 6 LowLevelDesign

### 6.1 Constants&Enumerations

None.

### 6.2 Typedefs&DataStructures

#### 6.2.1 PROC\_CurStatus

This structure defines the current status of the PROC component for each process.

##### Definition

```
typedef struct PROC_CurStatus_tag {
    Bool  isSetup ;
    Bool  isAttached  [MAX_DSPS] ;
    Bool  isStarted   [MAX_DSPS] ;
#ifdef (POOL_COMPONENT)
    Bool  poolIsOpened [MAX_POOLENTRIES] ;
#endif /* if defined (POOL_COMPONENT) */
#ifdef (MSGQ_COMPONENT)
    Bool  mqtIsOpened [MAX_DSPS] ;
#endif /* if defined (MSGQ_COMPONENT) */
} PROC_CurStatus ;
```

##### Fields

isSetup	Indicates whether PROC has been setup in this process.
isAttached	Indicates whether PROC has been attached in this process for the specified processor ID.
isStarted	Indicates whether PROC has been started in this process for the specified processor ID.
poolIsOpened	Indicates whether POOL has been opened in this process for the specified pool ID. Only defined if POOL component is enabled.
mqtIsOpened	Indicates whether MSGQ transport has been opened in this process for the specified processor ID. Only defined if MSGQ component is enabled.

##### Comments

This structure is used for tracking the PROC, MSGQ and CHNL startup and shutdown API calls made in each process. This is required to ensure that if a process has not called the startup API, it should not be allowed to call the corresponding shutdown API.

##### Constraints

None.

##### SeeAlso

PROC\_Object

### 6.2.2 PROC\_Object

This structure defines the PROC object, which contains state information required by the PROC user-side component.

#### Definition

```
typedef struct PROC_Object_tag {  
    SYNC_USR_CsObject * syncCsObj ;  
    PROC_CurStatus      curStatus ;  
} PROC_Object ;
```

#### Fields

<code>syncCsObj</code>	Mutex for protecting PROC operations in user-space.
<code>curStatus</code>	Current status for the components for each process.

#### Comments

This object is maintained in user space for each process and contains information for protecting and tracking user-space resources.

#### Constraints

None.

#### SeeAlso

`PROC_CurStatus`

## 6.3 APIDefinition

### 6.3.1 PROC\_setup

This function sets up the necessary data structures for the PROC component.

#### Syntax

```
DSP_STATUS PROC_setup (LINKCFG_Object * linkCfg) ;
```

#### Arguments

IN	LINKCFG_Object *	linkCfg
----	------------------	---------

Pointer to the configuration information structure for DSP/BIOS™ LINK. If NULL, indicates that default configuration should be used.

#### ReturnValue

DSP_SOK	Operation successfully completed.
DSP_SALREADYSETUP	The <i>DSPLINK</i> driver has already been setup by some other application/process.
DSP_EALREADYSETUP	The <i>DSPLINK</i> driver is already setup in this process.
DSP_ECONFIG	Error in specified dynamic configuration. Please check CFG_<PLATFORM>.c
DSP_EMEMORY	Operation failed due to memory error.
DSP_EFAIL	General failure.

#### Comments

This function is the first *DSPLINK* API that applications must call before they can make calls to any other *DSPLINK* APIs. The only *DSPLINK* API that can be called before `PROC_setup` is `PROC_getState ()`.

This API initializes the *DSPLINK* driver. This API can be successfully called once by every process in the system. However, it is not a must for every application/process to make the call, if at least one process has initialized the *DSPLINK* driver before the other applications/processes.

If this API is called more than once in a single process (even if called by different threads within the process), the subsequent calls return an error.

#### Constraints

1. The calling applications must ensure that the contents of the dynamic configuration structure passed to this API are correct.
2. If called by multiple applications, the calling applications must pass the same dynamic configuration structure to this API. Otherwise it can result in indeterminate system behavior.

#### SeeAlso

`PROC_destroy ()`

### 6.3.2 PROC\_destroy

This function destroys the data structures for the PROC component, allocated earlier by a call to `PROC_setup ()`.

#### Syntax

```
DSP_STATUS PROC_destroy (Void) ;
```

#### Arguments

None.

#### ReturnValue

DSP_SOK	Operation successfully completed.
DSP_SDESTROYED	The final client has finalized the driver.
DSP_EACCESSDENIED	The <i>DSPLINK</i> driver was not setup in this process.
DSP_ESETUP	The <i>DSPLINK</i> driver was not setup.
DSP_EMEMORY	Operation failed due to memory error.
DSP_EFAIL	General failure.

#### Comments

This function is the last *DSPLINK* API that applications must call after they have no further need to use *DSPLINK* services. The only *DSPLINK* API that can be called before `PROC_setup` is `PROC_getState ()`.

This API finalizes the *DSPLINK* driver. This API can be successfully called once by every process in the system. However, if the `PROC_setup ()` API was not called in the process, `PROC_destroy ()` must not be called.

If this API is called more than once in a single process (even if called by different threads within the process), the subsequent calls return an error.

#### Constraints

None.

#### SeeAlso

`PROC_setup ()`

### 6.3.3 PROC\_attach

This function attaches the client to the specified DSP and also initializes the DSP (if required).

#### Syntax

```
DSP_STATUS PROC_attach (ProcessorId   procId, PROC_Attrs * attr) ;
```

#### Arguments

IN            ProcessorId                            procId

DSP identifier.

IN OPT      PROC\_Attrs \*                            attr

Optional attributes for the processor on which attach is to be done.

#### ReturnValue

DSP_SOK	Operation successfully completed.
DSP_SALREADYSETUP	Successful attach. Also, indicates that another client has already attached to DSP.
DSP_EINVALIDARG	Invalid argument.
DSP_EACCESSDENIED	Not allowed to access the DSP.
DSP_EALREADYCONNECTED	Another thread of the same process has already attached to the processor.
DSP_EWRONGSTATE	Incorrect state for completing the requested operation.
DSP_EFAIL	General failure.

#### Comments

When any client wishes to use a specific DSP, it first needs to attach to the DSP by calling this API specifying the required DSP ID.

Every process that needs to use *DSPLINK* with the specific DSP must make a call to this API.

This API carries out all initialization required to be able to use *DSPLINK* with the specified DSP ID from the calling process. This API can be successfully called once by every process in the system. If this API is called more than once in a single process (even if called by different threads within the process), the subsequent calls return an error.

#### Constraints

PROC\_setup () must be called by at least one client in the system before any process can call this API.

#### SeeAlso

PROC\_detach ()

### 6.3.4 PROC\_detach

This function detaches the client from specified processor. If the caller is the owner of the processor, this function releases all the resources that this component uses and puts the DSP in an unusable state (from application perspective).

#### Syntax

```
DSP_STATUS PROC_detach (ProcessorId procId) ;
```

#### Arguments

IN	ProcessorId	procId
	DSP identifier.	

#### ReturnValue

DSP_SOK	Operation successfully completed.
DSP_SDETACHED	The final process has detached from the specific processor.
DSP_EINVALIDARG	Invalid argument.
DSP_ESETUP	The <i>DSPLINK</i> driver was not setup.
DSP_EACCESSDENIED	Not allowed to access the DSP.
DSP_EATTACHED	Not attached to the target processor.
DSP_EWRONGSTATE	Incorrect state for completing the requested operation.
DSP_EFAIL	General failure.

#### Comments

This function is the last *DSPLINK* API that all applications/processes must call after they have no further need to use *DSPLINK* services for a specific processor ID. Once this API has been called, the process cannot perform any further activities specific to the DSP.

This API finalizes the *DSPLINK* driver for the specified processor ID in the calling process. This API can be successfully called once by every process in the system. However, if the `PROC_attach ()` API was not called in the process for the specific processor ID, `PROC_detach ()` must not be called.

If this API is called more than once in a single process (even if called by different threads within the process), the subsequent calls return an error.

#### Constraints

None.

#### SeeAlso

`PROC_attach ()`

### 6.3.5 PROC\_load

This function loads the specified DSP executable on the target DSP.

#### Syntax

```
DSP_STATUS PROC_load (ProcessorId  procId,
                      Char8 *      imagePath,
                      Uint32       argc,
                      Char8 **     argv) ;
```

#### Arguments

IN	ProcessorId	procId	DSP identifier.
IN	Char8 *	imagePath	Full path to the image file to load on DSP.
IN	Uint32	argc	Number of argument to be passed to the base image upon start.
IN	Char8 **	argv	Arguments to be passed to DSP main application.

#### ReturnValue

DSP_SOK	Operation successfully completed.
DSP_SALREADYLOADED	The specified processor has already been loaded.
DSP_EINVALIDARG	Invalid argument.
DSP_EACCESSDENIED	Not allowed to access the DSP.
DSP_ESETUP	The <i>DSPLINK</i> driver has not been setup.
DSP_EATTACHED	This process has not attached to the specified processor.
DSP_EPENDING	H/W specific error. The request can't be serviced at this point of time.
DSP_EFILE	Invalid base image.
DSP_ESIZE	Size of the .args section is not sufficient to hold the passed arguments.
DSP_EWRONGSTATE	Incorrect state for completing the requested operation.
DSP_EFAIL	General failure.

**Comments**

Any client that wishes to use the DSP can call this API to load the DSP executable on it. However, only the first client to call this API actually loads the DSP. The subsequent calls are ignored.

**Constraints**

All applications using a specific DSP at the same time must ensure that they use the same base DSP executable.

**SeeAlso**

`PROC_start ()`

### 6.3.6 PROC\_start

This function starts execution of the loaded code on DSP from the starting point specified in the DSP executable loaded earlier by call to `PROC_load ()`.

#### Syntax

```
DSP_STATUS PROC_start (ProcessorId procId) ;
```

#### Arguments

IN	ProcessorId	procId
----	-------------	--------

DSP identifier.

#### ReturnValue

DSP_SOK	Operation successfully completed.
DSP_SALREADYSTARTED	The specified processor has already been started.
DSP_EINVALIDARG	Invalid argument.
DSP_EPENDING	H/W specific error. The request can't be serviced at this point of time.
DSP_EACCESSDENIED	Not allowed to access the DSP.
DSP_ESETUP	The <i>DSPLINK</i> driver has not been setup.
DSP_EATTACHED	This process has not attached to the specified processor.
DSP_EWRONGSTATE	Incorrect state for completing the requested operation.
DSP_ECONFIG	The specified processor could not be started. Driver handshake failed due to DSP driver initialization/configuration failure.
DSP_EFAIL	General failure.

#### Comments

Any client that wishes to use the DSP can call this API to start the DSP executable on it. However, only the first client to call this API actually starts the DSP. The subsequent calls are ignored.

#### Constraints

All applications using a specific DSP at the same time must ensure that they use the same base DSP executable.

#### SeeAlso

```
PROC_load ()  
PROC_stop ()
```

### 6.3.7 PROC\_stop

This function stops execution of the specified DSP. This API may place the DSP in reset.

#### Syntax

```
DSP_STATUS PROC_stop (ProcessorId procId) ;
```

#### Arguments

IN	ProcessorId	procId
	DSP identifier.	

#### ReturnValue

DSP_SOK	Operation successfully completed.
DSP_SSTOPPED	The final process has stopped the DSP execution.
DSP_EINVALIDARG	Invalid argument.
DSP_EACCESSDENIED	Not allowed to access the DSP.
DSP_ESETUP	The <i>DSPLINK</i> driver has not been setup.
DSP_EATTACHED	This process has not attached to the specified processor.
DSP_EWRONGSTATE	Incorrect state for completing the requested operation.
DSP_ESTARTED	The specified processor has not been started.
DSP_EFAIL	General failure.

#### Comments

Once a process has completed its processing requiring transfers with the DSP, it can call this API to stop the execution of the DSP with this API. However, it is not essential to call this API if it has been previously called by some other application/process.

Only the last client to call this API actually stops the DSP. The earlier calls are ignored.

If the `PROC_start ()` API was not called in the process, `PROC_stop ()` must not be called.

If this API is called more than once in a single process (even if called by different threads within the process), the subsequent calls return an error.

#### Constraints

None.

#### SeeAlso

`PROC_load ()`