

# beaglebone

---

- Insert the provided TI Linux EZ SDK SD card into the BeagleBone
- Connect an Ethernet cable (not provided) to the BeagleBone and to a Linux host PC
- Insert the provided USB cable (power/serial/JTAG) into the BeagleBone and to a Linux host PC
- The BeagleBone will boot automatically (~50 secs)
- On the Linux host PC, open the **START\_HERE** directory that appears on the desktop
- Double click on the **START\_HERE.sh** script
- Follow the on-screen instructions to enable the remote GUI and to start your development
- Visit [www.ti.com/linuxsdk](http://www.ti.com/linuxsdk) for software updates